Sound Font Configuration

Project maintained by profezzorn

Hosted on GitHub Pages — Theme by mattgraham

A sound font is mostly made up of many sound files in a single directory. Let's take a look at the following example and break down the important aspects.



This file name is made up of four main parts:

- >> The directory (Yellow) This can be anything you want, and is typically the name of the font. All sound and config files must be in the same final directory, but fonts can be organized in to as many sub-directories as you want. The first entry in the presets[] array specifies the full path to the font directory. For example, you can have your fonts sorted as sith\1\sith1, or fonts\jedi\named\obiwan , etc.
- >>> The name (Magenta) This is the name of the sound type, using the names specified below in the Sound Effect Names section. In this example, it's a clash sound.
- >>> The number (Cyan) If you want to have multiple sound effects of the same type, add a number to the end of the filename before the extension. The numbers can be in the following format:
 - >> 1,2,3, etc.
 - » 01, 02, 03, etc.
 - >> 001, 002, 003, etc.

The number sequence must be consistent and without any gaps. It's also possible to omit the number completely if there is only a single sound. When playing a sound, ProffieOS will generally pick one of them randomly. For looping sounds, ProffieOS will randomly pick one of the numbered files each time it starts over. This means it's possible to create a more interesting hum by having hum.wav , hum1.wav , hum2.wav , etc.

- >> Note: While Proffie-based boards support long filenames, Teensy-based boards support a maximum of 8 characters for file names. It is recommended to stick to this maximum to ensure full compatibility with any sound board.
- >> The extension (Pink) The recommended format is .wav files that are 44khz, 16-bit mono PCM. ProffieOS also supports 11khz, 22khz, and 44khz .wav in both mono and stereo. You may also use .raw and .usl files, but they must be 44khz mono.

Alternative font file naming

Instead of font1/NameNNN.wav, you can also use font1/Name/NNN.wav, which lets you have more files and better organization. font1/Name/NameNNN.wav is also supported for compatibility with Igniter boards.

Font Search Paths.

You can have ProffieOS look in multiple directories for font and animation files, as well as config.ini and smoothsw.ini files. Primarily, this is meant to make it easier to share files like "ccbegin" and "ccend" between fonts, but it can also be used for more advanced things, like adding different quotes to a font. So how do you use this? Basically, you just specify a list of directories with a semicolon in between.

So if your current preset says "font1", you could change it to "font1; common" to have it first search "font1", and any files found there will be used first. After that ProffieOS will search "common" and add any files not already found. A prime example of how this can be used is the "hero" font pack. You could have one "hero/font; hero/obiwan; common" preset, and another "hero/font; hero/luke; common" preset, without having to duplicate the files in the "hero/font" directory.

Currently, the only limit on how many directories you can search is that the whole list of directories must be less than 127 characters.

One caveat, you can't mix files with the same base name. Let's say hero/font contains preon01.wav. Even if hero/obiwan contains preon02.wav, it will not be used. The decision of which directory to use is done *once* for all files with the same "name", individually for each numbered file.

Note This feature is only available in ProffieOS 4.x. and later.

Sound Effect Names

The name part of the filename needs to be one that ProffieOS can recognize. Sounds can either be monophonic (Plecter) or polyphonic (Naigon Electronics) style. ProffieOS will automatically decide if a specific sound type is monophonic or polyphonic font based on the filename. Monophonic sounds will smoothly join with the hum when they are finished playing. Polyphonic sounds will automatically mix with the hum sound. Keep in mind that you cannot mix mono and polyphonic sounds for the same effect. For example, if you are using clash , you cannot use clsh as well. You can, however, mix for different effects. You could use clash alongside blst in the same font for example.

The following sounds are triggered along with blade animations. The buttons, gestures, or actions used to trigger them is specific to the prop file being used.

See The-CONFIG_PROP-section for a list of prop files included with ProffieOS. Additional sounds are available when using some props, such as quote . Each prop will have instructions in the top comment section for how to use it. If you are using the default saber.h prop, you can also read How to use ProffieOS for more details.

List of Names and Effects

Monophonic Filename	Polyphonic Filename	Effect
boot	boot	Played when ProffieOS boots up.
swing	swng	Accent swing sounds that play near the peak of a swing motion.
N/A	swingl	If present with swingh, the SmoothSwing algorithm will be used to generate swing sounds from these files when the saber is moved around.
N/A	swingh	If present with swing1, the SmoothSwing algorithm will be used to generate swing sounds from these files when

s1sh s1sh than the threshold set in either config.ini or smoothsw.in (OS3.x and up) stab stab Played when you make a stabbing motion (OS3.x and up) blaster b1st Blaster deflection sound. lockup lock Sound when blades come together and struggle. bgnlock bgnlock Played when lockup starts endlock endlock Played when lockup ends (if not present, clash is used) drag drag Sound for dragging the tip of the saber blade. bgndrag bgndrag Begin drag enddrag enddrag End drag lb Force lightning block. bgnlb Begin lightning block. endlb End lightning block. melt Simulate stabbing and melting an object with blade tip. bgnmelt Begin melt endmelt End melt poweronf N/A Force power on. (not yet implemented in ProffieOS) font font Played when you switch to this preset. N/A ccbegin Played when entering color change mode. Played when changing color in "stepped" color change.	Monophonic Filename	Polyphonic Filename	Effect
poweron out Extension sound when you ignite the blade. poweroff , pwroff , in Retraction sound when the blade is shut off. clash clsh Played when you hit something with the saber force Force use sound. slsh slsh slsh Played when you make a swing that is accelerating faster than the threshold set in either config.ini or smoothsw.in (OS3.x and up) stab stab Played when you make a stabbing motion (OS3.x and up) stab stab Played when you make a stabbing motion (OS3.x and up) stab stab Played when you make a stabbing motion (OS3.x and up) stab stab Played when pout make a stabbing motion (OS3.x and up) blaster blst Blaster deflection sound. lockup lock Sound when blades come together and struggle. bgnlock bgnlock Played when lockup starts endlock endlock Played when lockup ends (if not present, clash is used) drag drag Sound for dragging the tip of the saber blade. bgndrag bgndrag Begin drag enddrag enddrag End drag enddrag enddrag End drag lb Force lightning block. endlb Begin lightning block. endlb End lightning block. endlb End lightning block. endlb End melt bgnmelt Begin melt endmelt End melt poweronf N/A Force power on. (not yet implemented in ProffieOS) font font Played when you switch to this preset. N/A ccbegin Played when entering color change mode. N/A ccend Played when entering color change mode. Played when exiting color change mode Played when changing color in "stepped" color change mode Played when changing color in "stepped" color change mode Played before the blade turns on pstoff pstoff Played after retraction when the blade turns off			the saber is moved around.
poweroff powroff in Retraction sound when the blade is shut off. clash clsh Played when you hit something with the saber force force Force use sound. Played when you make a swing that is accelerating faster than the threshold set in either config.ini or smoothsw.in (OS3.x and up) stab stab Played when you make a stabbing motion (OS3.x and up) blaster blst Blaster deflection sound. lockup lock Sound when blades come together and struggle. bgnlock bgnlock Played when lockup starts endlock endlock Played when lockup ends (if not present, clash is used) drag drag Sound for dragging the tip of the saber blade. bgndrag bgndrag Begin drag enddrag enddrag End drag lb Force lightning block. bgnlb Begin lightning block. endlb End lightning block. endlb End lightning block. melt Simulate stabbing and melting an object with blade tip. bgnmelt Begin melt endmelt End melt poweronf N/A Force power on. (not yet implemented in ProffieOS) font font Played when entering color change mode. N/A ccend Played when entering color change mode Played when exiting color change mode Played when changing color in "stepped" color change mode Played when changing color in "stepped" color change mode Played when changing color in "stepped" color change mode Played before the blade turns on pstoff pstoff Played after retraction when the blade turns off	hum	hum	Played when the saber is on and stationary (looped)
pwroff clash clsh Played when you hit something with the saber force force Force use sound. Played when you make a swing that is accelerating faster than the threshold set in either config.ini or smoothsw.in (OS3.x and up) stab stab Played when you make a stabbing motion (OS3.x and up) blaster blst Blaster deflection sound. lockup lock Sound when blades come together and struggle. bgnlock bgnlock Played when lockup starts endlock endlock Played when lockup ends (if not present, clash is used) drag drag Sound for dragging the tip of the saber blade. bgndrag bgndrag Begin drag enddrag End drag lb Force lightning block. bgnlb Begin lightning block. endlb End lightning block. endlb End melt bgnmelt Begin melt endmelt End melt poweronf N/A Force power on. (not yet implemented in ProffieOS) font font Played when entering color change mode. N/A ccend Played when exiting color in "stepped" color change mode preon preon Played before the blade turns on pstoff Played after retraction when the blade turns off	poweron	out	Extension sound when you ignite the blade.
Force use sound. Played when you make a swing that is accelerating faster than the threshold set in either config.ini or smoothsw.in (OS3.x and up) stab stab Played when you make a stabbing motion (OS3.x and up) blaster blst Blaster deflection sound. lockup lock Sound when blades come together and struggle. bgnlock bgnlock Played when lockup starts endlock endlock Played when lockup ends (if not present, clash is used) drag drag Sound for dragging the tip of the saber blade. bgndrag bgndrag Begin drag enddrag enddrag End drag 1b Force lightning block. bgnlb Begin lightning block. endlb End lightning block. melt Simulate stabbing and melting an object with blade tip. bgnmelt Begin melt endmelt End melt poweronf N/A Force power on. (not yet implemented in ProffieOS) font font Played when you switch to this preset. N/A ccbegin Played when entering color change mode. N/A ccend Played when changing color in "stepped" color change mode preon preon Played before the blade turns on pstoff Played after retraction when the blade turns off		in	Retraction sound when the blade is shut off.
Played when you make a swing that is accelerating faster than the threshold set in either config.ini or smoothsw.in (OS3.x and up) stab stab Played when you make a stabbing motion (OS3.x and up) blaster blst Blaster deflection sound. lockup lock Sound when blades come together and struggle. bgnlock bgnlock Played when lockup starts endlock endlock Played when lockup ends (if not present, clash is used) drag drag Sound for dragging the tip of the saber blade. bgndrag bgndrag Begin drag enddrag enddrag End drag lb Force lightning block. bgnlb Begin lightning block. endlb End lightning block. melt Simulate stabbing and melting an object with blade tip. bgnmelt Begin melt endmelt End melt poweronf N/A Force power on. (not yet implemented in ProffieOS) font font Played when you switch to this preset. N/A ccbegin Played when entering color change mode. N/A ccend Played when entering color change mode Played when changing color in "stepped" color change mode preon preon Played before the blade turns on Played before the blade turns on	clash	clsh	Played when you hit something with the saber
s1sh s1sh than the threshold set in either config.ini or smoothsw.in (OS3.x and up) stab stab Played when you make a stabbing motion (OS3.x and up) blaster b1st Blaster deflection sound. lockup lock Sound when blades come together and struggle. bgnlock bgnlock Played when lockup ends (if not present, clash is used) drag drag Sound for dragging the tip of the saber blade. bgndrag bgndrag Begin drag enddrag enddrag End drag lb Force lightning block. bgnlb Begin lightning block. endlb End lightning block. melt Simulate stabbing and melting an object with blade tip. bgnmelt Begin melt endmelt End melt poweronf N/A Force power on. (not yet implemented in ProffieOS) font font Played when you switch to this preset. N/A ccbegin Played when entering color change mode. N/A ccend Played when exiting color in "stepped" color change mode preon preon Played before the blade turns on pstoff Played after retraction when the blade turns off	force	force	Force use sound.
blaster blst Blaster deflection sound. lockup lock Sound when blades come together and struggle. bgnlock bgnlock Played when lockup starts endlock endlock Played when lockup ends (if not present, clash is used) drag drag Sound for dragging the tip of the saber blade. bgndrag bgndrag Begin drag enddrag enddrag End drag lb Force lightning block. bgnlb Begin lightning block. endlb End lightning block. melt Simulate stabbing and melting an object with blade tip. bgnmelt Begin melt endmelt End melt poweronf N/A Force power on. (not yet implemented in ProffieOS) font font Played when you switch to this preset. N/A ccbegin Played when entering color change mode. N/A ccend Played when exiting color change mode N/A ccchange Played when changing color in "stepped" color change mode preon preon Played after retraction when the blade turns off	slsh	slsh	Played when you make a swing that is accelerating faster than the threshold set in either config.ini or smoothsw.in (OS3.x and up)
Tockup Tock Bonlock Bonlock Played when lockup starts endlock endlock Played when lockup ends (if not present, clash is used) drag drag Sound for dragging the tip of the saber blade. bgndrag enddrag End drag The Force lightning block. Begin lightning block. endlb End lightning block. melt Simulate stabbing and melting an object with blade tip. bgnmelt Begin melt endmelt End melt poweronf N/A Force power on. (not yet implemented in ProffieOS) font font Played when you switch to this preset. N/A ccbegin Played when entering color change mode. N/A Cccend Played when exiting color change mode Played when changing color in "stepped" color change mode preon preon Played after retraction when the blade turns off	stab	stab	Played when you make a stabbing motion (OS3.x and up)
bgnlock bgnlock Played when lockup starts endlock endlock Played when lockup ends (if not present, clash is used) drag drag Sound for dragging the tip of the saber blade. bgndrag bgndrag Begin drag enddrag enddrag End drag 1b Force lightning block. bgnlb Begin lightning block. endlb End lightning block. melt Simulate stabbing and melting an object with blade tip. bgnmelt Begin melt endmelt End melt poweronf N/A Force power on. (not yet implemented in ProffieOS) font font Played when you switch to this preset. N/A ccbegin Played when entering color change mode. N/A ccend Played when exiting color change mode Played when changing color in "stepped" color change mode preon preon Played before the blade turns on pstoff Played after retraction when the blade turns off	blaster	blst	Blaster deflection sound.
endlock endlock Played when lockup ends (if not present, clash is used) drag drag Sound for dragging the tip of the saber blade. bgndrag bgndrag Begin drag enddrag enddrag End drag 1b Force lightning block. bgnlb Begin lightning block. endlb End lightning block. melt Simulate stabbing and melting an object with blade tip. bgnmelt Begin melt endmelt End melt poweronf N/A Force power on. (not yet implemented in ProffieOS) font font Played when you switch to this preset. N/A ccbegin Played when entering color change mode. N/A ccend Played when exiting color change mode Played when changing color in "stepped" color change mode preon preon Played before the blade turns on pstoff Played after retraction when the blade turns off	lockup	lock	Sound when blades come together and struggle.
drag drag Sound for dragging the tip of the saber blade. bgndrag bgndrag Begin drag enddrag End drag 1b Force lightning block. bgn1b Begin lightning block. end1b End lightning block. me1t Simulate stabbing and melting an object with blade tip. bgnme1t Begin melt endme1t End melt poweronf N/A Force power on. (not yet implemented in ProffieOS) font font Played when you switch to this preset. N/A ccbegin Played when entering color change mode. N/A ccend Played when exiting color change mode N/A ccchange Played when changing color in "stepped" color change mode preon preon Played after retraction when the blade turns off	bgnlock	bgnlock	Played when lockup starts
bgndrag bgndrag Begin drag enddrag enddrag End drag 1b Force lightning block. bgn1b Begin lightning block. end1b End lightning block. melt Simulate stabbing and melting an object with blade tip. bgnmelt Begin melt endmelt End melt poweronf N/A Force power on. (not yet implemented in ProffieOS) font font Played when you switch to this preset. N/A ccbegin Played when entering color change mode. N/A ccend Played when exiting color change mode N/A ccchange Played when changing color in "stepped" color change mode preon preon Played before the blade turns on pstoff Played after retraction when the blade turns off	endlock	endlock	Played when lockup ends (if not present, clash is used)
enddrag End drag 1b Force lightning block. bgn1b Begin lightning block. end1b End lightning block. melt Simulate stabbing and melting an object with blade tip. bgnmelt Begin melt endmelt End melt poweronf N/A Force power on. (not yet implemented in ProffieOS) font font Played when you switch to this preset. N/A ccbegin Played when entering color change mode. N/A ccend Played when exiting color change mode N/A ccchange Played when changing color in "stepped" color change mode preon preon Played before the blade turns on pstoff Played after retraction when the blade turns off	drag	drag	Sound for dragging the tip of the saber blade.
Begin lightning block.	bgndrag	bgndrag	Begin drag
bgn1b Begin lightning block. end1b End lightning block. me1t Simulate stabbing and melting an object with blade tip. bgnme1t Begin melt endme1t End melt poweronf N/A Force power on. (not yet implemented in ProffieOS) font font Played when you switch to this preset. N/A ccbegin Played when entering color change mode. N/A ccend Played when exiting color change mode N/A ccchange Played when changing color in "stepped" color change mode preon preon Played before the blade turns on pstoff Played after retraction when the blade turns off	enddrag	enddrag	End drag
end1b End lightning block. me1t Simulate stabbing and melting an object with blade tip. bgnme1t Begin melt endme1t End melt poweronf N/A Force power on. (not yet implemented in ProffieOS) font font Played when you switch to this preset. N/A ccbegin Played when entering color change mode. N/A ccend Played when exiting color change mode N/A ccchange Played when changing color in "stepped" color change mode preon preon Played before the blade turns on pstoff pstoff Played after retraction when the blade turns off		1b	Force lightning block.
melt Simulate stabbing and melting an object with blade tip. bgnmelt Begin melt endmelt End melt poweronf N/A Force power on. (not yet implemented in ProffieOS) font font Played when you switch to this preset. N/A ccbegin Played when entering color change mode. N/A ccend Played when exiting color change mode N/A ccchange Played when changing color in "stepped" color change mode preon preon Played before the blade turns on pstoff pstoff Played after retraction when the blade turns off		bgnlb	Begin lightning block.
bgnmelt Begin melt endmelt End melt poweronf N/A Force power on. (not yet implemented in ProffieOS) font font Played when you switch to this preset. N/A ccbegin Played when entering color change mode. N/A ccend Played when exiting color change mode N/A ccchange Played when changing color in "stepped" color change mode preon preon Played before the blade turns on pstoff pstoff Played after retraction when the blade turns off		endlb	End lightning block.
endmelt End melt poweronf N/A Force power on. (not yet implemented in ProffieOS) font font Played when you switch to this preset. N/A ccbegin Played when entering color change mode. N/A ccend Played when exiting color change mode N/A ccchange Played when changing color in "stepped" color change mode preon preon Played before the blade turns on pstoff pstoff Played after retraction when the blade turns off		melt	Simulate stabbing and melting an object with blade tip.
poweronf N/A Force power on. (not yet implemented in ProffieOS) font font Played when you switch to this preset. N/A ccbegin Played when entering color change mode. N/A ccend Played when exiting color change mode N/A ccchange Played when changing color in "stepped" color change mode preon preon Played before the blade turns on pstoff pstoff Played after retraction when the blade turns off		bgnmelt	Begin melt
font font Played when you switch to this preset. N/A ccbegin Played when entering color change mode. N/A ccend Played when exiting color change mode N/A ccchange Played when changing color in "stepped" color change mode preon preon Played before the blade turns on pstoff pstoff Played after retraction when the blade turns off		endmelt	End melt
N/A ccend Played when entering color change mode. N/A ccend Played when exiting color change mode N/A ccchange Played when changing color in "stepped" color change mode preon preon Played before the blade turns on pstoff pstoff Played after retraction when the blade turns off	poweronf	N/A	Force power on. (not yet implemented in ProffieOS)
N/A ccend Played when exiting color change mode N/A ccchange Played when changing color in "stepped" color change mode preon preon Played before the blade turns on pstoff pstoff Played after retraction when the blade turns off	font	font	Played when you switch to this preset.
Played when changing color in "stepped" color change mode preon preon Played before the blade turns on pstoff pstoff Played after retraction when the blade turns off	N/A	ccbegin	Played when entering color change mode.
preon preon Played before the blade turns on pstoff pstoff Played after retraction when the blade turns off	N/A	ccend	Played when exiting color change mode
pstoff pstoff Played after retraction when the blade turns off	N/A	ccchange	
	preon	preon	Played before the blade turns on
altchng Played when the alt is changed. (OS7+)	pstoff	pstoff	Played after retraction when the blade turns off
	altchng	altchng	Played when the alt is changed. (OS7+)

Monophonic Filename	Polyphonic Filename	Effect
spin	spin	Spin sound (Experimental, needs #define ENABLE_SPINS)
fastout	fastout	Played instead of "out" when using fast on (OS8+)
quote	quote	Plays a quote (OS8+)
chhum	chhum	Like altchng , but played before the new hum with no gap. (OS8+)
mclick	mclick	Short menu clicked played when going between menu entries (OS8+)
idle	idle	Played when not on (OS8+, ENABLE_IDLE_SOUND)

Thermal Detonator Props

- >> bgnarm when the td is arming
- armhum when the td is armed (looped)
- >> endarm when the td is disarmed
- >> boom when the td blows up

Blaster Props

- >> bgnauto
- >> auto
- >> endauto
- >> blast
- >> clipin
- >> clipout
- >> empty
- >> fire
- >> full
- >> jam
- >> unjam
- >> mode
- >> plioff
- >> plion
- >> range
- >> stun
- >> reload

As of OS6:

- >> mdkill
- >> mdstun
- >> mdauto

SmoothSwing Configuration

When one or more set of swing1 / swingh files are present, ProffieOS will activate the SmoothSwing algorithms. To decide if it should use V1 or V2, it will read a file called "smoothsw.ini". More information on how to configure this file can be found on the smoothswing page.

SmoothSwing V1

Demo Video (Thexter's description) Many thanks to Thexter for his excellent work on this algorithm. Smoothswing V1 doesn't actually use any of the variables from the configuration file. The swingl and swingh files are played in a loop. The software will then place a rotating plane through the blade of your saber, and if the saber swings in one direction across the plane, we'll play more of swingl and less of the background hum. If we swing in the other direction, we'll play more of swingh and less of the hum. The fade will never blend swingl and swingh directly, it will essentially cross-fade between the regular hum and one of swingl/swingh based on direction and strength of the swing.

SmoothSwing V2

Demo Video (Thexter's description) Smoothswing V2 has some similarties to V1, but is much better at producing natural swing- and spin-like sounds, and also produces more variety than the V1 algorithm. To do this, the swinglNN.wav and swinghNN.wav files are paired up. Whenever a swing is not going on (swing speed < SwingStrengthThreshold) a new pair if selected randomly. As we start swinging, we keep track of how many degrees the saber has swung so far, and at a randomly selected threshold, we start a cross-fade to go from swingl to swingh. The transition lasts for Transition1Degrees, and if the swing continues, we will eventually cross-fade back from swingh to swingl 180 degrees after the first threshold. The second transition is generally wider and is controlled by Transition2Degrees. The combined swing sound is then cross-faded with the regular hum based on the swing strength.