PSCAD import tool for IEEE/CIGRE DLLs



ABOUT INTEROPERA:

The InterOPERA project will define technical frameworks and standards for electricity transmission and accelerate the integration of renewable energy. Ensuring that HVDC systems, HVDC transmission systems or HVDC components from different suppliers can work together – making them "interoperable"- is a top priority to accelerate Europe's energy transition.



DISCLAIMER:

Co-funded by the European Union. Views and opinions expressed are however those of the author(s) only and do not necessarily reflect those of the European Union or CINEA. Neither the European Union nor the granting authority can be held responsible for them.

PROJECT DETAILS:

Duration: 1 January 2023 – 30 April 2027

Grant agreement: 101095874 — InterOPERA — HORIZON-CL5-2022-D3-01



PSCAD import tool for IEEE/CIGRE DLLs

01 JUNE 2023 **LAST UPDATE 21 JANUARY 2025**

AUTHORS:

MARTIN César, Software developer, RTE DEHGHAN MARVASTI Farzad, Postdoctoral researcher, TU Delft

REVIEWERS:

DENNETIERE Sébastien, Power system expert, RTE BONNET Alexandra, Project coordinator, RTE

OTHER CONTRIBUTORS:

VERSION CONTROL

Version	Date	Created/modified by	Comments
1.0	27/03/2025	MARTIN César, DEHGHAN	First version
		MARVASTI Farzad	





Table of Contents

Background	5
PSCAD import tool of an IEEE/Cigre DLL	6
References	9





Background

Modeling for HVDC, FACTS, wind turbines, solar generators and other power system equipment that connect to the AC grid is an essential part for most electrical system studies. As many new power electronics equipment are being installed in the power systems, the need for a reference for control systems modeling and some guidelines to provide standard procedures have become a priority.

This IEEE/CIGRE DLL modeling is defined in the CIGRE Technical Brochure 958 ("Guidelines for Use of Real-Code in EMT Models for HVDC, FACTS and Inverter based generators in Power Systems Analysis"). It expands upon earlier work from IEC-61400-27-1.

It allows controls and protection models (usually the identical code developed by a manufacturer and running in field hardware – i.e., "realcode") to be used in any power system simulation tool, including Electro-Magnetic Transients (EMT) and Transient Stability (TS) RMS simulation programs.

RTE and TU Delft have worked together, within the InterOPERA project to develop an IEEE/CIGRE DLL import tool for PSCAD.





PSCAD import tool of an IEEE/CIGRE DLL

This tool, created in Python and then compiled in .exe, is presented in the form of a simple graphical interface. Two versions of the executable are available (32 and 64-bit) depending on the type of architecture of the DLL to be imported. The import tool's GUI is shown in Figure 1.

FIGURE 1 PSCAD Import Tool (Developed by RTE & TU Delft) PSCAD Import Tool (IEEE/Cigre DLL format) RTE/TUD v2.5 DLL File Path Browse Create New Project Destination folder Browse Select an open PSCAD project Use Available Project Generate PSCAD Model

This tool works only with PSCAD version 5 and Intel Fortran compilers. This may not work for old versions (2012 or less) of Intel Fortran compilers.

The user may start by selecting an IEEE/CIGRE DLL using the first browse button to convert it into a PSCAD DLL-based component. The integration process consists of:

- Creating and placing the component on the main canvas of a PSCAD project.
- Generating a Fortran interface file that facilitates communication between the component and the DLL.
- Adding the interface link to the project's resources.
- Copying both the Fortran interface file and the DLL to the project's folder.

The user has two options for integrating the component.

- 2- Create New Project: a new PSCAD project will be created inside the "Destination folder" specified using the second browse button. After clicking the "Generate PSCAD Model", the component will be created inside the new project.
- 2- Use Available Project: The import tool detects a running PSCAD instance and lists all the loaded projects. After selecting one of the projects and clicking the "Generate PSCAD Model", the component will be created inside the selected project.

The import tool provides two more buttons on its GUI.

- Refresh projects: For refreshing the list of available projects in case new projects are loaded by
- Open project's location: To navigate the user to the selected project's location, where the DLL and Fortran interface link are present.


As an example, Figure 2 (a) shows the representation of the SCRX9 component generated by the IEEE/CIGRE DLL import tool in PSCAD software environment. By double-clicking on the component block, various settings can be edited as shown in Figure (b)-(d).







FIGURE 2

Example of an IEEE/CIGRE DLL component in PSCAD. a) Imported component, b) Configuration tab, c) Model Parameters tab and d) Initial Conditions tab














More explanations for each tab can be found as follows:

Configuration tab

In the first "Configuration" tab, the path to the DLL is specified. While the path is set automatically, the user can modify it by specifying a relative or absolute path.

It is also possible to enable or disable the input linear interpolation feature, which is useful only if the time step of the DLL model is different from that of the PSCAD simulation.

Model Parameters tab

The parameters of the model are shown and can be edited from this tab. Data labels can be used for parameters.

Initial Conditions tab

There are additional options available via this tab. For example, TRelease allows an IEEE/CIGRE DLL model to be held at initial conditions until a certain release time. The other parameters are used to assign initial values to the outputs.

After setting the parameters, the PSCAD simulation can be run.

Notes:

- The snapshot feature will work properly if the IEEE/CIGRE DLL model has been designed to be compatible with it.
- The time-step of the PSCAD circuit can be set to a different value than the time-step of the DLL model. The user is free to decide whether or not to use the input interpolation in the Configuration tab.
- PSCAD multiple runs are allowed.
- Multiple instantiations of DLL models in PSCAD are supported by the solution.
- If the DLL is in 32-bit (respectively 64-bit), you must select a 32-bit (respectively 64-bit) Intel Fortran compiler in the PSCAD options.





References

CIGRE TB958 JWG CIGRE B4.82/IEEE, «Guidelines for use of real-code in EMT models for HVDC, FACTs and inverter based generators in power systems analysis,» 2025.

