# **User manual**

(v.: 0.1 - 07/2022)

### ## Features:

- Training (fight) time count and interval count between trainings.
- - Countdown time.
- - Panel brightness adjustment.
- - Allows user to see date and time while counting (makes automatic return).
- - Automatically return when idle within the menu tree.
- - Audio visual signaling, beep and voice (mp3 files)
- - Independent volume control for beep and voice (player has its volume control).
- - Playing music on USB flash drive and SD card (player also has FM and Bluetooth).
- - Panel operation is independent of mp3 player (shares audio output).
- - Displayed temperature range from 2 to 150 °C (Lower temperature needs different hardware).

Display modes: "Timer count" or "Time Date (and tempetature)"

## Menu access:

- When displaying the Round or Interval count, it allows accessing the counts and notifications settings menu.
- For panel brightness adjustment and time adjustment, the panel needs to be displaying the time and temperature.
- To adjust the date, the panel must be displaying the date.

### Menu items:

- Round count

Rd:12

34:56

Rd - Round count

12 - Count

34 - Minutes

56 - Seconds

- Interval count

In:12

34:56

In - Interval count

12 - Count

34 - Minutes

56 - Seconds

- Menu reset count

Reset Cnt?

Resets round and interval counts

- Menu set count

Set Cnt?

Adjusts the displayed count

# LED Panel P10 Fight Timer DMD2 HUB12 - User manual

- Menu set round Set Rd?
Sets the initial value of interval
- Menu set round Set Rd?
Sets the initial value of interval
<ul> <li>Menu round notifications</li> <li>Nt Rd</li> <li>Off</li> </ul>
Select or disable notification type for round (Off/Beep/Voice/Beep+Voice)
<ul> <li>Menu interval notifications</li> <li>Nt In Off</li> </ul>
Select or disable notification type for interval (Off/Beep/Voice/Beep+Voice
- Menu beep volume Volum B: 5
Select volume for beep
- Menu voice volume  Volum  V: 5
Select volume for voice
- Menu time adjust b:5 12:34
b - display brightness (min.: 5, max.: 100) 12 - Hours 34 - Minutes
- Menu date adjust  dd/mm  20yy
dd - Day mm - Month yy - Year

- HT6P20B remote control (must be 3 buttons)
  - Button 1: Menu / Next cell
  - Button 2: Select menu / Change value
  - Button 3: Exit menu / Switch between Timer or TimeDate

(Note: The order of buttons may vary by remote control manufacturer)