

## Verify USB driver availability

Step1: Access the device's using UART port.

Step2: Use the 'lsusb' command to view.

Step3: You can see that the USB has been recognized and the corresponding ID is **2c7c:0903**

```
#  
#  
# lsusb  
Bus 001 Device 001: ID 1d6b:0002 Linux 5.4.289 ehci_hcd EHCI Host Controller  
Bus 001 Device 002: ID 2c7c:0903 Quectel EC801E-CN  
#
```

Step4: ID **2c7c:0903** is used to map the USB and 4G modules through software

```
#define QUECTEL_PRODUCT_EM12          0x0512  
#define QUECTEL_PRODUCT_RM500Q       0x0800  
#define QUECTEL_PRODUCT_RM520N       0x0801  
#define QUECTEL_PRODUCT_EC200U        0x0901  
#define QUECTEL_PRODUCT_EC801E_CN     0x0903  
#define QUECTEL_PRODUCT_EG912Y        0x6001  
#define QUECTEL_PRODUCT_EC200S_CN     0x6002  
#define QUECTEL_PRODUCT_EC200A        0x6005  
{ USB_DEVICE_AND_INTERFACE_INFO(QUECTEL_VENDOR_ID, QUECTEL_PRODUCT_EC200A, 0xff, 0, 0) },  
{ USB_DEVICE_AND_INTERFACE_INFO(QUECTEL_VENDOR_ID, QUECTEL_PRODUCT_EC200U, 0xff, 0, 0) },  
{ USB_DEVICE_AND_INTERFACE_INFO(QUECTEL_VENDOR_ID, QUECTEL_PRODUCT_EC801E_CN, 0xff, 0, 0) },  
{ USB_DEVICE_AND_INTERFACE_INFO(QUECTEL_VENDOR_ID, QUECTEL_PRODUCT_EC200S_CN, 0xff, 0, 0) },  
{ USB_DEVICE_AND_INTERFACE_INFO(QUECTEL_VENDOR_ID, QUECTEL_PRODUCT_EC200T, 0xff, 0, 0) },  
{ USB_DEVICE_AND_INTERFACE_INFO(QUECTEL_VENDOR_ID, QUECTEL_PRODUCT_EG912Y, 0xff, 0, 0) },
```