Method of Handling Traffic: Crew Instructions

Project Information

- **Speed limit:** 35 mph
- **Road type:** Urban (low-speed)
- **Closure type:** Lane Closure Near Intersection · Divided Highway
- **Work zone length:** 500 ft
- **Jurisdiction:** Not set
- **Generated:** 2026-10-12

Required Equipment

- 22× Construction/Warning Sign (see sign list below)
  - 2× G20-1 ROAD CONSTRUCTION (NEXT 500 FT)
  - 2× G20-2 END ROAD WORK
  - 2× G20-5P CONSTRUCTION ZONE plaque
  - 4× R2-10 BEGIN DOUBLE FINES ZONE
  - 4× R2-11 END DOUBLE FINES ZONE
  - 4× W20-1 ROAD WORK AHEAD
  - 2× W20-5R RIGHT LANE CLOSED AHEAD
  - 2× W4-2R RIGHT LANE ENDS
- 8× Channelizing Drum (36-inch)
- 11× Traffic Cone (28-inch)
- 1× Arrow Board

Sign Placement Schedule

Sign Code	Description	Distance from Taper
W20-1	ROAD WORK AHEAD	300 ft upstream
W20-5R	RIGHT LANE CLOSED AHEAD	200 ft upstream
W4-2R	RIGHT LANE ENDS	100 ft upstream
G20-5P	CONSTRUCTION ZONE plaque	Within work zone
G20-2	END ROAD WORK	Downstream of work zone
R2-10	BEGIN DOUBLE FINES ZONE	250 ft upstream (1/2 C inside the outermost sign, per Case 18)
G20-1	ROAD CONSTRUCTION (NEXT 500 FT)	100 ft upstream of the work zone (within the buffer space)
R2-11	END DOUBLE FINES ZONE	250 ft downstream of the work zone

Cross-Street Signs (per approach leg; stations measured from the intersection curb line)

- **cross_a approach** (25 mph, Urban (low-speed); signalized: signal operation review required before work begins, MUTCD §6N.12 / Part 4): W20-1 at 200 ft (twice the key distance A) and R2-10 at 100 ft (at A) on the approach side. The S-630-1 Sheet 10 advance-signing key gives A = 100 ft for this leg's speed and road type. R2-11 at 100 ft

on the departure side.

- **cross_b approach** (25 mph, Urban (low-speed); signalized: signal operation review required before work begins, MUTCD §6N.12 / Part 4): W20-1 at 200 ft (twice the key distance A) and R2-10 at 100 ft (at A) on the approach side. The S-630-1 Sheet 10 advance-signing key gives A = 100 ft for this leg's speed and road type. R2-11 at 100 ft on the departure side.

Setup Procedure

Important: Set up from downstream to upstream (against traffic flow). This ensures you are always working behind protection.

1. Position arrow board at the upstream start of the merging taper (station 995 ft), centered in the closed right lane. Set to LEFT ARROW mode (traffic merges left, out of the closed lane). Activate flashing.
2. Place the END ROAD WORK sign (G20-2) at the downstream termination (station -150 ft), right side of road 28 ft from the left edge of the roadway. Place matching sign on the left curb, 4 ft left of the left edge of the roadway.
3. Place 2 traffic cones in the downstream reopening taper, between station -50 ft (lane edge) and station 0 (lane line) at 25 ft spacing. This taper returns traffic into the reopened right lane past the work zone (MUTCD §6B.08 downstream taper). Then place 9 traffic cones along the closed-lane line through the work zone at 62 ft spacing, starting at station 0 (downstream end of work zone) and working upstream to station 500 ft. Offset: 12 ft from centerline.
4. Place G20-5P WORK ZONE plaque(s) within the work zone at approximately 500 ft intervals.
5. Place 8 channelizing drums in the merging taper, starting at station 750 ft and working upstream to station 995 ft. Space drums at 35 ft intervals. Drums transition from the lane edge (24 ft) to the lane line (12 ft), closing the right lane.
6. Place advance warning signs upstream of the taper: Place matching signs on the left curb at each location, 4 ft left of the left edge of the roadway (CDOT S-630-1 Sheet 2 General Note 8: both sides on a divided highway).
   - W4-2R at 100 ft upstream of taper start (station 1,095 ft), right side.
   - W20-5R at 200 ft upstream of taper start (station 1,195 ft), right side.
   - W20-1 at 300 ft upstream of taper start (station 1,295 ft), right side.
7. Place the mainline regulatory and bookend signs, on both sides: the right side 28 ft from the left edge of the roadway, the left curb 4 ft left of it: R2-10 BEGIN DOUBLE FINES ZONE at station 1,245 ft (half the C spacing inside the outermost W20-1, per S-630-1 Case 18); G20-1 at station 600 ft; R2-11 END DOUBLE FINES ZONE at station -250 ft (downstream, past the lane reopening).
8. Place the cross-street advance sets, one set per approach leg. Stations for each set are measured along that leg FROM the intersection curb line, increasing away from the intersection:
   - **cross_a approach** (25 mph, Urban (low-speed)): W20-1 ROAD WORK AHEAD at 200 ft and R2-10 BEGIN DOUBLE FINES ZONE at 100 ft, both on the approach side 16 ft from that road's centerline. The W20-1 sits at twice the key distance A, the R2-10 at A, where the S-630-1 Sheet 10 advance-signing key gives A = 100 ft for this leg's own speed and road type. R2-11 END DOUBLE FINES ZONE at 100 ft on the departure side (facing traffic leaving the intersection). This approach is signalized: signal operation must be reviewed before work begins (MUTCD §6N.12; Part 4). See the audit trail.
   - **cross_b approach** (25 mph, Urban (low-speed)): W20-1 ROAD WORK AHEAD at 200 ft and R2-10 BEGIN DOUBLE FINES ZONE at 100 ft, both on the approach side 16 ft from that road's centerline. The W20-1 sits at twice the key distance A, the R2-10 at A, where the S-630-1 Sheet 10 advance-signing key gives A = 100 ft for this leg's own speed and road type. R2-11 END DOUBLE FINES ZONE at 100 ft on the departure side (facing traffic leaving the intersection). This approach is signalized: signal operation must be reviewed before work begins (MUTCD §6N.12; Part 4). See the audit trail.

Sequencing note: The MUTCD does not prescribe the order of mainline versus cross-street setup. Whether the cross-street sets go up before, after, or interleaved with the mainline sequence is the Traffic Control Supervisor's

determination for this site.

Takedown Procedure

Important: Remove from upstream to downstream (with traffic flow). Remove advance warning signs first, work zone devices last.

1. Remove advance warning signs: W20-1 first, then W20-5R, then W4-2R.
2. Remove taper drums from upstream to downstream.
3. Deactivate and remove arrow board.
4. Remove work zone cones from upstream to downstream.
5. Remove G20-5P plaques.
6. Remove G20-2 END ROAD WORK sign(s).
7. Remove the mainline R2-10 / R2-11 DOUBLE FINES ZONE pair and the G20-1 sign.
8. Remove each cross-street advance set (W20-1, R2-10, R2-11 per approach). The order of mainline versus cross-street takedown is the Traffic Control Supervisor's determination.

Safety Notes

- All personnel in the work zone must wear ANSI Class 2 (daytime) or Class 3 (nighttime) high-visibility apparel.
- Divided highway: all warning and regulatory signs are posted on BOTH sides of this carriageway, the median side included, per CDOT S-630-1 Sheet 2 General Note 8. Offsets are measured from the left (median) edge of the roadway.
- Median opening: the plates don't draw the cross street's median opening. Confirm the signing at the median opening with the Engineer before setup.
- Closed lane: this plan draws the closure on the RIGHTMOST lane. That is a modeling assumption, not an MUTCD rule; the work location dictates the lane. If the work occupies a different lane, this plan does not apply as drawn.
- Maintain 250 ft longitudinal buffer space between the taper and the work area at all times.
- Maximum speed reduction per sign installation: 15 mph (CDOT S-630-1 Sheet 2 General Note 3).
- This plan was generated by MHT Tool. A certified Traffic Control Supervisor (TCS) must review, approve, and sign before field implementation.
- Reference: CDOT S-630-1, MUTCD 11th Edition Part 6, Colorado Supplement (effective January 18, 2026).

Pedestrian and Bicycle Accommodation

- No pedestrian or bicycle facility is flagged as affected by this closure. If a sidewalk, crosswalk, shared-use path, or bike facility exists within the work zone in the field, stop and have the TCS update the plan before setup.
- The TCS verifies pedestrian and bicycle accommodation on site; where a facility is maintained, it must remain accessible and detectable per MUTCD standards.

Emergency Access

- 1 of 2 same-direction travel lane remains open (12 ft of traversable width) past the closed lane.
- The Traffic Control Supervisor completes and confirms the emergency access plan for this site and coordinates notification of police, fire, and emergency medical responder agencies prior to work (TCS duties per CDOT Standard Specifications 630.11).
- An emergency access plan is a required minimum element of the approved Method of Handling Traffic (CDOT 630.10(a)); this section is draft input for it, not the approved plan.