

Method of Handling Traffic — Crew Instructions

Project Information

- **Speed limit:** 35 mph
- **Road type:** Urban (low-speed)
- **Closure type:** Shoulder Closure — 4-Lane Undivided
- **Work zone length:** 800 ft
- **Jurisdiction:** CDOT
- **Generated:** 2026-08-22

Required Equipment

- 8× Construction/Warning Sign (see sign list below)
 - 1× G20-1 ROAD CONSTRUCTION (NEXT 800 FT)
 - 1× G20-2 END ROAD WORK
 - 1× G20-5P CONSTRUCTION ZONE plaque
 - 2× R9-9 SIDEWALK CLOSED
 - 1× W20-1 ROAD WORK AHEAD
 - 1× W20-2 ROAD WORK 200 FT
 - 1× W21-5aR RIGHT SHOULDER CLOSED AHEAD
- 4× Channelizing Drum (36-inch)
- 15× Traffic Cone (28-inch)
- 4× Type III Barricade
- 1× Arrow Board

Sign Placement Schedule

Sign Code	Description	Distance from Taper
W20-1	ROAD WORK AHEAD	300 ft upstream
W20-2	ROAD WORK 200 FT	200 ft upstream
W21-5aR	RIGHT SHOULDER CLOSED AHEAD	100 ft upstream
G20-5P	CONSTRUCTION ZONE plaque	Within work zone
G20-2	END ROAD WORK	Downstream of work zone

Setup Procedure

Important: Set up from downstream to upstream (against traffic flow). This ensures you are always working behind protection.

1. Position arrow board at the upstream start of the shoulder taper (station 1,104 ft). Set to RIGHT ARROW mode (for right shoulder closure). Activate flashing.
2. Place the END ROAD WORK sign (G20-2) at the downstream termination (station -150 ft), right side of road 28 ft from centerline.

3. Place 2 traffic cones in the downstream taper, between station -50 ft (shoulder edge) and station 0 (lane edge) at 25 ft spacing — this taper returns traffic from the lane edge back to the shoulder edge past the work zone (MUTCD §6B.08 downstream taper). Then place 13 traffic cones along the right lane edge at 67 ft spacing, starting at station 0 (downstream end of work zone) and working upstream to station 800 ft. Offset: 24 ft from centerline.
4. Place G20-5P WORK ZONE plaque(s) within the work zone at approximately 800 ft intervals.
5. Place 4 channelizing drums in the shoulder taper, starting at station 1,050 ft and working upstream to station 1,104 ft. Space drums at 18 ft intervals. Drums transition from the lane edge (24 ft) to the shoulder edge (32 ft).
6. Place advance warning signs upstream of the taper:
 - W21-5aR at 100 ft upstream of taper start (station 1,204 ft), right side.
 - W20-2 at 200 ft upstream of taper start (station 1,304 ft), right side.
 - W20-1 at 300 ft upstream of taper start (station 1,404 ft), right side.

Takedown Procedure

Important: Remove from upstream to downstream (with traffic flow). Remove advance warning signs first, work zone devices last.

1. Remove advance warning signs: W20-1 first, then W20-2, then W21-5aR.
2. Remove taper drums from upstream to downstream.
3. Deactivate and remove arrow board.
4. Remove work zone cones from upstream to downstream.
5. Remove G20-5P plaques.
6. Remove G20-2 END ROAD WORK sign(s).

Safety Notes

- All personnel in the work zone must wear ANSI Class 2 (daytime) or Class 3 (nighttime) high-visibility apparel.
- Maintain 250 ft longitudinal buffer space between the taper and the work area at all times.
- Maximum speed reduction per sign installation: 15 mph (CDOT S-630-1 Sheet 2 General Note 3).
- This plan was generated by MHT Tool. A certified Traffic Control Supervisor (TCS) must review, approve, and sign before field implementation.
- Reference: CDOT S-630-1, MUTCD 11th Edition Part 6, Colorado Supplement (effective January 18, 2026).

Pedestrian and Bicycle Accommodation

- A pedestrian facility is affected by this closure. 2 R9-9 SIDEWALK CLOSED signs are placed at the closure (MUTCD §6G.10 — the plain R9-9 legend; no alternate-side assertion, which belongs to R9-10, and no detour-routing signs, which require sidewalk geometry this plan does not carry). Sidewalk closure points are barricaded (MUTCD §6C.02). Pedestrians must not be diverted into an open travel lane.
- The TCS verifies pedestrian and bicycle accommodation on site; where a facility is maintained, it must remain accessible and detectable per MUTCD standards.

Emergency Access

- All travel lanes remain open — the closure occupies the shoulder only. Emergency vehicles pass through the work zone in the open lanes.

- The Traffic Control Supervisor completes and confirms the emergency access plan for this site and coordinates notification of police, fire, and emergency medical responder agencies prior to work (TCS duties per CDOT Standard Specifications 630.11).
- An emergency access plan is a required minimum element of the approved Method of Handling Traffic (CDOT 630.10(a)); this section is draft input for it, not the approved plan.

Site-Specific Notes

- **pedestrian_facility** — Added 4 Type III barricades (sidewalk closure points) and 2 R9-9 SIDEWALK CLOSED signs at the upstream and downstream ends of the work zone. (*MUTCD §6C.02 — pedestrian considerations in work zones*)