Method of Handling Traffic: Crew Instructions

Project Information

- **Speed limit:** 25 mph
- **Road type:** Urban (low-speed)
- **Closure type:** Flagger Alternating Traffic · 2-Lane Undivided
- **Work zone length:** 50 ft
- **Jurisdiction:** Denver (guessed from the pin, not confirmed)
- **Generated:** 2026-10-24

Required Equipment

- 15× Construction/Warning Sign (see sign list below)
  - 2× G20-1 ROAD CONSTRUCTION (NEXT 50 FT)
  - 2× G20-2 END ROAD WORK
  - 1× G20-5P WORK ZONE plaque
  - 2× R9-9 SIDEWALK CLOSED
  - 2× W20-1 ROAD WORK AHEAD
  - 2× W20-4 ONE LANE ROAD AHEAD
  - 2× W20-7 FLAGGER AHEAD
  - 2× W3-4 BE PREPARED TO STOP
- 6× Channelizing Drum (36-inch)
- 10× Traffic Cone (28-inch)
- 2× Type III Barricade
- 2× Flagger Station
- 1× Arrow Board (caution mode only)

Sign Placement Schedule

Sign Code	Description	Distance from Taper
W20-1	ROAD WORK AHEAD	500 ft upstream
W20-4	ONE LANE ROAD AHEAD	400 ft upstream
W3-4	BE PREPARED TO STOP	300 ft upstream
W20-7	FLAGGER AHEAD	200 ft upstream
G20-5P	WORK ZONE plaque	Within work zone
G20-2	END ROAD WORK	Downstream of work zone

Setup Procedure

Important: Set up from downstream to upstream (against traffic flow). This ensures you are always working behind protection.

1. Identify both flagger station positions (do not staff yet; stations are staffed after all devices are in place, step 7): Station #1 at station 405 ft (approach side, 100 ft upstream of the taper start, closed-lane side); Station #2 at station

-300 ft (opposing approach, 300 ft past the work-area end per CDOT S-630-1 Case 17).

2. Place the END ROAD WORK sign (G20-2) at the downstream termination (station -150 ft), right side of road 16 ft from centerline. Place the opposing-direction G20-2 past the upstream end of the work zone (left side).
3. Place 4 traffic cones in the downstream taper, between station -50 ft (right lane edge) and station 0 (centerline) at 12 ft spacing. This taper returns right-direction traffic from the centerline back to the right lane edge past the work area (MUTCD §6B.08 ¶12; S-630-1 Case 17 annotates the run 100' MAX.). Then place 3 traffic cones along the centerline boundary between the open opposing lane and the closed work lane at 25 ft spacing, starting at station 0 (downstream end of work zone) and working upstream to station 50 ft. Then continue the line through the buffer space: 3 more traffic cones at 39 ft spacing, from station 50 ft up to the taper (station 205 ft), at the same offset. Keep the buffer itself clear of work and equipment (CDOT S-630-1 Sheet 2 General Note 18b: no more than twice the speed limit apart along the buffer space).
4. Place G20-5P WORK ZONE plaque(s) within the work zone at approximately 50 ft intervals.
5. Place 6 channelizing drums in the one-lane two-way taper, starting at station 205 ft and working upstream to station 305 ft. Space drums at 20 ft intervals (approximately 20 ft per MUTCD §6B.08. This taper stages stopped traffic behind the flagger; it must be short enough to not be mistaken for a transition). Drums transition from the right lane edge (12 ft) to the centerline (0 ft).
6. Place advance warning signs upstream of the taper: Repeat the series for the opposing approach (left side, negative stations; S-630-1 Case 17: "SIGN SEQUENCE IS THE SAME FOR OPPOSITE DIRECTION"). Arrow board (DOTI PT-116.1 requires one): Caution mode only, never an arrow or chevron: one lane is closed on a two-lane, two-way road (MUTCD 11th Ed. §6L.06 ¶18, p. 833; CDOT S-630-1 Sheet 2 General Note 26). Set it to flashing caution or alternating diamond and activate it. The drawing doesn't place it, because MUTCD Fig. 6P-10 and S-630-1 Case 17 show no arrow board for a flagger closure. The Traffic Control Supervisor picks its position.
   - W20-7 at 200 ft upstream of taper start (station 505 ft), right side.
   - W3-4 at 300 ft upstream of taper start (station 605 ft), right side.
   - W20-4 at 400 ft upstream of taper start (station 705 ft), right side.
   - W20-1 at 500 ft upstream of taper start (station 805 ft), right side.
7. Staff both flagger stations (STOP/SLOW paddles, high-visibility apparel, radio or agreed hand-signal communication between stations). Verify each station is visible to approaching traffic from the full advance-warning distance and has an identified escape path. Begin the alternating one-way operation.

Takedown Procedure

Important: The one-lane operation ends before its warning signs come down. Flaggers control traffic until the roadway is fully restored to two-way operation.

1. Complete work and clear all personnel and equipment from the work area.
2. Under continued flagger control, remove the work-zone cones and the taper drums (restoring the closed lane).
3. Cease the alternating one-way operation and release both flagger stations.
4. Remove advance warning signs on both approaches: W20-1 first, then W20-4, then W3-4, then W20-7.
5. Remove G20-5P plaques and the G20-1/G20-2 BEGIN/END ROAD WORK signs.
6. Deactivate and remove the arrow board.

Safety Notes

- All personnel in the work zone must wear ANSI Class 2 (daytime) or Class 3 (nighttime) high-visibility apparel.
- Maintain 155 ft longitudinal buffer space between the taper and the work area at all times.
- Maximum speed reduction per sign installation: 15 mph (CDOT S-630-1 Sheet 2 General Note 3).

- This plan was generated by MHT Tool. A certified Traffic Control Supervisor (TCS) must review, approve, and sign before field implementation.
- Reference: CDOT S-630-1, MUTCD 11th Edition Part 6, Colorado Supplement (effective January 18, 2026).

Pedestrian and Bicycle Accommodation

- A pedestrian facility is affected by this closure. 2 R9-9 SIDEWALK CLOSED signs are placed at the closure (MUTCD §6G.10: the plain R9-9 legend; no alternate-side assertion, which belongs to R9-10, and no detour-routing signs, which require sidewalk geometry this plan does not carry). Sidewalk closure points are barricaded (MUTCD §6C.02). Pedestrians must not be diverted into an open travel lane.
- **Denver TCP sheet requirements**: The submitted TCP must depict sidewalks, pedestrian accessible routes, and bike-lane assignments as existing conditions, plus the proposed pedestrian accessible route, bike facilities, and a sidewalk/bike closure detail. That existing-conditions inventory is site-survey content this generated draft doesn't carry. The TCS supplies it on the submitted TCP.
- The TCS verifies pedestrian and bicycle accommodation on site; where a facility is maintained, it must remain accessible and detectable per MUTCD standards.

Emergency Access

- The roadway is reduced to one alternating lane; access through the closure is controlled at the flagger stations.
- The Traffic Control Supervisor completes and confirms the emergency access plan for this site and coordinates notification of police, fire, and emergency medical responder agencies prior to work (TCS duties per CDOT Standard Specifications 630.11).
- An emergency access plan is a required minimum element of the approved Method of Handling Traffic (CDOT 630.10(a)); this section is draft input for it, not the approved plan.

Site-Specific Notes

- **adjacent_intersection**: No devices added: the cross-street approach layout isn't generated. See the pending-verification disclosure. *(MUTCD §6N.12 p. 848: Work within the Traveled Way at an Intersection (11th Ed.))*
- **pedestrian_facility**: Added 2 Type III barricades (sidewalk closure points) and 2 R9-9 SIDEWALK CLOSED signs at the upstream and downstream ends of the work zone. *(MUTCD §6C.02: pedestrian considerations in work zones)*