Method of Handling Traffic: Crew Instructions

Project Information

- **Speed limit:** 55 mph
- **Road type:** Urban (high-speed)
- **Closure type:** Lane Closure Near Intersection · Undivided
- **Work zone length:** 50 ft
- **Jurisdiction:** Not set
- **Generated:** 2026-10-24

Required Equipment

- 13× Construction/Warning Sign (see sign list below)
  - 1× G20-1 ROAD CONSTRUCTION (NEXT 50 FT)
  - 1× G20-2 END ROAD WORK
  - 1× G20-5P WORK ZONE plaque
  - 2× M4-9a BIKE DETOUR
  - 2× R2-10 BEGIN DOUBLE FINES ZONE
  - 2× R2-11 END DOUBLE FINES ZONE
  - 2× W20-1 ROAD WORK AHEAD
  - 1× W20-5R RIGHT LANE CLOSED AHEAD
  - 1× W4-2R RIGHT LANE ENDS
- 13× Channelizing Drum (36-inch)
- 9× Traffic Cone (36-inch)
- 1× Arrow Board

Sign Placement Schedule

Sign Code	Description	Distance from Taper
W20-1	ROAD WORK AHEAD	1,050 ft upstream
W20-5R	RIGHT LANE CLOSED AHEAD	700 ft upstream
W4-2R	RIGHT LANE ENDS	350 ft upstream
G20-5P	WORK ZONE plaque	Within work zone
G20-2	END ROAD WORK	Downstream of work zone
R2-10	BEGIN DOUBLE FINES ZONE	875 ft upstream (1/2 C inside the outermost sign, per Case 18)
G20-1	ROAD CONSTRUCTION (NEXT 50 FT)	100 ft upstream of the work zone (within the buffer space)
R2-11	END DOUBLE FINES ZONE	250 ft downstream of the work zone

Cross-Street Signs (per approach leg; stations measured from the intersection curb line)

- **cross_a approach** (45 mph, Urban (high-speed); signalized: signal operation review required before work begins, MUTCD §6N.12 / Part 4): W20-1 at 700 ft (twice the key distance A) and R2-10 at 350 ft (at A) on the approach

side. The S-630-1 Sheet 10 advance-signing key gives A = 350 ft for this leg's speed and road type. R2-11 at 100 ft on the departure side.

Setup Procedure

Important: Set up from downstream to upstream (against traffic flow). This ensures you are always working behind protection.

1. Position arrow board at the upstream start of the merging taper (station 1,205 ft), centered in the closed right lane. Set to LEFT ARROW mode (traffic merges left, out of the closed lane). Activate flashing.
2. Place the END ROAD WORK sign (G20-2) at the downstream termination (station -150 ft), right side of road 28 ft from centerline.
3. Place 2 traffic cones in the downstream reopening taper, between station -50 ft (lane edge) and station 0 (lane line) at 25 ft spacing. This taper returns traffic into the reopened right lane past the work zone (MUTCD §6B.08 downstream taper). Then place 3 traffic cones along the closed-lane line through the work zone at 25 ft spacing, starting at station 0 (downstream end of work zone) and working upstream to station 50 ft. Offset: 12 ft from centerline. Then continue the line through the buffer space: 4 more traffic cones at 99 ft spacing, from station 50 ft up to the taper (station 545 ft), at the same offset. Keep the buffer itself clear of work and equipment (CDOT S-630-1 Sheet 2 General Note 18b: no more than twice the speed limit apart along the buffer space).
4. Place G20-5P WORK ZONE plaque(s) within the work zone at approximately 50 ft intervals.
5. Place 13 channelizing drums in the merging taper, starting at station 545 ft and working upstream to station 1,205 ft. Space drums at 55 ft intervals. Drums transition from the lane edge (24 ft) to the lane line (12 ft), closing the right lane.
6. Place advance warning signs upstream of the taper:
   - W4-2R at 350 ft upstream of taper start (station 1,555 ft), right side.
   - W20-5R at 700 ft upstream of taper start (station 1,905 ft), right side.
   - W20-1 at 1,050 ft upstream of taper start (station 2,255 ft), right side.
7. Place the mainline regulatory and bookend signs, single side, 28 ft from centerline: R2-10 BEGIN DOUBLE FINES ZONE at station 2,080 ft (half the C spacing inside the outermost W20-1, per S-630-1 Case 18); G20-1 at station 150 ft; R2-11 END DOUBLE FINES ZONE at station -250 ft (downstream, past the lane reopening).
8. Place the cross-street advance sets, one set per approach leg. Stations for each set are measured along that leg FROM the intersection curb line, increasing away from the intersection:
   - **cross_a approach** (45 mph, Urban (high-speed)): W20-1 ROAD WORK AHEAD at 700 ft and R2-10 BEGIN DOUBLE FINES ZONE at 350 ft, both on the approach side 52 ft from that road's centerline. The W20-1 sits at twice the key distance A, the R2-10 at A, where the S-630-1 Sheet 10 advance-signing key gives A = 350 ft for this leg's own speed and road type. R2-11 END DOUBLE FINES ZONE at 100 ft on the departure side (facing traffic leaving the intersection). This approach is signalized: signal operation must be reviewed before work begins (MUTCD §6N.12; Part 4). See the audit trail.

Sequencing note: The MUTCD does not prescribe the order of mainline versus cross-street setup. Whether the cross-street sets go up before, after, or interleaved with the mainline sequence is the Traffic Control Supervisor's determination for this site.

Takedown Procedure

Important: Remove from upstream to downstream (with traffic flow). Remove advance warning signs first, work zone devices last.

1. Remove advance warning signs: W20-1 first, then W20-5R, then W4-2R.
2. Remove taper drums from upstream to downstream.

3. Deactivate and remove arrow board.
4. Remove work zone cones from upstream to downstream.
5. Remove G20-5P plaques.
6. Remove G20-2 END ROAD WORK sign(s).
7. Remove the mainline R2-10 / R2-11 DOUBLE FINES ZONE pair and the G20-1 sign.
8. Remove each cross-street advance set (W20-1, R2-10, R2-11 per approach). The order of mainline versus cross-street takedown is the Traffic Control Supervisor's determination.

Safety Notes

- All personnel in the work zone must wear ANSI Class 2 (daytime) or Class 3 (nighttime) high-visibility apparel.
- Closed lane: this plan draws the closure on the RIGHTMOST lane. That is a modeling assumption, not an MUTCD rule; the work location dictates the lane. If the work occupies a different lane, this plan does not apply as drawn.
- Maintain 495 ft longitudinal buffer space between the taper and the work area at all times.
- Maximum speed reduction per sign installation: 15 mph (CDOT S-630-1 Sheet 2 General Note 3).
- This plan was generated by MHT Tool. A certified Traffic Control Supervisor (TCS) must review, approve, and sign before field implementation.
- Reference: CDOT S-630-1, MUTCD 11th Edition Part 6, Colorado Supplement (effective January 18, 2026).

Pedestrian and Bicycle Accommodation

- A bicycle facility is affected by this closure. 2 M4-9a BIKE DETOUR signs are placed at the upstream and downstream ends (MUTCD §9C.101).- The TCS verifies pedestrian and bicycle accommodation on site; where a facility is maintained, it must remain accessible and detectable per MUTCD standards.

Emergency Access

- 1 of 2 same-direction travel lane remains open (12 ft of traversable width) past the closed lane.
- The Traffic Control Supervisor completes and confirms the emergency access plan for this site and coordinates notification of police, fire, and emergency medical responder agencies prior to work (TCS duties per CDOT Standard Specifications 630.11).
- An emergency access plan is a required minimum element of the approved Method of Handling Traffic (CDOT 630.10(a)); this section is draft input for it, not the approved plan.

Site-Specific Notes

- **adjacent_intersection**: No devices added: the cross-street approach layout isn't generated. See the pending-verification disclosure. *(MUTCD §6N.12 p. 848: Work within the Traveled Way at an Intersection (11th Ed.))*
- **bicycle_facility**: Added 2 M4-9a BIKE DETOUR signs at the upstream and downstream ends. *(MUTCD §9C.101: bicycle facility work zone signing)*