Spin qubits

When we look back at the development of semi-conducting technology, a great moment was in 1947 - the demonstration of the first transistor. Shortly after that, people began to put several transistors together on a circuit with capacitors and resistors; and developed the first transistor radio. Even though this technology was quite remarkable, it clearly had its limits; how many components could you really solder together by hand on a board?

So a second momentous step was in 1958 - the first demonstration of an integrated circuit, where all of the relevant components were integrated monolithically in the same piece of germanium or silicon, and that's led to the remarkably powerful and complex processors that we use in computers and memory chips today.

Now, based on this very same core technology of transistors and integrated circuits, we have found in the last decade how to build some of the highest-quality quantum bits. If we look at how a transistor is built, essentially, it is a switch that controls the flow of electrons between two contacts using the voltage applied to a single gate. If we now imagine that we replace the one gate by multiple gates side-by-side separating the contacts, then with the gates we can locally pull in electrons or push away electrons, depending on the polarity of the voltage that we apply to the gates. In this way it is actually possible to isolate small puddles of electrons from the rest of the world. A quantum dot is the small space where electrons are pulled in below one gate separated by other puddles of electrons. As a community, it's now become routine to go to the extreme limit, where below each of these electrodes, just one single electron is isolated; and the spin of that electron is going to be our quantum bit.

So how in the world can we isolate individual electrons and control them? It starts with the notion of the charging energy, that is the energy that results from the Coulomb repulsion between electrons. As we add charges to the island, this costs energy, and if you go to very small capacitances, it turns out that the charging energy, the energy required to add one single electron charge, can be larger than the thermal energy. To give some examples, for a small island with a radius of a 100 nanometers, the charging energy is 3 meV. To put that number into perspective, the thermal energy at 4K is ten times less than this. So at 4K it is actually possible to control the number of charges on these islands one-by-one.

How do we know that individual charges are being added to the island?

The standard method is to look at the current that flows between the contacts through the quantum dot — the central island. In this schematic, we see a set of lines, called electrochemical potential lines, that can be pushed up or pulled down by the gate voltage as a ladder, and each line indicates the energy needed to add the next electron to the island. What we see in the configuration on the left is that this energy is larger than the energy of the highest occupied state in the reservoirs, called the Fermi energy, so the electrons in the reservoir don't have enough energy to go into the quantum dot. Furthermore, the line at the dot below it is lower than the Fermi energy in both reservoirs so no electron can leave the



dot. In other words, electrons cannot be removed from the island and electrons cannot be added to the island; current is blocked. We call this Coulomb blockade. In the configuration on the right, we have adjusted the gate voltage in such a way that the ladder comes down, and the electrochemical potential $\mu(N)$ lies exactly within the window between the source and drain Fermi energies or electrochemical potentials. In this condition, if an electron can move from the source into the island, then from the island it can move out to the drain. However, before the first electron leaves, no second electron can enter. So individual electrons are really being added one by one as they pass through the quantum dot. But altogether, these many electrons moving through one by one, do produce a measurable current.

The current flows whenever the electrochemical potential lies within this biased window between source and drain. We see this beautifully in measurements as sharp peaks in the conductors and current through the quantum dot for specific gate voltages where we have reached an alignment as shown in the schematic on the right, and for the intermediate gate voltages, the current is blocked.

A second important method to measure and detect the presence or absence of individual electrons is what we call charge sensing. Basically, if you imagine a single quantum dot and another quantum dot next to it, as you have seen, the current through the second quantum dot sensitively depends on the gate voltage; with a small change in gate voltage we can produce a large current or completely shut off the current. Now imagine a second quantum dot is placed next to the first. It turns out that a single charge added to the second quantum dot acts like a small shifting gate voltage through capacitive coupling, it shifts the position of the levels in the first quantum dot. So when a single charge is added to one quantum dot, the current through a neighbouring quantum dot is changed in a measurable way.

Let's look at an example of two quantum dots. In this case we need an additional gate in between the two quantum dots to control their coupling. By lowering the voltage on this tunnel barrier gate we can tune the electrical potential in such way that the two electrons are well isolated from each other. If we draw a gate voltage space where the gate voltage that controls the potential of one quantum dot is plotted on the horizontal axis, and the gate voltage that controls the second quantum dot on the vertical axis; then, if the two quantum dots are uncoupled, for specific voltages on the first gate electrode electrons are added to the first quantum dot. These transitions are represented by the vertical lines in the plot.

Similarly, for specific voltages on the second gate electrode, electrons are added one at a time to the second quantum dot. These are the horizontal lines.

If we now consider two quantum dots in each other's vicinity, two effects will happen. The first is that crosstalk. The voltage applied to the first gate electrode also affects the potential of the second quantum dot, which sits to its side; and vice versa. That's why, the lines that were vertical and horizontal before, are now aligned at an angle.



A second effect is that a change in the number of electrons in one quantum dot changes the alignment of the levels in the second quantum dot, which is seen in the diagram as discrete shifts in the position of the charge transitions.

So now, how to go from these simple concepts of early demonstrations to large-scale circuits? First we require all the quantum dots to be as identical and uniform as they can be, so that it becomes practical to control the properties of many quantum dots, representing the qubits. To do that, even though university clean rooms have been a great way to get started, it has become clear that we really need access to industry-standard clean rooms, that are optimized not for creative science and exploring new ideas, like university clean rooms, but that are optimized for producing many components that are all as clean and identical as they can be. With this motivation, in 2015, we started a close collaboration with Intel that is focused on using 300 mm technology to produce high quality quantum dot arrays.

Now, even if quantum dot arrays are placed along a line, eventually, we do need twodimensional arrays. Bringing wires to all the qubits in a two-dimensional array may be very difficult; however fruitful ideas have been explored to adjust qubits or quantum dots using cross-bar technology - the same technology that is used today in displays and memory chips. Where a limited number of wires, that are running horizontally and vertically, can be used to adjust a much larger number of components, like pixels on a display or quantum dots in a two-dimensional array. With this approach, we envision that perhaps something like 1024 qubits can be integrated into a single array, no larger than 30 x 30 micrometres. To go beyond that, we envision true quantum integrated circuits, where different local arrays are interconnected with other local arrays on the same chip using what we call quantum links, links that can carry quantum information, that can transfer entanglement. Many ideas for producing such links have been tested and are being tested in the lab today. In addition, we imagine a layer of classical electronics co-integrated with the qubits in the same way, to distribute signals on the chip efficiently. No doubt, it's a phenomenal challenge to realize such complex circuits. All the pieces are falling in place and we are working hard to make it happen.

