# Unboxing Storyboard


FRAGILE
birds eye view
PRIORITY MAIL

1) Upon opening the initial box, there should be the machine, one black box, and one larger white box.


TABLET
PRIORITY
★MAIL★

2) Take the machine and your two boxes out. The printer is heavy so you may want someone to help you take it out.


Jumper
press top left
REPETREL
HYREL 3D

3) Carefully take the tablet out of the box and turn it on by pressing the top left corner

* Unbox the big box *


PRIORITY
★MAIL★

4) Carefully unbox the larger box.



5) Components: Painters tape, bag: syringe, clay, extruder, injection heads, nozzle heads, hex set, pliers, tweezers, scraping tool, wire brush, blade, power cord, metal pole holder with screws



these are only in the box if it was bought

6: More Components: First Box = micrometer, fan, extruder. There could be more extruders if bought together.


ABS
Glass Bed
Bed

7) More Components: Filament, Bed, Glass Bed



8) Put your tablet on the tablet stand and plug in the two cords accordingly


y-axis
x-axis

9) Check that the x-axis moves from left to right and the y-axis moves front and back.


switch
power plug

10) The left side of the machine has a switch and the power plug.


12 v jack
microphone
headphones
usb ports

11) The right side of the machine has four USB connection ports, 12 v jack, microphone and headphones jack



12) You can insert heads onto the yokes or you can store the on the top sides of the machine.