# Installing the ESP32 Board in Arduino IDE (Windows, Mac OS X, Linux)

There's an add-on for the Arduino IDE that allows you to program the ESP32 using the Arduino IDE and its programming language. In this tutorial we'll show you how to install the ESP32 board in Arduino IDE whether you're using Windows, Mac OS X or Linux.

#### Watch the Video Tutorial

https://youtu.be/mBaS3YnqDaU

### Prerequisites: Arduino IDE Installed


Before starting this installation procedure, make sure you have the latest version of the Arduino IDE installed in your computer. If you don't, uninstall it and install it again. Otherwise, it may not work.

Having the latest Arduino IDE software installed from <a href="mailto:arduino.cc/en/Main/Software">arduino.cc/en/Main/Software</a>, continue with this tutorial.


## Installing ESP32 Add-on in Arduino IDE

To install the ESP32 board in your Arduino IDE, follow these next instructions:

1. In your Arduino IDE, go to File> Preferences




2. Enter https://dl.espressif.com/dl/package\_esp32\_index.json into the "Additional Board Manager URLs" field as shown in the figure below. Then, click the "OK" button:




**Note:** if you already have the ESP8266 boards URL, you can separate the URLs with a comma as follows:

https://dl.espressif.com/dl/package\_esp32\_index.json, http://arduino.esp8266.com/stable/package\_esp8266com\_index.json


3. Open the Boards Manager. Go to Tools > Board > Boards Manager...



4. Search for **ESP32** and press install button for the "**ESP32 by Espressif Systems**":




5. That's it. It should be installed after a few seconds.




### **Testing the Installation**

Plug the ESP32 board to your computer. With your Arduino IDE open, follow these steps:


1. Select your Board in **Tools** > **Board** menu (in my case it's the **DOIT ESP32 DEVKIT V1**)



2. Select the Port (if you don't see the COM Port in your Arduino IDE, you need to install the CP210x USB to UART Bridge VCP Drivers):



3. Open the following example under File > Examples > WiFi (ESP32) > WiFiScan



4. A new sketch opens in your Arduino IDE:

```
🔯 WiFiScan | Arduino 1.8.5
                                                                                  ×
File Edit Sketch Tools Help
 WiFiScan
 1 /*
       This sketch demonstrates how to scan WiFi networks.
 3 * The API is almost the same as with the WiFi Shield library,
 4 * the most obvious difference being the different file you need to include:
 6 #include "WiFi.h"
 8 void setup()
 9 {
10
       Serial.begin(115200);
11
       // Set WiFi to station mode and disconnect from an AP if it was previously
12
13
       WiFi.mode(WIFI STA);
14
       WiFi.disconnect();
15
       delay(100);
16
       Serial.println("Setup done");
17
18 }
19
20 void loop()
                                                         DOIT ESP32 DEVKIT V1, 80MHz, 921600, None on COM4
```

5. Press the **Upload** button in the Arduino IDE. Wait a few seconds while the code compiles and uploads to your board.



6. If everything went as expected, you should see a "**Done uploading.**" message.

```
Done uploading

Writing at UXUUU4CUUU... (84 %)

Writing at 0x00050000... (89 %)

Writing at 0x00058000... (100 %)

Wrote 481440 bytes (299651 compressed) at 0x00010000 in 4.7 secon

Hash of data verified.

Compressed 3072 bytes to 122...

Writing at 0x00008000... (100 %)

Wrote 3072 bytes (122 compressed) at 0x00008000 in 0.0 seconds (e

Hash of data verified.


Leaving...

Hard resetting...
```

7. Open the Arduino IDE Serial Monitor at a baud rate of 115200:




8. Press the ESP32 on-board **Enable** button and you should see the networks available near your ESP32:



### **Troubleshooting**

If you try to upload a new sketch to your ESP32 and you get this error message "A fatal error occurred: Failed to connect to ESP32: Timed out... Connecting...". It means that your ESP32 is not in flashing/uploading mode. Having the right board name and COM por selected, follow these steps:

Hold-down the "BOOT" button in your ESP32 board



Press the "Upload" button in the Arduino IDE to upload your sketch:



 After you see the "Connecting...." message in your Arduino IDE, release the finger from the "BOOT" button:

```
Uploading.

Archiving built core (caching) in: C:\Users\BUISAN-1\AppData\Local\Temp\arduino_cache_959083\core\core_espressif_esp32_esp32doit-devkit-vi_Flas

&ketch uses $01366 bytes (384) of program storage space. Maximum is 1310720 bytes.

&lobal variables use 37320 bytes (124) of dynamic memory, leaving 257592 bytes for local variables. Maximum is 294912 bytes.

esptool.py v2.1

connecting......

Chip is RS$3200WD66 (revision (unknown 0xa))

typloading stub...

Blub running...

Changing baud rate to 921600

Changed.

configuring flash size...

Auto-detected Flash size: 4MB

Compressed 8192 bytes to 47...

Writing at 0x0000e000... (100 %)

Wrote $192 bytes (47 compressed) at 0x0000e000 in 0.0 seconds (effective $192.1 kbit/s)...

Bush of data verified.

Compressed 12304 bytes to 8126...

Writing at 0x00001000... (100 %)
```

• After that, you should see the "**Done uploading**" message That's it. Your ESP32 should have the new sketch running. Press the "**ENABLE**" button to restart the ESP32 and run the new uploaded sketch.