

MAINTENANCE PROCEDURE

Preventive Maintenance SOP

1. Inspect pumps monthly.
2. Inspect compressors every 90 days.
3. Record maintenance logs.
4. Review maintenance records quarterly.

Responsible Department:

Maintenance Team