

ON-BOARD DIAGNOSTIC [MULTIPLEX COMMUNICATION SYSTEM (L.H.D.)]

09-02F ON-BOARD DIAGNOSTIC [MULTIPLEX COMMUNICATION SYSTEM (L.H.D.)]

FOREWORD [MULTIPLEX COMMUNICATION SYSTEM (L.H.D.)]	09-02F-1
Troubleshooting Procedure	09-02F-2
DTC TABLE [MULTIPLEX COMMUNICATION SYSTEM (L.H.D.)]	09-02F-3
DETERMINING MALFUNCTIONING PART (HS-CAN) [MULTIPLEX COMMUNICATION SYSTEM (L.H.D.)]	09-02F-4
DTC Output Pattern and Malfunctioning Part	09-02F-5
A	09-02F-6
B	09-02F-7
C	09-02F-8
D	09-02F-9
E	09-02F-10
F	09-02F-11
G	09-02F-12
H	09-02F-13
I	09-02F-14
J	09-02F-15
K	09-02F-16
DETERMINING MALFUNCTIONING PART (MS-CAN) [MULTIPLEX COMMUNICATION SYSTEM (L.H.D.)]	09-02F-16
DTC Output Pattern and Malfunctioning Part	09-02F-17
A	09-02F-17
B	09-02F-18
M-MDS AND VEHICLE NOT COMMUNICATING [MULTIPLEX COMMUNICATION SYSTEM (L.H.D.)]	09-02F-18
Detection Condition	09-02F-18
Possible Causes	09-02F-18
Wiring Diagram	09-02F-19
Diagnostic Procedure	09-02F-19
DTC U0073, U1900 [MULTIPLEX COMMUNICATION SYSTEM (L.H.D.)]	09-02F-21
Diagnostic procedure	09-02F-22
DTC 16:Er12 [MULTIPLEX COMMUNICATION SYSTEM (L.H.D.)]	09-02F-23
Diagnostic procedure	09-02F-24