1	GND
2	GND
3	3 POWER
4	O2 HEATER B2S1
5	O2 HEATER 1
6	6
7	IGN2
8	IGN7
9	SAI VALVE 9
10	10
11	11
12	O2 RETURN B2S1
13	O2 B2S1
14	02 1
15	15
16	16
17	RADIATOR TEMP
18	VVT2 B1
19	INJ7
20	EGT BANK2
21	21 RELAY OR VIGN
22	VVT1 1
23	MARELAY 23
24	INJ8
25	25
26	IAT
27	GNDA
28	ALTERNATOR
29	MAF
30	30
31	31
32	GND
33	GNDA
34	PPS1
35	PPS2
36	GNDA
37	TACH
38	CRUISE ON1
39	CLUTCH
40	40 AC
41	41 AC

J3A

TE 1241434-1 VAG 121

1	GND
2	GND
3	OEM3_POWER
4	OUT_O2_HEATER_B2S1
5	OUT_O2_HEATER_1
6	OEM_6
7	OUT_IGN2
8	OUT_IGN7
9	OUT_SAI_VALVE_9
10	OEM_10
11	OEM_11
12	O2_RETURN_B2S1
13	IN_O2_B2S1
14	IN_O2_1
15	OEM_15
16	OEM_16
17	IN_RADIATOR_TEMP
18	OUT_VVT2_B1
19	OUT_INJ7
20	IN_EGT_BANK2
21	OEM21_RELAY_OR_VIGN
22	OUT_VVT1_1
23	OUT_MAIN_RELAY_23
24	OUT_INJ8
25	OEM_25
26	IN_IAT
27	GNDA
28	IN_ALTERNATOR
29	IN_MAF
30	OEM_30
31	OEM_31
32	GND
33	GNDA
34	IN_PPS1
35	IN_PPS2
36	GNDA
37	OUT_TACH
38	IN_CRUISE_ON1
39	IN_CLUTCH
40	OEM40_AC
41	OEM41_AC

42	42
43	K_LINE
44	SAI VALVE 44
45	45
46	SAI PUMP RELAY
47	CHECK ENGINE
48	48
49	49
50	GNDA
51	LSU VM 51
52	LSU IP 52
53	+5V
54	VSS
55	BRAKE NC
56	BRAKE NO
57	CRUISE ON2
58	CAN L
59	GND
60	CAN H
61	61 EGT OR AC
62	CONSTANT POWER
63	O2 HEATER B1S2
64	EVAP
65	FUEL PUMP RELAY
66	66 FAN OR SAI
67	67
68	O2 RETURN B1S2
69	O2 B1S2
70	LSU UN 70
71	LSU RCAL 71
72	+5V
73	+5V
74	74
75	CRUISE SET
76	CRUISE RESUME
77	77
78	78
79	79
80	80
81	FUEL CONSUMPTION

J3B

TE 1241434-1 VAG 121

42	OEM_42
43	K_LINE
44	OUT_SAI_VALVE_44
45	OEM_45
46	OUT_SAI_PUMP_RELAY
47	OUT_CHECK_ENGINE
48	OEM_48
49	OEM_49
50	GNDA
51	LSU_VM_51
52	LSU_IP_52
53	+5V
54	IN_VSS
55	IN_BRAKE_NC
56	IN_BRAKE_NO
57	IN_CRUISE_ON2
58	CAN_L
59	GND
60	CAN_H
61	OEM61_EGT_OR_AC
62	IN_CONSTANT_POWER
63	OUT_O2_HEATER_B1S2
64	OUT_EVAP
65	OUT_FUEL_PUMP_RELAY
66	OEM66_FAN_OR_SAI
67	OEM_67
68	O2_RETURN_B1S2
69	IN_O2_B1S2
70	LSU_UN_70
71	LSU_RCAL_71
72	+5V
73	+5V
74	OEM_74
75	IN_CRUISE_SET
76	IN_CRUISE_RESUME
77	OEM_77
78	OEM_78
79	OEM_79
80	OEM_80
81	OUT_FUEL_CONSUMPTION

82	CRANK VR POS
83	+5V
84	TPS2
85	IAT
86	CAM1
87	CAM2
88	INJ4
89	INJ2
90	CRANK VR NEG
91	GNDA
92	TPS1
93	CLT
94	IGN4
95	IGN8
96	INJ1
97	INJ3
98	+5V
99	GNDA
100	100
101	MAP
102	IGN1
103	IGN5
104	WASTEGATE
105	IDLE
106	KNOCK1
107	KNOCK2
108	GNDA
109	109
110	IGN6
111	IGN3
112	INJ6
113	INJ5
114	114
115	VVT1 2
116	116
117	ETB POS
118	ETB NEG
119	119
120	VVT2 B2
121	121 POWER OR LOAD

J3C

TE 1241434-1 VAG 121

82	IN_CRANK_VR_POS
83	+5V
84	IN_TPS2
85	IN_IAT
86	IN_CAM1
87	IN_CAM2
88	OUT_INJ4
89	OUT_INJ2
90	IN_CRANK_VR_NEG
91	GNDA
92	IN_TPS1
93	IN_CLT
94	OUT_IGN4
95	OUT_IGN8
96	OUT_INJ1
97	OUT_INJ3
98	+5V
99	GNDA
100	OEM_100
101	IN_MAP
102	OUT_IGN1
103	OUT_IGN5
104	OUT_WASTEGATE
105	OUT_IDLE
106	IN_KNOCK1
107	IN_KNOCK2
108	GNDA
109	OEM_109
110	OUT_IGN6
111	OUT_IGN3
112	OUT_INJ6
113	OUT_INJ5
114	OEM_114
115	OUT_VVT1_2
116	OEM_116
117	OUT_ETB_POS
118	OUT_ETB_NEG
119	OEM_119
120	OUT_VVT2_B2
121	OEM121_POWER_OR_LOAD

J1A

Superseal 60 A/B

IN_CLT	1A
OUT_VVT2_B2	2A
OUT_ETB_NEG	3A
OUT_WASTEGATE	4A
OUT_IDLE	5A
OUT_INJ1	6A
OUT_INJ2	7A
OUT_INJ3	8A
OUT_INJ6	9A
IN_KNOCK2	10A
IN_O2_B2S1	11A
OUT_IGN3	12A
IN_CAM1	13A
OUT_IGN8	14A
OUT_IGN5	15A
IN_CAM2	16A
IN_KNOCK1	17A
IN_BRAKE_NC	18A
OUT_IGN6	19A
IN_CRANK_VR_POS	20A
OUT_IGN1	21A
IN_MAP	22A
OUT_IGN4	23A
GNDA	24A
IN_TPS1	25A
IN_BRAKE_NO	26A
OEM121_POWER_OR_LOAD	27A
OUT_VVT1_2	28A
OUT_ETB_POS	29A
OUT_TACH	30A
IN_TPS2	31A
OUT_INJ5	32A
OUT_INJ4	33A
IN_CRANK_VR_NEG	34A

J1B

Superseal 60 A/B

IN_RADIATOR_TEMP	1B
O2_RETURN_B1S2	2B
OUT_O2_HEATER_B1S2	3B
OUT_EVAP	4B
LSU_IP_52	5B
OUT_SAI_VALVE_44	6B
OUT_SAI_VALVE_9	7B
OUT_IGN2	8B
OEM66_FAN_OR_SAI	9B
IN_O2_B1S2	10B
IN_VSS	11B
IN_PPS2	12B
IN_O2_1	13B
OUT_IGN7	14B
LSU_UN_70	15B
OUT_FUEL_PUMP_RELAY	16B
LSU_RCAL_71	17B
LSU_VM_51	18B
O2_RETURN_B2S1	19B
IN_PPS1	20B
OUT_SAI_PUMP_RELAY	21B
IN_IAT	22B
+5V	23B
IN_MAF	24B
OUT_CHECK_ENGINE	25B
IN_ALTERNATOR	26B

J2

Superseal 26 C

OUT_VVT2_B1	1C
OUT_FUEL_CONSUMPTION	2C
OUT_INJ7	3C
OUT_MAIN_RELAY_23	4C
GND	5C
K_LINE	6C
OUT_O2_HEATER_B2S1	7C
IN_CRUISE_ON2	8C
IN_CRUISE_RESUME	9C
IN_EGT_BANK2	10C
IN_CONSTANT_POWER	11C
OEM61_EGT_OR_AC	12C
IN_CRUISE_SET	13C
OEM21_RELAY_OR_VIGN	14C
OEM40_AC	15C
CAN_L	16C
IN_CRUISE_ON1	17C
IN_CLUTCH	18C
CAN_H	19C
GND	20C
OUT_VVT1_1	21C
OUT_INJ8	22C
OEM41_AC	23C
OUT_O2_HEATER_1	24C
OEM3_POWER	25C
GND	26C

OEM_6 — P6

OEM_10 — P10

OEM_11 — P11

OEM_15 — P15

OEM_16 — P16

OEM_25 — P25

OEM_30 — P30

OEM_31 — P31

OEM_42 — P42

OEM_45 — P45

OEM_48 — P48

OEM_49 — P49

OEM_67 — P67

OEM_74 — P74

OEM_77 — P77

OEM_78 — P78

OEM_79 — P79

OEM_80 — P80

OEM_100 — P100

OEM_109 — P109

OEM_114 — P114

OEM_116 — P116

OEM_119 — P119

VAG ME7.x / Superseal 60+26

GND

GNDA

+5V

rusEFI

Sheet: /

File: vag121-superseal.kicad_sch

Title: VAG 121 to Superseal 60+26

Size: A2	Date: 2026-10-17	**Rev: a**
KiCad E.D.A. 10.0.6		Id: 1/1