General purpose bus
Ignition
Injection
Analog inputs (sensors)
Discrete inputs
LS & HS outputs
DC Motor

Install R25 for 1990–1993 manual models with KIA TPS Also remove R22 for KIA TPS WARNING: Installing R25 with stock 1990–1993 TP switch will lead to short of 5V-GND!



