







rusEFI.com

Sheet: /DC Driver 1/
File: DC_MOTOR_0.1.kicad_sch


Title: UAEFI

Size: A4 Date: 2026-07-14

KiCad E.D.A. 10.0.6

Rev: F3

Id: 2/9



rusEFI.com

Sheet: /LS/
File: LS4.kicad_sch


Title: UAEFI

Size: A4 Date: 2026-07-14

KiCad E.D.A. 10.0.6

Rev: F3

Id: 3/9



rusEFI.com

Sheet: /DC Driver 2/
File: DC_MOTOR_0.1.kicad_sch

Title: UAEFI


Size: A4 Date: 2026-07-14

KiCad E.D.A. 10.0.6

Rev: F3

Id: 4/9





rusEFI.com

Sheet: /LS HOT/

File: LS_HOT.kicad_sch

Title: UAEFI


Size: A4

Date: 2026-07-14


Rev: F3

KiCad E.D.A. 10.0.6

Id: 6/9



Remove R20-R22, R26-R28, and install Q7-Q12 for use with dumb coils




rusEFI.com

Sheet: /Ignition/
File: IGN6.kicad_sch

Title: UAEFI

Size: A4 Date: 2026-07-14
KiCad E.D.A. 10.0.6

Rev: F3
Id: 9/9



rusEFI.com

Sheet: /Injector/

File: INJ6.kicad_sch

Title: UAEFI

Size: A4

Date: 2026-07-14

Rev: F3

KiCad E.D.A. 10.0.6

Id: 10/9