RHYTHM X

# USER MANUAL

GOAT DIGITAL

# COMPANY PROFILE

GOAT Digital is a dynamic and fast-emerging brand committed to delivering high-quality, premium mobile accessories at aggressive and reasonable prices. Launched in January 2025 and headquartered in Nagpur, Maharashtra, our mission is simple: to bridge the gap between cutting-edge tech and affordability.
We specialize in a wide range of mobile accessories including:
TWS (True Wireless Stereo) Earbuds, Neckbands, Power Banks, Fast Chargers, Data & Charging Cable, And a growing line of innovative mobile gadgets.

To become India's most trusted and value-driven brand in the mobile accessories space by delivering products that combine style, performance, and durability — without the premium price tag.

We offer premium build quality, ensuring our products stand out in durability and design. Our smart, fast-charging solutions are engineered for efficiency and convenience, while our audio devices deliver superior sound experiences. With an aggressive pricing strategy, we make top-tier technology accessible to everyone. Every product undergoes rigorous quality control to maintain high standards. As a proudly Indian brand, we are committed to excellence and innovation.

# INSIDE THE BOX

- 1 N Neckband
- 1N Type-C Charging Cable

# PRODUCT LAYOUT

Magnet On/Off Switch

Game Mode/ Voice Assistant Button

Volume Increase/ Next Button

Multifunction Button

Volume Decrease/ Previous Button

Type-C Charging Port

# HOW TO PAIR

Step 1: Before turning on the neckband, make sure it is adequately charged. The neckband features magnetic on/off technology. To turn on the neckband, simply separate the two earbuds. Once separated, the neckband will automatically power on and enter pairing mode.

Step 2: Tap **“GOAT Rhythm X”** from the smartphone’s Bluetooth menu. There is a ring prompt after a succesful connection. This indicates that neckband is successfully connected to your device.

Step 3: Congratulations! You are now connected and can start playing media.

# MEDIA CONTROLS

**Play/Pause:**

- Single press the Multifunction button to play or pause the music.

**Volume +/-:**

- Press the “+” button to turn the volume up.
- Press the “-” button to turn the volume down.

**Music Skip:**

- Press and hold the “+” button to skip to the next track.
- Press and hold the “-” button to skip to the previous track.

# CALL CONTROLS

**Answer incoming call:**

- When there is an incoming call, the earphone will issue a voice message. Press the Multifunction button once to answer the call, or use your mobile phone to answer it.

**Reject a call:**

- When there is an incoming call, the earphone will issue a voice message. Press the Multifunction button for 2 seconds to reject the call, or use your mobile phone to reject the call.
- Press the Multifunction button once or use your mobile phone to hang up your call.

# DUAL PAIRING

**Step 1:**

- Connect the neckband to one of the two devices. Then switch both the neckband and the device's Bluetooth mode off.

**Step 2:**

- Now connect the neckband to the second device, and again switch the first device's Bluetooth mode on.
- The neckband will be connected to both devices. If not, manually connect the first device once again to activate dual pairing.

# GAME MODE AND VOICE ASSISTANT ACTIVATION

**Enable Voice Assistant:**

- Press and hold the Game Mode/Voice Assistant button for 3 seconds to activate the voice assistant.

**Enable Game Mode:**

- Press the Game Mode/Voice Assistant button once to activate Game Mode.

# CHARGING THE NECKBAND

Note: Please only use a 5V/1A adapter to charge the neckband as higher voltage adapters can damage the battery of the neckband.

**Charging the Neckband:** While charging the neckband, the LED light will glow static indicating that the neckband is charging.

**Fully Charged:** When fully charged,  LED light will turn off indicating that the neckband is fully charged.

# TECHNICAL SPECIFICATIONS

| Parameter | Value |
|---|---|
| Bluetooth Version | 5.3 |
| Effective Distance | 15m |
| Impedance | 32 Ω |
| Product Weight | 33g |
| Speaker Size | 13mm |
| Total Playtime | upto 50 Hours |
| Standby Time | upto 350 Hours |

| Parameter | Value |
|---|---|
| Neckband Charging Time | 1.5 Hours |
| Talktime | upto 45 Hours |
| Frequency | 20Hz~20KHz |
| IP Rating | IPX5 |
| Charging Port | Type-C |
| Rated Input | 5V/1A |

# SAFETY & MAINTENANCE

Please read the below suggestions to help prolong the product lifespan and clearly understand the warranty clauses:
Please keep the product dry, do not put it in humid conditions to avoid a short circuit.

Do not expose it to the peak sun or high heat for extended periods, as this will shorten the lifespan of electronic components, damage the battery and deform some plastic parts.

Please do not put it in cold circumstances to avoid damage to the PCB board.

Please do not attempt to dismantle the product, as it may be unsafe, especially for non-professionals.

Do not use chemical products, detergents, or oily liquids to clean the item.

Do not scratch the surface with sharp items to avoid damaging the case and appearance.

Do not charge the product for more than 5 hours to avoid loss in battery life.

Avoid hearing music at maximum volume for long periods as this can affect your hearing and is not advisable.

Note: Any damage to the product that is not a manufacturing defect will render the warranty null and void. Therefore, please take utmost care of your product.