

ChargerInterface

+ start() : void
+ stop() : void
+ setEvseMaxCurrent(value) : void
+ setEvseMaxVoltage(value) : void
+ setEvseMaxPower(value) : void
+ setEvseDeltaVoltage(value) : void
+ setEvseDeltaCurrent(value) : void
+ setEvTargetVoltage(voltage) : bool
+ setEvTargetCurrent(current) : bool
+ getEvsePresentVoltage() : float
+ getEvsePresentCurrent() : float
+ isVoltageLimitExceeded(voltage) : bool
+ isPowerLimitExceeded(power) : bool



Charger

- evse_present_voltage : float
- evse_present_current : float
- evse_delta_u : float
- evse_delta_i : float
- stopped : bool

+ start() : void
+ stop() : void
+ setEvTargetVoltage(voltage) : bool
+ setEvTargetCurrent(current) : bool
- _calcEvsePresentVoltage() : void
- _calcEvsePresentCurrent() : void

Implements physics simulation:
Ramps voltage/current based on
delta values instead of instantaneous steps.