

ChargerInterface

- + *start() : void*
- + *stop() : void*
- + *setEvseMaxCurrent(value) : void*
- + *setEvseMaxVoltage(value) : void*
- + *setEvseMaxPower(value) : void*
- + *setEvseDeltaVoltage(value) : void*
- + *setEvseDeltaCurrent(value) : void*
- + *setEvTargetVoltage(voltage) : bool*
- + *setEvTargetCurrent(current) : bool*
- + *getEvsePresentVoltage() : float*
- + *getEvsePresentCurrent() : float*
- + *isVoltageLimitExceeded(voltage) : bool*
- + *isPowerLimitExceeded(power) : bool*



Charger

- *evse_present_voltage : float*
- *evse_present_current : float*
- *evse_delta_u : float*
- *evse_delta_i : float*
- *stopped : bool*
- + *start() : void*
- + *stop() : void*
- + *setEvTargetVoltage(voltage) : bool*
- + *setEvTargetCurrent(current) : bool*
- *_calcEvsePresentVoltage() : void*
- *_calcEvsePresentCurrent() : void*

Implements physics simulation:
Ramps voltage/current based on
delta values instead of instantaneous steps.