Contents

- Inital point of design variable
- Setting up Linear Inequality constraint
- Running Optimization
- Plotting section

```
clc
clear all
```

Inital point of design variable

Setting up Linear Inequality constraint

```
Nnodes = Nelem + 1;
% rin > 1cm ---> -rin < -1cm
A1 = zeros(Nnodes, 2*Nnodes);
k=2;
for i=1:((Nnodes))
    A1(i,k) = -1;
    k = k+2;
end
b1 = -1e-2*ones(Nnodes, 1);
% rout - rin > 2.5mm ----> -rout + rin < -2.5mm</pre>
A2 = zeros((Nnodes),2*(Nnodes));
k = 1;
for i=1:((Nnodes))
    A2(i,k) = -1;
   A2(i,k+1) = 1;
    k = k+2;
end
b2 = -2.5e-3*ones(Nnodes,1);
% rout < 5cm
A3 = zeros((Nnodes),2*(Nnodes));
k=1;
for i=1:((Nnodes))
    A3(i,k) = 1;
    k = k+2;
```

```
end
b3 = 5e-2*ones(Nnodes, 1);
% -rout + rin < 0 ---> rout > rin
A4 = zeros(Nnodes, 2*Nnodes);
k=1;
for i=1:Nnodes
    A4(i,k) = -1;
    A4(i,k+1) = 1;
    k = k+2;
end
b4 = zeros(Nnodes, 1);
A = [A1; A2; A3; A4];
b = [b1;b2;b3;b4];
lb = ones(2*Nnodes,1);
ub = 1b;
1b(2:2:end) = 0.01;
1b(1:2:end) = 0.0175;
ub(2:2:end) = 0.0475;
ub(1:2:end) = 0.05;
```

Running Optimization

Plotting section

```
Iyy = Calc_Iyy(X_opt, Nnodes);
force = Calc_force(x,500,L);
[u] = CalcBeamDisplacement(L, 70e9, Iyy, force, Nelem);
zmax = X_opt(1:2:end);
[sigma] = CalcBeamStress(L, 70e9, zmax, u, Nnodes-1);
norm_sigma = sigma/600e6;
figure
plot(x,norm sigma,'ks-')
xlabel('distance along wing')
ylabel('magnitude of normal stress')
figure
plot(x,sigma,'ks-')
xlabel('distance along wing')
ylabel('magnitude of normal stress')
figure
plot(x,u(1:2:2*(Nelem+1)), 'ks-');
xlabel('distance along wing')
ylabel('vertical displacement of spar')
figure
plot(x,X_opt(1:2:end), 'bv-');
hold on;
plot(x, X_opt(2:2:end), 'k^-');
plot(x,-X_opt(1:2:end), 'bv-');
plot(x,-X_opt(2:2:end), 'k^-');
```

```
plot(x,0*X_opt(1:2:end),'k--','lineWidth',2);
xlabel('Length of Spar');
ylabel('Radius');
legend('$R_{out}$','$R_{in}$','Interpreter','latex');
title ('Cross-sectional View of Spar')
figure
plot(x, X0(1:2:end), 'bv-');
hold on;
plot(x,X0(2:2:end), 'k^-');
plot(x,-X0(1:2:end),'bv-');
plot(x,-X0(2:2:end),'k^-');
plot(x,0*X0(1:2:end),'k--','lineWidth',2);
xlabel('Length of Spar');
ylabel('Radius');
legend('$R_{out}$','$R_{in}$','Interpreter','latex');
title ('Cross-sectional View of Spar')
```

Published with MATLAB® R2021a