

HMIP-SWDM – Domoticz Plugin Overview



Datapoints for Device 3597 & STATE 3622 to obtain value attribute "0" |

HMIP-SWDM – HomeMatic WebUI - Devices



HMIP-SWDM — Get the IDs for the Device and Datapoints (XML-API)

Get the devices state list: http://ccu-ip-address/config/xmlapi/statelist.cgi
Result is XML tree.

Select device HMIP-SWDM with serial number 001558A99D5A78, device id 3597 and the channel

• Channel 1 with datapoint id 3622 (STATE) – Name: HmIP-RF. 001558A99D5A78:1.STATE The ids are used in the plugin configuration.

The type "STATE" is used with value "0" (Closed) or "1" (Open).

```
<state>
   <device name="Garagentor" ise id="3597" unreach="false" config pending="false">
       <channel name="Garagentor:0" ise id="3598">
           <datapoint name="HmIP-RF.001558A99D5A78:0.CONFIG PENDING" type="CONFIG PENDING" ise id="3599" value="false" valuetype="2" valueunit="" timestamp="1611044101"/>
           <datapoint name="HmIP-RF.001558A99D5A78:0.DUTY CYCLE" type="DUTY CYCLE" ise id="3603" value="false" valuetype="2" valueunit="" timestamp="1611044101"/>
           <datapoint name="HmIP-RF.001558A99D5A78:0.LOW BAT" type="LOW BAT" ise id="3605" value="false" valuetype="2" valueunit="" timestamp="1611044101"/>
           <datapoint name="HmIP-RF.001558A99D5A78:0.OPERATING VOLTAGE" type="OPERATING VOLTAGE" ise id="3609" value="2.800000" valuetype="4" valueunit="" timestamp="1611044101"/>
           <datapoint name="HmIP-RF.001558a99D5a78:0.0PERATING VOLTAGE STATUS" type="0PERATING VOLTAGE STATUS" ise id="3610" value="0" value=type="16" valueunit="" timestamp="161104"</pre>
           <datapoint name="HmIP-RF.001558A99D5A78:0.RSSI DEVICE" type="RSSI DEVICE" ise id="3611" value="178" valuetype="8" valueunit="" timestamp="1611044101"/>
           <datapoint name="HmIP-RF.001558A99D5A78:0.RSSI PEER" type="RSSI PEER" ise id="3612" value="0" valuetype="8" valueunit="" timestamp="0"/>
           <datapoint name="HmIP-RF.001558A99D5A78:0.UNREACH" type="UNREACH" ise id="3613" value="false" valuetype="2" valueunit="" timestamp="1611044101"/>
           <datapoint name="HmIP-RF.001558A99D5A78:0.UPDATE PENDING" type="UPDATE PENDING" ise id="3617" value="false" valuetype="2" valueunit="" timestamp="1610968122"/>
       </channel>
       <channel name="HmIP-SWDM 001558A99D5A78:1" ise id="3621">
           <datapoint name="HmIP-RF.001558A99D5A78:1.STATE" type="STATE" ise id="3622" value="0" valuetype="16" valueunit="""" timestamp="1611044101"/>
       <channel name="HmIP-SWDM 001558A99D5A78:2" ise id="3623"/>
   </device>
</state>
```

HMIP-SWDM – Domoticz Add Hardware




Notes: Set Check Interval as required, i.e. 30 seconds to get a faster response. Set Debug to false if plugin working ok.

HMIP-SWDM — Domoticz Add Hardware Log

```
2021-01-19 10:25:36.952 Status: Python Plugin System: (C1) Started.
2021-01-19 10:25:37.208 (C1) Debug logging mask set to: PYTHON PLUGIN QUEUE IMAGE DEVICE CONNECTION MESSAGE ALL
2021-01-19 10:25:37.208 (C1) 'HardwareID':'13'
2021-01-19 10:25:37.208 (C1) 'HomeFolder':'/home/pi/domoticz/plugins/hmip-swdm/'
2021-01-19 10:25:37.208 (C1) 'StartupFolder':'/home/pi/domoticz/'
2021-01-19 10:25:37.208 (C1) 'UserDataFolder':'/home/pi/domoticz/'
2021-01-19 10:25:37.208 (C1) 'Database':'/home/pi/domoticz/domoticz.db'
2021-01-19 10:25:37.208 (C1) 'Language':'en'
2021-01-19 10:25:37.208 (C1) 'Version':'1.0.0 (Build 20210119)'
2021-01-19 10:25:37.208 (C1) 'Author': 'rwbL'
2021-01-19 10:25:37.208 (C1) 'Name':'C1'
2021-01-19 10:25:37.208 (C1) 'Address':'CCU-IP'
2021-01-19 10:25:37.208 (C1) 'Port':'0'
2021-01-19 10:25:37.208 (C1) 'Key':'HmIP-SWDM'
2021-01-19 10:25:37.208 (C1) 'Mode1':'3597'
2021-01-19 10:25:37.208 (C1) 'Mode2':'3622'
2021-01-19 10:25:37.208 (C1) 'Mode5':'60'
2021-01-19 10:25:37.208 (C1) 'Mode6':'Debug'
2021-01-19 10:25:37.208 (C1) 'DomoticzVersion':'2020.2 (build 12847)'
2021-01-19 10:25:37.208 (C1) 'DomoticzHash':'815e12372-modified'
2021-01-19 10:25:37.208 (C1) 'DomoticzBuildTime':'2021-01-16 14:57:39'
2021-01-19 10:25:37.208 (C1) Device count: 0
2021-01-19 10:25:37.208 (C1) Creating new devices ...
2021-01-19 10:25:37.208 (C1) Creating device 'State'.
2021-01-19 10:25:37.209 (C1 - State) Updating device from 0:" to have values 1: 'Closed'.
2021-01-19 10:25:37.215 (C1) Device created: C1 - State
2021-01-19 10:25:37.215 (C1) Creating new devices: OK
2021-01-19 10:25:37.215 (C1) Heartbeat set: 60
2021-01-19 10:25:37.216 Python Plugin System: (C1) Pushing 'PollIntervalDirective' on to queue
2021-01-19 10:25:37.216 (C1) Datapoints:3622
2021-01-19 10:25:37.216 (C1) Processing 'PollIntervalDirective' message
2021-01-19 10:25:37.216 Python Plugin System: (C1) Heartbeat interval set to: 60.
2021-01-19 10:25:37.207 Status: Python Plugin System: (C1) Entering work loop.
2021-01-19 10:25:37.207 Status: Python Plugin System: (C1) Initialized version 1.0.0 (Build 20210119), author 'rwbL'
```

HMIP-SWDM – Domoticz Devices



State Closed has Alert level 1, Open Alert level 4.

HMIP-SWDM – dzVents script with Notification Example

```
--[[
   alert_window-door-contact.dzvents
   Window-Door-Contact (homematicIP device HmIP-SWDM) Alert Example.
   Send notification if the level of the Alert device changes to 4 (RED).
]]--
local IDX_WINDOWDOORCONTACT = 87; -- Type General, SubType Alert
local STATE OPEN = 4; -- Alert level 4 RED
return {
  on = \{
   devices = {
     IDX WINDOWDOORCONTACT
  },
  execute = function(domoticz, device)
   domoticz.log(('Device %s state changed to %s (%d).'):format(device.name, device.sValue, device.nValue), domoticz.LOG INFO)
   if device.nValue == STATE OPEN then
     -- Send notification via email
     local subject = ('SECURITY ALERT'):format()
     local message = ('Window-Door-Contact %s state changed to %s.'):format(device.name, device.sValue)
     domoticz.notify(subject, message, domoticz.PRIORITY HIGH)
   end
  end
```