

EE 531: ADVANCED VLSI DESIGN

Introduction to SystemVerilog

Nishith N. Chakraborty

January, 2025

INTRODUCTION

- SystemVerilog is a superset of Verilog
 - The SystemVerilog subset we use is 99% Verilog + a few new constructs
 - Familiarity with Verilog (which you have) helps a lot

MORE THOUGHTS ON HDLS

- Used for a variety of purposes in hardware design
 - High-level behavioral modeling
 - Register transfer level (RTL) behavioral modeling
 - Gate level netlists
 - Timing models for timing simulation
 - Design verification and testbench development
- Many different and useful features
- We tend to focus on RTL modeling and “synthesizable HDL”

HDL VS. PROGRAMMING

- Syntactically similar:
 - Data types, variables, assignments, if statements, loops, ...
- Very different mentality and semantic models: everything runs concurrently, unless specified otherwise
 - Statements model hardware
 - Implement structure in space not actions in time
- SW programs are composed of *subroutines* or *functions*
 - Subroutines *call* each other
 - Calling subroutine pauses when called subroutine runs
- HW descriptions are composed of *modules*
 - *Hierarchy* of modules *connected* to each other
 - Modules are active at same time – they're *concurrent*

SYSTEMVERILOG MODULES

- Look familiar? This is basically Verilog!
- Modules interface with top level constructs via ports
- Ports are usually input or output

```
module mymodule
  (a, b, c, f);

  output f;
  input  a, b, c;

  // Description goes here
endmodule: mymodule

// alternatively
module mymodule
  (input logic a , b, c,
   output logic f);

  // Description goes here
endmodule: mymodule
```

MODULE INSTANTIATION

- You can instantiate your own modules or pre-defined gates
 - Always instantiated inside another module
- Predefined: and, nand, or, nor, xor, xnor
 - For predefined gates port order is (output, input(s))
- For user defined modules, port order determined by user

```
module mymodule
  (a, b, c, f);

  output f;
  input a, b, c;

  module_name inst_name(port_connections);
endmodule: mymodule
```

Name of module to instantiate

Instance name

Connect the ports

The diagram illustrates the instantiation of a user-defined module named 'mymodule'. It shows the module declaration with its port list (a, b, c, f) and the instantiation statement. Annotations explain the components: 'Name of module to instantiate' points to the 'module' keyword; 'Instance name' points to the 'inst_name' parameter in the instantiation; and 'Connect the ports' points to the 'port_connections' parameter.

OPTIONS FOR CONNECTING MODULES

- For module instantiation, can specify port connections by name or by order.

```
module mod1
  (input a, b, output f);

  // ...
endmodule: mod1

// by order
module mod2
  (input c, d, output g);

  mod1 i0(c, d, g);
endmodule: mod2

// by name
module mod3
  (input c, d, output g);

  mod1 i0(.f(g), .b(d), .a(c));
endmodule: mod3
```

By name connections
can save headaches

EXAMPLE STRUCTURAL DESIGN

- This is SystemVerilog... you've seen this before with Verilog.

```
module mux
  (input a, b, sel output f);

  logic c, d, not_sel;

  not gate0(not_sel, sel);
  and gate1(c, a, not_sel);
  and gate2(d, b, sel);
  or  gate3(f, c, d);
endmodule: mux
```

Datatype for describing logical value

Built-in gates:
Port order is output(s), input(s)

EDGE-TRIGGERED EVENTS

- Variant of always block called *always_ff*
 - Indicated that block will be sequential logic (flip flops)
- Procedural block occurs only on signal's edge
 - @ (**posedge** ...) or @ (**negedge** ...)

```
always_ff @ (posedge clk, negedge reset_n) begin
    // This procedure will be executed
    // anytime clk goes from 0 to 1
    // or anytime reset_n goes from 1 to 0
end
```

FLIP FLOPS

- Output q “remembers” what input d was at last clock edge
 - One bit of memory
- Without reset:

```
module flipflop
  (d, q, clk);

  input d, clk;
  output logic q;

  always_ff @(posedge clk) begin
    q <= d;
  end
endmodule: flipflop
```

FLIP FLOPS

- Output q “remembers” what input d was at last clock edge
 - One bit of memory
- With asynchronous reset:

```
module flipflop_asyncr
  (d, q, clk, rst_n);

  input d, clk, rst_n;
  output logic q;

  always_ff @(posedge clk, negedge rst_n) begin
    if (rst_n == 0)
      q <= 0;
    else
      q <= d;
  end
endmodule: flipflop_asyncr
```

FLIP FLOPS

- Output q “remembers” what input d was at last clock edge
 - One bit of memory
- With synchronous reset:

```
module flipflop_syncr
  (d, q, clk, rst_n);

  input d, clk, rst_n;
  output logic q;

  always_ff @(posedge clk) begin
    if (rst_n == 0)
      q <= 0;
    else
      q <= d;
  end
endmodule: flipflop_syncr
```

MULTI-BIT FLIP FLOP

```
module flipflop_asyncr
(d, q, clk, rst_n);

    input [15:0] d,
    input clk, rst_n;
    output logic [15:0] q;

    always_ff @ (posedge clk, negedge rst_n) begin
        if (rst_n == 0)
            q <= 0; ←
        else
            q <= d;
    end
endmodule: flipflop_asyncr
```

Recognized by
type

DIGRESSION: MODULE PARAMETERS

- Parameters allow modules to be easily changed

```
module my_flipflop
# (parameter WIDTH=16)
(d, q, clk, rst_n);

    input [WIDTH-1:0] d;
    input clk, rst_n;
    output logic [WIDTH-1:0] q;
    ...
endmodule: my_flipflop
```

- Instantiate and set parameter:

```
// To use the default parameter value:
my_flipflop f0(d, q, clk, rst_n);

// Change parameter to 12 for this instance:
my_flipflop #(12) f0(d, q, clk, rst_n);
```


NON-BLOCKING ASSIGNMENT

- `<=` is the non-blocking assignment operator
- All left-hand side values take new values *concurrently*

```
always_ff @ (posedge clk) begin
    b <= a;
    c <= b;
end
```

c gets *old* value of b, not
value assigned just above

- This models synchronous logic



NON-BLOCKING VS. BLOCKING

- Use non-blocking assignment <= to describe edge-triggered (synchronous) assignments


```
always_ff @ (posedge clk) begin
    b <= a;
    c <= b;
end
```

- Use blocking assignment = to describe combinational assignment

```
always_comb begin
    b = a;
    c = b;
end
```


FINITE STATE MACHINE (FSM)

- State names
- Output values
- Transition values
- Reset state



FINITE STATE MACHINES CONTINUED

- An FSM look like when implemented



- Combinational logic and registers (things we know how to implement using SystemVerilog)

FULL FSM EXAMPLE

```


module fsm
  (clk, rst, x, y);

  input clk, rst, x, y;
  output logic [1:0] y;
  enum { STATEA=2'b00, STATEB=2'b01, STATEC=2'b10,
           STATED=2'b11 } curr_state, next_state;

  // next state logic
  always_comb begin
    case(curr_state)
      STATEA: next_state = x ? STATEB : STATEA;
      STATEB: next_state = x ? STATEC : STATED;
      STATEC: next_state = x ? STATED : STATEA;
      STATED: next_state = x ? STATEC : STATEB;
    endcase
  end

  // to be continued ...


```



FULL FSM EXAMPLE

```
// now concluded ...
// register for state memory
always_ff @(posedge clk) begin
    if (rst)
        curr_state <= STATEA;
    else
        curr_state <= next_state;
end

// output logic
always_comb begin
    case(curr_state)
        STATEA: y = 2'b00;
        STATEB: y = 2'b00;
        STATEC: y = 2'b11;
        STATED: y = 2'b10;
    endcase
end
endmodule: fsm
```



ARRAYS

```
module multidimarraytest;
  logic [3:0] myarray [2:0];

  assign myarray[0]      = 4'b0010;
  assign myarray[1][3:2] = 2'b01;
  assign myarray[1][1]   = 1'b1;
  assign myarray[1][0]   = 1'b0;
  assign myarray[2][3:0] = 4'hC;

  initial begin
    $display("myarray      == %b", myarray);
    $display("myarray[2:0] == %b", myarray[2:0]);
    $display("myarray[1:0] == %b", myarray[1:0]);
    $display("myarray[1]  == %b", myarray[1]);
    $display("myarray[1][2] == %b", myarray[1][2]);
    $display("myarray[2][1:0] == %b", myarray[2][1:0]);
  end
endmodule: multidimarraytest
```

ASSERTIONS

- Assertions are test constructs
 - Automatically validated as design is simulated
 - Written for properties that must always be true
- Makes it easier to test design
 - Don't have to manually check for these conditions

EXAMPLE: GOOD PLACE FOR ASSERTIONS

- Imagine you have a FIFO queue
 - When queue is full, it sets status_full to true
 - When queue is empty, it sets status_empty to true



- When status_full is true, wr_en must be false
- When status_empty is true, rd_en must be false

ASSERTION SYNTAX

- Assertion: a procedural statement that checks an expression when statement is executed

Use \$display to print test, \$error to print error, or \$fatal to print and halt simulation

```
// general form
assertion_name: assert(expression) pass_code;
else fail_code;

// example
always @(posedge clk) begin
    assert ((status_full == 0) || (wr_en == 0))
    else $error("Tried to write to FIFO when full.");
end
```

- SystemVerilog includes *concurrent assertions* that are continuously monitored and can express temporal conditions
 - Complex but very powerful

Thank you!