
This document provides additional assistance with wiring your Extron IP Link Pro Control Processor to your device. Different components may require a different wiring scheme than those listed below.

For complete operating instructions, refer to the user's manual for the specific IP Link Pro Control Processor or the documentation supplied by the manufacturer of the controlled device.

For more information on using Global Scriptor Modules, refer to the "[Guide to Using Scriptor Modules](#)" document.

Device Specifications

Device Type: Camera
Manufacturer: ACTi
Firmware Version: N/A
Model(s): i92

Tested on the Following Software and Firmware Versions

IP Link Pro Control Processor Firmware	Global Scriptor Version
2.08.0002-b001	1.4.2

Version History

Module Version	Date	Notes
1_0_0_0	7/16/2018	Initial Version

Supported Classes and Examples

HTTPClass

```
InterfaceName = ModuleName.HTTPClass('192.168.254.254', 80, 'admin', 'password', Model='i92')
```

Control Commands

Format with Qualifier:

```
InterfaceName.Set(Command, Value, {'Qualifier Key': 'Qualifier Value'})
```

Format without Qualifier:

```
InterfaceName.Set(Command, Value)
```

Command Brightness	Value 1 to 100 in steps of 1		
# Brightness example InterfaceName.Set('Brightness', 100)			
Command Contrast	Value 1 to 100 in steps of 1		
# Contrast example InterfaceName.Set('Contrast', 100)			
Command ExposureMode	Value 'Auto' 'Shutter Priority'	Value 'Manual'	Value 'Iris Priority'
# ExposureMode example InterfaceName.Set('ExposureMode', 'Auto')			
Command Flip	Value 'Enable'	Value 'Disable'	
# Flip example InterfaceName.Set('Flip', 'Enable')			
Command Focus	Value 'Far' 'Auto' 'Refocus'	Value 'Near' 'Manual'	Value 'Stop' 'Zoom_AF'
# Focus example InterfaceName.Set('Focus', 'Far')			
Command Home	Value None		
# Home example InterfaceName.Set('Home', None)			
Command IrisMode	Value 'Auto'	Value 'Manual'	
# IrisMode example InterfaceName.Set('IrisMode', 'Auto')			
Command Mirror	Value 'Enable'	Value 'Disable'	
# Mirror example			

Global Scripter Module Communication Sheet

InterfaceName.Set('Mirror', 'Enable')			
Command MotionDetection	Value 'On'	Value 'Off'	
# MotionDetection example InterfaceName.Set('MotionDetection', 'On')			
Command PanandTilt	Value 'Up' 'Right' 'Down Left'	Value 'Down' 'Up Left' 'Down Right'	Value 'Left' 'Up Right' 'Stop'
Qualifier Key 'Pan Speed'	Qualifier Value '1' – '5'		
Qualifier Key 'Tilt Speed'	Qualifier Value '1' – '5'		
# PanandTilt example InterfaceName.Set('PanandTilt', 'Up', {'Pan Speed': '1', 'Tilt Speed': '1'})			
Command PowerLED	Value 'Enable'	Value 'Disable'	
# PowerLED example InterfaceName.Set('PowerLED', 'Enable')			
Command RecallPreset	Value '1' – '32'		
# RecallPreset example InterfaceName.Set('RecallPreset', '1')			
Command ShutterMode	Value 'Auto'	Value 'Manual'	
# ShutterMode example InterfaceName.Set('ShutterMode', 'Auto')			
Command WhiteBalanceMode	Value 'Auto' 'Outdoor 1' 'Manual'	Value 'Indoor 1' 'Outdoor 2'	Value 'Indoor 2' 'Hold'
# WhiteBalanceMode example InterfaceName.Set('WhiteBalanceMode', 'Auto')			
Command Zoom	Value 'Tele'	Value 'Wide'	Value 'Stop'
Qualifier Key 'Speed'	Qualifier Value '2' – '7'		
# Zoom example InterfaceName.Set('Zoom', 'Tele', {'Speed': '2'})			

Status Available: N/A

Network communication

When configuring the Ethernet module, be sure device settings match those of the Global Scripter ethernet interface

Port Type:	Ethernet
Default Port:	80
Logon Credentials Supported:	Yes
Multi-Connection Capabilities:	Undetermined
Port Changeability:	Yes

Ethernet Module Configuration Description

Please refer to user manual for settings and changes to the network communication

Notes for the Device