

This document provides additional assistance with wiring your Extron IPL PRO enabled product to your device. Different components may require a different wiring scheme than those listed below.

For complete operating instruction, refer to the user's manual for the specific Extron IPL PRO enabled product or the controlled device manufacturer supplied documentation.

Device Specifications:

Device Type: Audio Processor
Manufacturer: Ashly
Firmware Version: N/A
Model(s): nXp752, nXp754, nXp1502, nXp1504

Tested on the Following Software and Firmware Versions:

IP Link Pro Control Processor Firmware	Touch Link Panel Firmware	GS Version
2.06.0000-b010	2.01.0002-b005	1.4.0

Version History

Module Version	Date	Notes
1_0_0_0	6/30/2017	Initial Version

Module Notes

- Unidirectional variable must be set to 'True' if status is not required. Default value is 'False'. Example: InterfaceName.Unidirectional = 'True'
- connectionCounter variable must be set the number of queries that will be sent to the device before displaying 'Disconnected' if no response is received. Default value is 15. Example: InterfaceName.connectionCounter = 5
- MACAddress variable must be set accordingly. MAC Address format should of XX-XX-XX-XX-XX-XX
Example: InterfaceName.MACAddress = '00-05-A6-A9-2D-FA'
- Login credentials are required, devicePassword and deviceUsername must be set accordingly. Example:
InterfaceName.devicePassword = 'admin'
InterfaceName.deviceUsername = 'admin'
- devicePassword and deviceUsername must be set to 8 characters or less.

Control Commands, States, and Qualifiers:

InputMute	'On' 'Off'
['Channel']	'1' – '4'
InputVolume	-50 to 12 in steps of 1
['Channel']	'1' – '4'
OutputMute	'On' 'Off'
['Channel']	'1' – '4'
OutputVolume	-50 to 12 in steps of 1
['Channel']	'1' – '4'
PresetRecall	'1' – '35'
PresetSave	'1' – '35'

Status Available:

ConnectionStatus	'Connected' 'Disconnected'
InputMute	'On' 'Off'
['Channel']	'1' – '4'
InputVolume	-50 to 12 in steps of 1
['Channel']	'1' – '4'
OutputMute	'On' 'Off'
['Channel']	'1' – '4'
OutputVolume	-50 to 12 in steps of 1
['Channel']	'1' – '4'
PowerStatus	'On' 'Standby'

Network communication:

When configuring the Ethernet interface, be sure the device settings match that of the GS interface settings.

Port Type:	Ethernet
Default Listen Port:	3100
Logon Credentials Supported:	Yes
Default User Name:	admin
Multi-Connection Capabilities:	Undetermined
Port Changeability:	No

Ethernet Module Configuration Description:

Please refer to user manual for settings and changes to the network communication

Notes for the Device: