

This document provides additional assistance with wiring your Extron IPL PRO enabled product to your device. Different components may require a different wiring scheme than those listed below.

For complete operating instruction, refer to the user's manual for the specific Extron IPL PRO enabled product or the controlled device manufacturer supplied documentation.

Device Specifications:

Device Type: Controller
Manufacturer: Antrax
Firmware Version: v2.3.5
Model(s): Multibox - LAN

Tested on the Following Software and Firmware Versions:

IP Link Pro Control Processor Firmware	Touch Link Panel Firmware	GS Version
2.04.0000-b007	2.01.0001-b001	1.2.2

Version History

Module Version	Date	Notes
1_0_0_0	1/3/2017	Initial Version

Module Notes

- connectionCounter variable must be set the number of queries that will be sent to the device before displaying 'Disconnected' if no response is received. Default value is 15. Example:
InterfaceName.connectionCounter = 5
- For Ethernet support using HTTP protocol, HTTPClass must be used. Example: InterfaceName = ModuleName.HTTPClass ('192.168.254.254', 'admin', 'password', Model = 'ModelName')

Control Commands, States, and Qualifiers:

Power	'On'	'Off'
['Port']	'1' – '4'	

Status Available:

ConnectionStatus	'Connected'	'Disconnected'
Power	'On'	'Off'
['Port'] ¹	'1' – '4'	

¹ Not required for Update. Any Update will update the statuses of all ports.

Network communication:

When configuring the Ethernet interface, be sure the device settings match that of the GS interface settings.

Port Type: Ethernet

Default Port: 80

Logon Credentials Yes

Supported:

Multi-Connection Yes

Capabilities:

Port Changeability: Yes

Ethernet Module Configuration Description:

Please refer to user manual for settings and changes to the network communication

Notes for the Device: