

This document provides additional assistance with wiring your Extron IP Link Pro Control Processor to your device. Different components may require a different wiring scheme than those listed below.

For complete operating instructions, refer to the user's manual for the specific IP Link Pro Control Processor or the documentation supplied by the manufacturer of the controlled device.

For more information on using Global Scriptor Modules, refer to the "[Guide to Using Scriptor Modules](#)" document.

Device Specifications

Device Type: Video Processor
Manufacturer: Analog Way
Firmware Version: N/A
Model(s): NXT1604-4K

Tested on the Following Software and Firmware Versions

IP Link Pro Control Processor Firmware	Global Scriptor Version
2.06.0000-b010	1.4.1

Version History

Module Version	Date	Notes
1_0_0_1	9/5/2017	Updated status example.
1_0_0_0	8/10/2017	Initial Version

Module Notes

- Unidirectional variable must be set to 'True' if status is not required. Default value is 'False'.
Example: `InterfaceName.Unidirectional = 'True'`
- connectionCounter variable must be set to the number of queries that will be sent to the device before displaying 'Disconnected' if no response is received. Default value is 15.
Example: `InterfaceName.connectionCounter = 5`

Supported Classes and Examples

EthernetClass

```
InterfaceName = ModuleName.EthernetClass('192.168.254.254', 10600, Model='NXT1604-4K')
```

Set Commands

Format with Qualifier:

```
InterfaceName.Set(Command, Value, {'Qualifier Key': 'Qualifier Value'})
```

Format without Qualifier:

```
InterfaceName.Set(Command, Value)
```

Command PresetRecall	Value None
Qualifier Key 'Type'	Qualifier Value 'Program' Qualifier Value 'Preview'
Qualifier Key 'Origin'	Qualifier Value '1' – '144'
Qualifier Key 'Destination'	Qualifier Value '1' – '8'
# PresetRecall example InterfaceName.Set('PresetRecall', None, {'Type': 'Program', 'Origin': '1', 'Destination': '1'})	
Command Source	Value '1' – '8'
Qualifier Key 'Web RCS'	Qualifier Value '1' – '144'
Qualifier Key 'Type'	Qualifier Value 'Program' Qualifier Value 'Preview'
Qualifier Key 'Layer'	Qualifier Value 'A' Qualifier Value 'B' Qualifier Value 'C'
# Source example InterfaceName.Set('Source', '1', {'Web RCS': '1', 'Type': 'Program', 'Layer': 'A'})	
Command Take	Value None
Qualifier Key 'Web RCS'	Qualifier Value '1' – '144'
# Take example InterfaceName.Set('Take', None, {'Web RCS': '1'})	

Status Available

For all commands, call Update to receive the latest status. ConnectionStatus does not support the Update function and is triggered by the device providing a successful response to other Update function calls.

Format with Qualifier:

```
InterfaceName.Update(Command, {'Qualifier Key': 'Qualifier Value'})
Value = InterfaceName.ReadStatus(Command, {'Qualifier Key': 'Qualifier Value'})
InterfaceName.SubscribeStatus(Command, {'Qualifier Key': 'Qualifier Value'}, FeedbackHandler)
FeedbackHandler will be called only when the specified qualifier gets a new status.
```

Format without Qualifier:

```
InterfaceName.Update(Command)
Value = InterfaceName.ReadStatus(Command)
InterfaceName.SubscribeStatus(Command, None, FeedbackHandler)
FeedbackHandler will be called when any qualifier gets a new status.
```

Command	Value	Value
ConnectionStatus	'Connected'	'Disconnected'
# ConnectionStatus examples Value = InterfaceName.ReadStatus('ConnectionStatus') InterfaceName.SubscribeStatus('ConnectionStatus', None, FeedbackHandler)		
Command	Value	
DeviceType	'NeXtage 16 - 4K'	
# DeviceType examples InterfaceName.Update('DeviceType') Value = InterfaceName.ReadStatus('DeviceType') InterfaceName.SubscribeStatus('DeviceType', None, FeedbackHandler)		

Network communication

When configuring the Ethernet module, be sure device settings match those of the Global Scripter ethernet interface

Port Type:	Ethernet
Default Port:	10600
Logon Credentials Supported:	No
Multi-Connection	Yes
Capabilities:	
Port Changeability:	Yes

Ethernet Module Configuration Description

Please refer to user manual for settings and changes to the network communication

Notes for the Device

Appendix A. Set Commands

Preset Recall None Origin 1 Type Preview Destination 1	0PMmet\x0A0PMscf\x0A1PMprf\x0A1PMloa\x0A
Preset Recall None Origin 1 Type Preview Destination 8	0PMmet\x0A7PMscf\x0A1PMprf\x0A1PMloa\x0A
Preset Recall None Origin 1 Type Program Destination 1	0PMmet\x0A0PMscf\x0A0PMprf\x0A1PMloa\x0A
Preset Recall None Origin 1 Type Program Destination 8	0PMmet\x0A7PMscf\x0A0PMprf\x0A1PMloa\x0A
Preset Recall None Origin 144 Type Preview Destination 1	143PMmet\x0A0PMscf\x0A1PMprf\x0A1PMloa\x0A
Preset Recall None Origin 144 Type Preview Destination 8	143PMmet\x0A7PMscf\x0A1PMprf\x0A1PMloa\x0A
Preset Recall None Origin 144 Type Program Destination 1	143PMmet\x0A0PMscf\x0A0PMprf\x0A1PMloa\x0A
Preset Recall None Origin 144 Type Program Destination 8	143PMmet\x0A7PMscf\x0A0PMprf\x0A1PMloa\x0A
Source 1 Web RCS 1 Type Preview Layer A	0,1,0,1SPPEi\x0A
Source 1 Web RCS 1 Type Preview Layer B	0,1,1,1SPPEi\x0A
Source 1 Web RCS 1 Type Preview Layer C	0,1,2,1SPPEi\x0A
Source 1 Web RCS 1 Type Preview Layer D	0,1,3,1SPPEi\x0A
Source 1 Web RCS 1 Type Program Layer A	0,0,0,1SPPEi\x0A
Source 1 Web RCS 1 Type Program Layer B	0,0,1,1SPPEi\x0A
Source 1 Web RCS 1 Type Program Layer C	0,0,2,1SPPEi\x0A
Source 1 Web RCS 1 Type Program Layer D	0,0,3,1SPPEi\x0A
Source 1 Web RCS 144 Type Preview Layer A	143,1,0,1SPPEi\x0A
Source 1 Web RCS 144 Type Preview Layer B	143,1,1,1SPPEi\x0A
Source 1 Web RCS 144 Type Preview Layer C	143,1,2,1SPPEi\x0A
Source 1 Web RCS 144 Type Preview Layer D	143,1,3,1SPPEi\x0A
Source 1 Web RCS 144 Type Program Layer A	143,0,0,1SPPEi\x0A
Source 1 Web RCS 144 Type Program Layer B	143,0,1,1SPPEi\x0A
Source 1 Web RCS 144 Type Program Layer C	143,0,2,1SPPEi\x0A
Source 1 Web RCS 144 Type Program Layer D	143,0,3,1SPPEi\x0A
Source 8 Web RCS 1 Type Preview Layer A	0,1,0,8SPPEi\x0A
Source 8 Web RCS 1 Type Preview Layer B	0,1,1,8SPPEi\x0A
Source 8 Web RCS 1 Type Preview Layer C	0,1,2,8SPPEi\x0A
Source 8 Web RCS 1 Type Preview Layer D	0,1,3,8SPPEi\x0A
Source 8 Web RCS 1 Type Program Layer A	0,0,0,8SPPEi\x0A
Source 8 Web RCS 1 Type Program Layer B	0,0,1,8SPPEi\x0A
Source 8 Web RCS 1 Type Program Layer C	0,0,2,8SPPEi\x0A
Source 8 Web RCS 1 Type Program Layer D	0,0,3,8SPPEi\x0A
Source 8 Web RCS 144 Type Preview Layer A	143,1,0,8SPPEi\x0A
Source 8 Web RCS 144 Type Preview Layer B	143,1,1,8SPPEi\x0A
Source 8 Web RCS 144 Type Preview Layer C	143,1,2,8SPPEi\x0A
Source 8 Web RCS 144 Type Preview Layer D	143,1,3,8SPPEi\x0A
Source 8 Web RCS 144 Type Program Layer A	143,0,0,8SPPEi\x0A
Source 8 Web RCS 144 Type Program Layer B	143,0,1,8SPPEi\x0A
Source 8 Web RCS 144 Type Program Layer C	143,0,2,8SPPEi\x0A

Source 8 Web RCS 144 Type Program Layer D	143,0,3,8SPPEi\x0A
Take None Web RCS 1	0,1SPCtk\x0A
Take None Web RCS 144	143,1SPCtk\x0A

Appendix B. Query Commands

Device Type	?\x0A
-------------	-------