
This document provides additional assistance with wiring your Extron IP Link Pro Control Processor to your device. Different components may require a different wiring scheme than those listed below.

For complete operating instructions, refer to the user's manual for the specific IP Link Pro Control Processor or the documentation supplied by the manufacturer of the controlled device.

For more information on using Global Scriptor Modules, refer to the "[Guide to Using Scriptor Modules](#)" document.

Device Specifications

Device Type: Camera
Manufacturer: Axis
Firmware Version: N/A
Model(s): P5414-E, P5415-E

Tested on the Following Software and Firmware Versions

IP Link Pro Control Processor Firmware	Global Scriptor Version
3.04.0001-b002	2.3.1

Version History

Module Version	Date	Notes
1_0_2_0	10/7/2019	Initial Version

Module Notes

- Unidirectional variable must be set to 'True' if status is not required. Default value is 'False'.
Example: `InterfaceName.Unidirectional = 'True'`
- connectionCounter variable must be set to the number of queries that will be sent to the device before displaying 'Disconnected' if no response is received. Default value is 15.
Example: `InterfaceName.connectionCounter = 5`

Supported Class and Example

HTTPClass

```
InterfaceName = ModuleName.HTTPClass('192.168.254.254', 80, 'root', 'password', Model='P5414-E')
```

Control Commands

Format with Qualifier:

```
InterfaceName.Set(Command, Value, {'Qualifier Key': 'Qualifier Value'})
```

Format with Qualifier:

```
InterfaceName.Set(Command, Value)
```

Command	Value	Value	Value
AutoFocus	'On'	'Off'	
# AutoFocus example InterfaceName.Set('AutoFocus', 'On')			
Command	Value		
Focus	6603 to 9999 in steps of 1		
# Focus example InterfaceName.Set('Focus', 9999)			
Command	Value	Value	Value
PanTilt	'Up'	'Down'	'Left'
	'Right'	'Up-Left'	'Up-Right'
	'Down-Left'	'Down-Right'	'Stop'
	'Home'		
# PanTilt example InterfaceName.Set('PanTilt', 'Up')			
Command	Value		
PanTiltSpeed	'1' – '100'		
# PanTiltSpeed example InterfaceName.Set('PanTiltSpeed', '1')			
Command	Value		
PresetRecall	'1' – '100'		
# PresetRecall example InterfaceName.Set('PresetRecall', '1')			
Command	Value		
PresetSave	'1' – '100'		
# PresetSave example InterfaceName.Set('PresetSave', '1')			
Command	Value		
Zoom	1 to 10909 in steps of 1		
# Zoom example InterfaceName.Set('Zoom', 10909)			

Status Available

For all commands, call Update to receive the latest status. ConnectionStatus does not support the Update function. ConnectionStatus is triggered by the device providing a successful response to other Update function calls.

Format with Qualifier:

```
InterfaceName.Update(Command, {'Qualifier Key': 'Qualifier Value'})  
Value = InterfaceName.ReadStatus(Command, {'Qualifier Key': 'Qualifier Value'})  
InterfaceName.SubscribeStatus(Command, {'Qualifier Key': 'Qualifier Value'},  
FeedbackHandler)
```

FeedbackHandler will be called only when the specified qualifier gets a new status.

Format without Qualifier:

```
InterfaceName.Update(Command)  
Value = InterfaceName.ReadStatus(Command)  
InterfaceName.SubscribeStatus(Command, None, FeedbackHandler)  
FeedbackHandler will be called when any qualifier gets a new status.
```

Command AutoFocus	Value 'On'	Value 'Off'
# AutoFocus example InterfaceName.Update('AutoFocus') Value = InterfaceName.ReadStatus('AutoFocus') InterfaceName.SubscribeStatus('AutoFocus', None, FeedbackHandler)		
Command ConnectionStatus	Value 'Connected'	Value 'Disconnected'
# ConnectionStatus example Value = InterfaceName.ReadStatus('ConnectionStatus') InterfaceName.SubscribeStatus('ConnectionStatus', None, FeedbackHandler)		
Command Focus	Value 6603 to 9999 in steps of 1	
# Focus example InterfaceName.Update('Focus') Value = InterfaceName.ReadStatus('Focus') InterfaceName.SubscribeStatus('Focus', None, FeedbackHandler)		
Command IOPort	Value 'Active'	Value 'Inactive'
Qualifier Key 'Port'	Qualifier Value '1' – '4'	
# IOPort example InterfaceName.Update('IOPort', {'Port': '1'}) Value = InterfaceName.ReadStatus('IOPort', {'Port': '1'}) InterfaceName.SubscribeStatus('IOPort', None, FeedbackHandler)		
Command PanTiltSpeed	Value '1' – '100'	
# PanTiltSpeed example InterfaceName.Update('PanTiltSpeed') Value = InterfaceName.ReadStatus('PanTiltSpeed') InterfaceName.SubscribeStatus('PanTiltSpeed', None, FeedbackHandler)		
Command Zoom	Value 1 to 10909 in steps of 1	
# Zoom example Value = InterfaceName.ReadStatus('Zoom') InterfaceName.SubscribeStatus('Zoom', None, FeedbackHandler)		

Network communication

When configuring the Ethernet module, be sure device settings match those of the Global Scriptor ethernet interface.

Port Type: Ethernet

Default Port: 80

Logon Credentials Supported: Yes

Default Username: root

Default Password:

Multi-Connection Undetermined

Capabilities:

Port Changeability: Yes

Ethernet Module Configuration Description

Please refer to user manual for settings and changes to the network communication

Notes for the Device