

This document provides additional assistance with wiring your Extron IP Link Pro Control Processor to your device. Different components may require a different wiring scheme than those listed below.

For complete operating instructions, refer to the user's manual for the specific IP Link Pro Control Processor or the documentation supplied by the manufacturer of the controlled device.

For more information on using Global Scriptor Modules, refer to the "[Guide to Using Scriptor Modules](#)" document.

Device Specifications

Device Type: Camera
Manufacturer: Axis
Firmware Version: 5.75.1
Model(s): V5915, V5915 Basic Authentication

Tested on the Following Software and Firmware Versions

IP Link Pro Control Processor Firmware	Global Scriptor Version
2.08.0002-b001	1.4.2

Version History

Module Version	Date	Notes
1_3_1_0	8/21/2018	Added model: V5915 Basic Authentication
1_3_0_0	7/26/2018	Fixed Control and Status commands. Renamed the following command names: - Backlight Compensation to Backlight - Pan/Tilt to Pan Tilt - Pan/Tilt Speed to Pan Tilt Speed
1_2_1_0	4/17/2017	Updated to latest standard. Renamed Backlight to Backlight Compensation. Fixed Preset Save. Added Continuous Focus, Continuous Pan Tilt and Continuous Zoom commands. Removed Position Update command and added individual Update commands for each status.

1_1_0_0	7/8/2016	Initial Version
---------	----------	-----------------

Module Notes

- Unidirectional variable must be set to 'True' if status is not required. Default value is 'False'.
Example: `InterfaceName.Unidirectional = 'True'`
- connectionCounter variable must be set to the number of queries that will be sent to the device before displaying 'Disconnected' if no response is received. Default value is 15.
Example: `InterfaceName.connectionCounter = 5`
- If login credentials are required, devicePassword and deviceUsername must be set accordingly.
deviceUsername default value is root respectively.
Example: `InterfaceName.deviceUsername = 'root'`
`InterfaceName.devicePassword = 'password'`
- This module does not support HTTPS. Use the HTTP port when specifying the port to use.

Supported Classes and Examples

HTTPClass

```
InterfaceName = ModuleName.HTTPClass('192.168.254.254', 80, 'root', 'password', Model='V5915')  
InterfaceName = ModuleName.HTTPClass('192.168.254.254', 80, 'root', 'password', Model='V5915  
Basic Authentication')
```

Control Commands

Format with Qualifier:

```
InterfaceName.Set(Command, Value, {'Qualifier Key': 'Qualifier Value'})
```

Format without Qualifier:

```
InterfaceName.Set(Command, Value)
```

Command AutoFocus	Value 'On'	Value 'Off'	
# AutoFocus example InterfaceName.Set('AutoFocus', 'On')			
Command AutoIris	Value 'On'	Value 'Off'	
# AutoIris example InterfaceName.Set('AutoIris', 'On')			
Command Backlight	Value 'On'	Value 'Off'	
# Backlight example InterfaceName.Set('Backlight', 'On')			
Command Brightness	Value 1 to 9999 in steps of 1		
# Brightness example InterfaceName.Set('Brightness', 9999)			
Command ContinuousFocus	Value 'Far'	Value 'Near'	Value 'Stop'
Qualifier Key 'Speed'	Qualifier Value '1' – '100'		
# ContinuousFocus example InterfaceName.Set('ContinuousFocus', 'Far', {'Speed': '1'})			
Command ContinuousPanTilt	Value 'Up' 'Right' 'Down-Left'	Value 'Down' 'Up-Left' 'Down-Right'	Value 'Left' 'Up-Right' 'Stop'
Qualifier Key 'Speed'	Qualifier Value '1' – '100'		
# ContinuousPanTilt example InterfaceName.Set('ContinuousPanTilt', 'Up', {'Speed': '1'})			
Command ContinuousZoom	Value 'Tele'	Value 'Wide'	Value 'Stop'
Qualifier Key 'Speed'	Qualifier Value '1' – '100'		

# ContinuousZoom example InterfaceName.Set('ContinuousZoom', 'Tele', {'Speed': '1'})			
Command Focus	Value 770 to 9999 in steps of 1		
# Focus example InterfaceName.Set('Focus', 9999)			
Command IRCutFilter	Value 'On'	Value 'Off'	Value 'Auto'
# IRCutFilter example InterfaceName.Set('IRCutFilter', 'On')			
Command Iris	Value 1 to 9999 in steps of 1		
# Iris example InterfaceName.Set('Iris', 9999)			
Command PanTilt	Value 'Up' 'Right' 'Down-Left' 'Home'	Value 'Down' 'Up-Left' 'Down-Right'	Value 'Left' 'Up-Right' 'Stop'
# PanTilt example InterfaceName.Set('PanTilt', 'Up')			
Command PanTiltSpeed	Value '1' – '100'		
# PanTiltSpeed example InterfaceName.Set('PanTiltSpeed', '1')			
Command PresetRecall	Value '1' – '256'		
# PresetRecall example InterfaceName.Set('PresetRecall', '1')			
Command PresetSave	Value '1' – '256'		
# PresetSave example InterfaceName.Set('PresetSave', '1')			
Command Zoom	Value 1 to 9999 in steps of 1		
# Zoom example InterfaceName.Set('Zoom', 9999)			

Status Available

For all commands, call Update to receive the latest status. ConnectionStatus, Iris do not support the Update function and is triggered by the device providing a successful response to other Update function calls.

Format with Qualifier:

```
InterfaceName.Update(Command, {'Qualifier Key': 'Qualifier Value'})
Value = InterfaceName.ReadStatus(Command, {'Qualifier Key': 'Qualifier Value'})
InterfaceName.SubscribeStatus(Command, {'Qualifier Key': 'Qualifier Value'}, FeedbackHandler)
FeedbackHandler will be called only when the specified qualifier gets a new status.
```

Format without Qualifier:

```
InterfaceName.Update(Command)
Value = InterfaceName.ReadStatus(Command)
InterfaceName.SubscribeStatus(Command, None, FeedbackHandler)
FeedbackHandler will be called when any qualifier gets a new status.
```

Command	Value	Value
AutoFocus ¹	'On'	'Off'
# AutoFocus examples InterfaceName.Update('AutoFocus') Value = InterfaceName.ReadStatus('AutoFocus') InterfaceName.SubscribeStatus('AutoFocus', None, FeedbackHandler)		
Command	Value	Value
AutoIris ¹	'On'	'Off'
# AutoIris examples InterfaceName.Update('AutoIris') Value = InterfaceName.ReadStatus('AutoIris') InterfaceName.SubscribeStatus('AutoIris', None, FeedbackHandler)		
Command	Value	
Brightness ¹	1 to 9999 in steps of 1	
# Brightness examples InterfaceName.Update('Brightness') Value = InterfaceName.ReadStatus('Brightness') InterfaceName.SubscribeStatus('Brightness', None, FeedbackHandler)		
Command	Value	Value
ConnectionStatus	'Connected'	'Disconnected'
# ConnectionStatus examples Value = InterfaceName.ReadStatus('ConnectionStatus') InterfaceName.SubscribeStatus('ConnectionStatus', None, FeedbackHandler)		
Command	Value	
Focus ¹	770 to 9999 in steps of 1	
# Focus examples InterfaceName.Update('Focus') Value = InterfaceName.ReadStatus('Focus') InterfaceName.SubscribeStatus('Focus', None, FeedbackHandler)		

Command	Value
PanTiltSpeed	'1' – '100'
<pre># PanTiltSpeed examples InterfaceName.Update('PanTiltSpeed') Value = InterfaceName.ReadStatus('PanTiltSpeed') InterfaceName.SubscribeStatus('PanTiltSpeed', None, FeedbackHandler)</pre>	
Zoom ¹	1 to 9999 in steps of 1
<pre># Zoom examples InterfaceName.Update('Zoom') Value = InterfaceName.ReadStatus('Zoom') InterfaceName.SubscribeStatus('Zoom', None, FeedbackHandler)</pre>	

¹ These commands send the same query to the device and will update the status of these commands.

Network communication

When configuring the Ethernet module, be sure device settings match those of the Global Scripter ethernet interface

Port Type:	Ethernet
Default Port:	80
Logon Credentials Supported:	Yes
Default Username:	root
Multi-Connection	Undetermined
Capabilities:	
Port Changeability:	Yes

Ethernet Module Configuration Description

Please refer to user manual for settings and changes to the network communication

Notes for the Device