

This document provides additional assistance with wiring your Extron IP Link Pro Control Processor to your device. Different components may require a different wiring scheme than those listed below.

For complete operating instructions, refer to the user's manual for the specific IP Link Pro Control Processor or the documentation supplied by the manufacturer of the controlled device.

For more information on using Global Scriptor Modules, refer to the "[Guide to Using Scriptor Modules](#)" document.

Device Specifications

Device Type: Camera
Manufacturer: Axis
Firmware Version: N/A
Model(s): V5925

Tested on the Following Software and Firmware Versions

IP Link Pro Control Processor Firmware	Global Scriptor Version
3.15.0000-b004	2.14.0

Version History

Module Version	Date	Notes
1_0_0_0	1/11/2022	Initial Version

Module Notes

- Unidirectional variable must be set to 'True' if status is not required. Default value is 'False'.
Example: `InterfaceName.Unidirectional = 'True'`
- connectionCounter variable must be set to the number of queries that will be sent to the device before displaying 'Disconnected' if no response is received. Default value is 15.
Example: `InterfaceName.connectionCounter = 5`

Supported Class and Example

HTTPClass

```
InterfaceName = ModuleName.HTTPClass('192.168.254.254', 80, 'root', 'password', Model='V5925')
```

Control Commands

Format with Qualifier:

```
InterfaceName.Set(Command, Value, {'Qualifier Key': 'Qualifier Value'})
```

Format without Qualifier:

```
InterfaceName.Set(Command, Value)
```

Command	Value	Value	Value
AutoFocus	'On'	'Off'	
# AutoFocus example InterfaceName.Set('AutoFocus', 'On')			
Command	Value	Value	
AutoIris	'On'	'Off'	
# AutoIris example InterfaceName.Set('AutoIris', 'On')			
Command	Value	Value	
Backlight	'On'	'Off'	
# Backlight example InterfaceName.Set('Backlight', 'On')			
Command	Value		
Brightness ^{1,4}	1 to 9999 in steps of 1		
# Brightness example InterfaceName.Set('Brightness', 9999)			
Command	Value	Value	Value
ContinuousFocus	'Far'	'Near'	'Stop'
Qualifier Key 'Speed'	Qualifier Value '1' – '100'		
# ContinuousFocus example InterfaceName.Set('ContinuousFocus', 'Far', {'Speed': '1'})			
Command	Value	Value	Value
ContinuousPanTilt	'Up'	'Down'	'Left'
	'Right'	'Up-Left'	'Up-Right'
	'Down-Left'	'Down-Right'	'Stop'
Qualifier Key 'Speed'	Qualifier Value '1' – '100'		
# ContinuousPanTilt example InterfaceName.Set('ContinuousPanTilt', 'Up', {'Speed': '1'})			
Command	Value	Value	Value
ContinuousZoom	'Tele'	'Wide'	'Stop'
Qualifier Key 'Speed'	Qualifier Value '1' – '100'		
# ContinuousZoom example InterfaceName.Set('ContinuousZoom', 'Tele', {'Speed': '1'})			
Command	Value		
Focus ^{2,4}	770 to 9999 in steps of 1		
# Focus example InterfaceName.Set('Focus', 9999)			
Command	Value	Value	Value
IRCutFilter	'On'	'Off'	'Auto'
# IRCutFilter example InterfaceName.Set('IRCutFilter', 'On')			

Command Iris ^{3, 4}	Value 1 to 9999 in steps of 1		
# Iris example InterfaceName.Set('Iris', 9999)			
Command PanTilt	Value 'Up' 'Right' 'Down-Left' 'Home'	Value 'Down' 'Up-Left' 'Down-Right'	Value 'Left' 'Up-Right' 'Stop'
# PanTilt example InterfaceName.Set('PanTilt', 'Up')			
Command PanTiltSpeed	Value '1' – '100'		
# PanTiltSpeed example InterfaceName.Set('PanTiltSpeed', '1')			
Command PresetRecall	Value '1' – '256'		
# PresetRecall example InterfaceName.Set('PresetRecall', '1')			
Command PresetSave	Value '1' – '256'		
# PresetSave example InterfaceName.Set('PresetSave', '1')			
Command Zoom	Value 1 to 9999 in steps of 1		
# Zoom example InterfaceName.Set('Zoom', 9999)			

¹ The Brightness command will work only when Auto Iris is on.

² If Auto Focus is on, using the Focus command will turn Auto Focus off and will reset the value of Focus back to the value of the last Focus command sent.

³ If Auto Iris is on, using the Iris command will turn Auto Iris off and will reset the value of Iris back to the value of the last Iris command sent.

⁴ There may be no actual change to the device while incrementing/decrementing these values until the values reach a certain threshold. Because of this, along with the long range of values, a sensitivity of over 100 is recommended.

Status Available

For all commands, call Update to receive the latest status. ConnectionStatus, AutoIris, Brightness, Focus, and Zoom do not support the Update function. ConnectionStatus is triggered by the device providing a successful response to other Update function calls.

Format with Qualifier:

```
InterfaceName.Update(Command, {'Qualifier Key': 'Qualifier Value'})  
Value = InterfaceName.ReadStatus(Command, {'Qualifier Key': 'Qualifier Value'})  
InterfaceName.SubscribeStatus(Command, {'Qualifier Key': 'Qualifier Value'},  
FeedbackHandler)
```

FeedbackHandler will be called only when the specified qualifier gets a new status.

Format without Qualifier:

```
InterfaceName.Update(Command)  
Value = InterfaceName.ReadStatus(Command)  
InterfaceName.SubscribeStatus(Command, None, FeedbackHandler)  
FeedbackHandler will be called when any qualifier gets a new status.
```

Command	Value	Value
AutoFocus	'On'	'Off'
# AutoFocus example InterfaceName.Update('AutoFocus') Value = InterfaceName.ReadStatus('AutoFocus') InterfaceName.SubscribeStatus('AutoFocus', None, FeedbackHandler)		
Command	Value	Value
AutoIris	'On'	'Off'
# AutoIris example Value = InterfaceName.ReadStatus('AutoIris') InterfaceName.SubscribeStatus('AutoIris', None, FeedbackHandler)		
Command	Value	
Brightness ¹	1 to 9999 in steps of 1	
# Brightness example Value = InterfaceName.ReadStatus('Brightness') InterfaceName.SubscribeStatus('Brightness', None, FeedbackHandler)		
Command	Value	Value
ConnectionStatus	'Connected'	'Disconnected'
# ConnectionStatus example Value = InterfaceName.ReadStatus('ConnectionStatus') InterfaceName.SubscribeStatus('ConnectionStatus', None, FeedbackHandler)		
Command	Value	
Focus ²	770 to 9999 in steps of 1	
# Focus example Value = InterfaceName.ReadStatus('Focus') InterfaceName.SubscribeStatus('Focus', None, FeedbackHandler)		
Command	Value	
Iris ³	1 to 9999 in steps of 1	
# Iris example Value = InterfaceName.ReadStatus('Iris') InterfaceName.SubscribeStatus('Iris', None, FeedbackHandler)		
Command	Value	
PanTiltSpeed	'1' – '100'	
# PanTiltSpeed example InterfaceName.Update('PanTiltSpeed') Value = InterfaceName.ReadStatus('PanTiltSpeed') InterfaceName.SubscribeStatus('PanTiltSpeed', None, FeedbackHandler)		

Command	Value
Zoom	1 to 9999 in steps of 1
<pre># Zoom example Value = InterfaceName.ReadStatus('Zoom') InterfaceName.SubscribeStatus('Zoom', None, FeedbackHandler)</pre>	

¹ Status will update only when Auto Iris is on and the Brightness command has been used.

² Status will not update if Auto Focus is on.

³ Status will not update if Auto Iris is on.

Network communication

When configuring the Ethernet module, be sure device settings match those of the Global Scriptor ethernet interface.

Port Type: Ethernet (HTTP)

Default Port: 80

Logon Credentials Supported: Yes

Default Username: root

Default Password:

Multi-Connection Yes

Capabilities:

Port Changeability: Yes

Ethernet Module Configuration Description

Please refer to user manual for settings and changes to the network communication

Notes for the Device