

This document provides additional assistance with wiring your Extron IPL PRO enabled product to your device. Different components may require a different wiring scheme than those listed below.

For complete operating instruction, refer to the user's manual for the specific Extron IPL PRO enabled product or the controlled device manufacturer supplied documentation.

Device Specifications:

Device Type: Collaboration Systems
Manufacturer: Biamp
Firmware Version: N/A
Model(s): Devio CR-1

Tested on the Following Software and Firmware Versions:

IP Link Pro Control Processor Firmware	Touch Link Panel Firmware	GS Version
2.04.0000-b007	2.01.0001-b001	1.2.3

Version History

Module Version	Date	Notes
1_0_0_0	2/20/2017	Initial Version

Module Notes

- Unidirectional variable must be set to 'True' if status is not required. Default value is 'False'. Example:
InterfaceName.Unidirectional = 'True'
- connectionCounter variable must be set the number of queries that will be sent to the device before displaying 'Disconnected' if no response is received. Default value is 15. Example:
InterfaceName.connectionCounter = 5

Control Commands, States, and Qualifiers:

EnableHeadset	'True'	'False'
EnableUSBVideo	'True'	'False'
MasterMicrophoneMute	'True'	'False'

Status Available:

CallInProgress	'True'	'False'
ConnectionStatus	'Connected'	'Disconnected'
EnableHeadset	'True'	'False'
EnableUSBVideo	'True'	'False'
FarEndAudioPresent	'True'	'False'
LineFault	'True'	'False'
MasterMicrophoneMute	'True'	'False'
MicrophoneAudioPresent	'True'	'False'

Network communication:

When configuring the Ethernet interface, be sure the device settings match that of the GS interface settings.

Port Type: Ethernet

Default Port: 4030

Logon Credentials No

Supported:

Multi-Connection No

Capabilities:

Port Changeability: No

Ethernet Module Configuration Description:

Please refer to user manual for settings and changes to the network communication

Notes for the Device:

Appendix A. Set Commands

Enable Headset False	DEVICE set enableHeadset false\x0D
Enable Headset True	DEVICE set enableHeadset true\x0D
Enable USB Video False	DEVICE set enableUsbVideo false\x0D
Enable USB Video True	DEVICE set enableUsbVideo true\x0D
Master Microphone Mute False	DEVICE set masterMicMute false\x0D
Master Microphone Mute True	DEVICE set masterMicMute true\x0D

Appendix B. Query Commands

Enable Headset	DEVICE get enableHeadset\x0D
Enable USB Video	DEVICE get enableUsbVideo\x0D
Line Fault	DEVICE get lineFault\x0D
Master Microphone Mute	DEVICE get masterMicMute\x0D
Microphone Audio Present	DEVICE get micAudioPresent\x0D