
This document provides additional assistance with wiring your Extron IP Link Pro Control Processor to your device. Different components may require a different wiring scheme than those listed below.

For complete operating instructions, refer to the user's manual for the specific IP Link Pro Control Processor or the documentation supplied by the manufacturer of the controlled device.

For more information on using Global Scriptor Modules, refer to the "[Guide to Using Scriptor Modules](#)" document.

Device Specifications

Device Type: Display
Manufacturer: Blackmagic Design
Firmware Version: N/A
Model(s): SmartView 4K, SmartScope Duo 4K

Tested on the Following Software and Firmware Versions

IP Link Pro Control Processor Firmware	Global Scriptor Version
2.06.0002-b002	1.4.2

Version History

Module Version	Date	Notes
1_0_0_0	2/7/2018	Initial Version

Module Notes

Supported Classes and Examples

EthernetClass

InterfaceName = ModuleName.EthernetClass('192.168.254.254', 9992, Model='SmartView 4K')

Set Commands

Format with Qualifier:

```
InterfaceName.Set(Command, Value, {'Qualifier Key': 'Qualifier Value'})
```

Format without Qualifier:

```
InterfaceName.Set(Command, Value)
```

Command AspectRatio ^{1,4}	Value 'SD in 16:9'	Value 'SD in 4:3'	
Qualifier Key 'Monitor'	Qualifier Value 'A'	Qualifier Value 'B'	
# AspectRatio example InterfaceName.Set('AspectRatio', 'SD in 16:9', {'Monitor': 'A'})			
Command AudioChannel	Value 'Channels 1 and 2' 'Channels 7 and 8' 'Channels 13 and 14'	Value 'Channels 3 and 4' 'Channels 9 and 10' 'Channels 15 and 16'	Value 'Channels 5 and 6' 'Channels 11 and 12'
Qualifier Key 'Monitor'	Qualifier Value 'A'	Qualifier Value 'B'	
# AudioChannel example InterfaceName.Set('AudioChannel', 'Channels 1 and 2', {'Monitor': 'A'})			
Command LoadLUT ^{1,3}	Value '1'	Value '2'	Value 'Disable'
Qualifier Key 'Monitor'	Qualifier Value 'A'	Qualifier Value 'B'	
# LoadLUT example InterfaceName.Set('LoadLUT', '1', {'Monitor': 'A'})			
Command ScopeSelect ^{1,2}	Value 'Audio Dbfs' 'Parade RGB' 'Vector 100'	Value 'Audio Dbvu' 'Parade YUV' 'Vector 75'	Value 'Histogram' 'Picture (Video Monitor)' 'Waveform Luma'
Qualifier Key 'Monitor'	Qualifier Value 'A'	Qualifier Value 'B'	
# ScopeSelect example InterfaceName.Set('ScopeSelect', 'Audio Dbfs', {'Monitor': 'A'})			

¹ Only supported for SmartScope Duo 4K

² Only supported for SmartView 4K

³ When using this command for the SmartScope Duo 4K, the Scope Select command must be set first. If using the Aspect Ratio command, Scope Select should be set to Picture (Video Monitor). If using Audio Channel command, Scope Select should be set to the correct audio state.

Status Available N/A

Network communication

When configuring the Ethernet module, be sure device settings match those of the Global Scripter ethernet interface

Port Type:	Ethernet
Default Port:	9992
Logon Credentials Supported:	No
Multi-Connection	Undetermined
Capabilities:	
Port Changeability:	No

Ethernet Module Configuration Description

Please refer to user manual for settings and changes to the network communication

Notes for the Device

Appendix A. Set Commands

Aspect Ratio SD in 16:9 Monitor A	MONITOR A:\x0DWidescreenSD: ON\x0D
Aspect Ratio SD in 4:3 Monitor A	MONITOR A:\x0DWidescreenSD: OFF\x0D
Aspect Ratio SD in 16:9 Monitor B	MONITOR B:\x0DWidescreenSD: ON\x0D
Aspect Ratio SD in 4:3 Monitor B	MONITOR B:\x0DWidescreenSD: OFF\x0D
Audio Channel Channels 1 and 2 Monitor A	MONITOR A:\x0DAudioChannel: 0\x0D
Audio Channel Channels 11 and 12 Monitor A	MONITOR A:\x0DAudioChannel: 5\x0D
Audio Channel Channels 13 and 14 Monitor A	MONITOR A:\x0DAudioChannel: 6\x0D
Audio Channel Channels 15 and 16 Monitor A	MONITOR A:\x0DAudioChannel: 7\x0D
Audio Channel Channels 3 and 4 Monitor A	MONITOR A:\x0DAudioChannel: 1\x0D
Audio Channel Channels 5 and 6 Monitor A	MONITOR A:\x0DAudioChannel: 2\x0D
Audio Channel Channels 7 and 8 Monitor A	MONITOR A:\x0DAudioChannel: 3\x0D
Audio Channel Channels 9 and 10 Monitor A	MONITOR A:\x0DAudioChannel: 4\x0D
Audio Channel Channels 1 and 2 Monitor B	MONITOR B:\x0DAudioChannel: 0\x0D
Audio Channel Channels 11 and 12 Monitor B	MONITOR B:\x0DAudioChannel: 5\x0D
Audio Channel Channels 13 and 14 Monitor B	MONITOR B:\x0DAudioChannel: 6\x0D
Audio Channel Channels 15 and 16 Monitor B	MONITOR B:\x0DAudioChannel: 7\x0D
Audio Channel Channels 3 and 4 Monitor B	MONITOR B:\x0DAudioChannel: 1\x0D
Audio Channel Channels 5 and 6 Monitor B	MONITOR B:\x0DAudioChannel: 2\x0D
Audio Channel Channels 7 and 8 Monitor B	MONITOR B:\x0DAudioChannel: 3\x0D
Audio Channel Channels 9 and 10 Monitor B	MONITOR B:\x0DAudioChannel: 4\x0D
Load LUT 1 Monitor A	MONITOR A:\x0DLUT: 0\x0D
Load LUT 2 Monitor A	MONITOR A:\x0DLUT: 1\x0D
Load LUT Disable Monitor A	MONITOR A:\x0DLUT: NONE\x0D
Load LUT 1 Monitor B	MONITOR B:\x0DLUT: 0\x0D
Load LUT 2 Monitor B	MONITOR B:\x0DLUT: 1\x0D
Load LUT Disable Monitor B	MONITOR B:\x0DLUT: NONE\x0D
Scope Select Audio Dbfs Monitor A	MONITOR A:\x0DScopeMode: AudioDbfs\x0D
Scope Select Audio Dbvu Monitor A	MONITOR A:\x0DScopeMode: AudioDbvu\x0D
Scope Select Histogram Monitor A	MONITOR A:\x0DScopeMode: Histogram\x0D
Scope Select Parade RGB Monitor A	MONITOR A:\x0DScopeMode: ParadeRGB\x0D
Scope Select Parade YUV Monitor A	MONITOR A:\x0DScopeMode: ParadeYUV\x0D
Scope Select Picture (Video Monitor) Monitor A	MONITOR A:\x0DScopeMode: Picture\x0D
Scope Select Vector 100 Monitor A	MONITOR A:\x0DScopeMode: Vector100\x0D
Scope Select Vector 75 Monitor A	MONITOR A:\x0DScopeMode: Vector75\x0D
Scope Select Waveform Luma Monitor A	MONITOR A:\x0DScopeMode: WaveformLuma\x0D
Scope Select Audio Dbfs Monitor B	MONITOR B:\x0DScopeMode: AudioDbfs\x0D

Global Scripter Module Communication Sheet

Scope Select Audio Dbvu Monitor B	MONITOR B:\x0DScopeMode: AudioDbvu\x0D
Scope Select Histogram Monitor B	MONITOR B:\x0DScopeMode: Histogram\x0D
Scope Select Parade RGB Monitor B	MONITOR B:\x0DScopeMode: ParadeRGB\x0D
Scope Select Parade YUV Monitor B	MONITOR B:\x0DScopeMode: ParadeYUV\x0D
Scope Select Picture (Video Monitor) Monitor B	MONITOR B:\x0DScopeMode: Picture\x0D
Scope Select Vector 100 Monitor B	MONITOR B:\x0DScopeMode: Vector100\x0D
Scope Select Vector 75 Monitor B	MONITOR B:\x0DScopeMode: Vector75\x0D
Scope Select Waveform Luma Monitor B	MONITOR B:\x0DScopeMode: WaveformLuma\x0D