
This document provides additional assistance with wiring your Extron IP Link Pro Control Processor to your device. Different components may require a different wiring scheme than those listed below.

For complete operating instructions, refer to the user's manual for the specific IP Link Pro Control Processor or the documentation supplied by the manufacturer of the controlled device.

For more information on using Global Scriptor Modules, refer to the "[Guide to Using Scriptor Modules](#)" document.

Device Specifications

Device Type: Media Player
Manufacturer: BlueSound
Firmware Version: N/A
Model(s): B100S

Tested on the Following Software and Firmware Versions

IP Link Pro Control Processor Firmware	Global Scriptor Version
3.04.0001-b002	2.3.1

Version History

Module Version	Date	Notes
1_0_0_0	11/8/2019	Initial Version

Module Notes

- Unidirectional variable must be set to 'True' if status is not required. Default value is 'False'.
Example: `InterfaceName.Unidirectional = 'True'`
- connectionCounter variable must be set to the number of queries that will be sent to the device before displaying 'Disconnected' if no response is received. Default value is 15.
Example: `InterfaceName.connectionCounter = 5`

Supported Class and Example

HTTPClass

```
InterfaceName = ModuleName.HTTPClass('192.168.254.254', 11000, 'admin', 'password',  
Model='B100S')
```

Control Commands

Format with Qualifier:

```
InterfaceName.Set(Command, Value, {'Qualifier Key': 'Qualifier Value'})
```

Format with Qualifier:

```
InterfaceName.Set(Command, Value)
```

Command Mute	Value 'On'	Value 'Off'	
# Mute example InterfaceName.Set('Mute', 'On')			
Command Playback	Value 'Play' 'Skip'	Value 'Pause' 'Back'	Value 'Stop'
# Playback example InterfaceName.Set('Playback', 'Play')			
Command Preset	Value 1 – 999		
# Preset example InterfaceName.Set('Preset', 999)			
Command Repeat	Value 'Current Queue'	Value 'Current Track'	Value 'Off'
# Repeat example InterfaceName.Set('Repeat', 'Current Queue')			
Command Shuffle	Value 'On'	Value 'Off'	
# Shuffle example InterfaceName.Set('Shuffle', 'On')			
Command Volume	Value 0 to 100 in steps of 1		
# Volume example InterfaceName.Set('Volume', 100)			

Status Available

For all commands, call Update to receive the latest status. ConnectionStatus, ArtistName, CurrentTrackLength, CurrentTrackTime, CurrentTrackTitle, Mute, Playback, Repeat, Shuffle, and Volume do not support the Update function. ConnectionStatus is triggered by the device providing a successful response to other Update function calls.

Format with Qualifier:

```
InterfaceName.Update(Command, {'Qualifier Key': 'Qualifier Value'})
Value = InterfaceName.ReadStatus(Command, {'Qualifier Key': 'Qualifier Value'})
InterfaceName.SubscribeStatus(Command, {'Qualifier Key': 'Qualifier Value'},
```

FeedbackHandler)

FeedbackHandler will be called only when the specified qualifier gets a new status.

Format without Qualifier:

```
InterfaceName.Update(Command)
Value = InterfaceName.ReadStatus(Command)
InterfaceName.SubscribeStatus(Command, None, FeedbackHandler)
FeedbackHandler will be called when any qualifier gets a new status.
```

Command	Value	
AlbumName	'String'	
# AlbumName example InterfaceName.Update('AlbumName') Value = InterfaceName.ReadStatus('AlbumName') InterfaceName.SubscribeStatus('AlbumName', None, FeedbackHandler)		
Command	Value	
ArtistName	'String'	
# ArtistName example InterfaceName.Update('ArtistName') Value = InterfaceName.ReadStatus('ArtistName') InterfaceName.SubscribeStatus('ArtistName', None, FeedbackHandler)		
Command	Value	Value
ConnectionStatus	'Connected'	'Disconnected'
# ConnectionStatus example InterfaceName.Update('ConnectionStatus') Value = InterfaceName.ReadStatus('ConnectionStatus') InterfaceName.SubscribeStatus('ConnectionStatus', None, FeedbackHandler)		
Command	Value	
CurrentTrackLength	'String'	
# CurrentTrackLength example InterfaceName.Update('CurrentTrackLength') Value = InterfaceName.ReadStatus('CurrentTrackLength') InterfaceName.SubscribeStatus('CurrentTrackLength', None, FeedbackHandler)		
Command	Value	
CurrentTrackTime	'String'	
# CurrentTrackTime example InterfaceName.Update('CurrentTrackTime') Value = InterfaceName.ReadStatus('CurrentTrackTime') InterfaceName.SubscribeStatus('CurrentTrackTime', None, FeedbackHandler)		
Command	Value	
CurrentTrackTitle	'String'	
Qualifier Key	Qualifier Value	
Number	'1' – '3'	
# CurrentTrackTitle example InterfaceName.Update('CurrentTrackTitle', {'Number': '1'}) Value = InterfaceName.ReadStatus('CurrentTrackTitle', {'Number': '1'})		

Global Scripter Module Communication Sheet

InterfaceName.SubscribeStatus('CurrentTrackTitle', None, FeedbackHandler)			
Command Mute	Value 'On'	Value 'Off'	
# Mute example InterfaceName.Update('Mute') Value = InterfaceName.ReadStatus('Mute') InterfaceName.SubscribeStatus('Mute', None, FeedbackHandler)			
Command Playback	Value 'Play' 'Skip' 'Connecting'	Value 'Pause' 'Back' 'Other'	Value 'Stop' 'Streaming'
# Playback example InterfaceName.Update('Playback') Value = InterfaceName.ReadStatus('Playback') InterfaceName.SubscribeStatus('Playback', None, FeedbackHandler)			
Command Repeat	Value 'Current Queue'	Value 'Current Track'	Value 'Off'
# Repeat example InterfaceName.Update('Repeat') Value = InterfaceName.ReadStatus('Repeat') InterfaceName.SubscribeStatus('Repeat', None, FeedbackHandler)			
Command Shuffle	Value 'On'	Value 'Off'	
# Shuffle example InterfaceName.Update('Shuffle') Value = InterfaceName.ReadStatus('Shuffle') InterfaceName.SubscribeStatus('Shuffle', None, FeedbackHandler)			
Command Volume	Value 0 to 100 in steps of 1		
# Volume example InterfaceName.Update('Volume') Value = InterfaceName.ReadStatus('Volume') InterfaceName.SubscribeStatus('Volume', None, FeedbackHandler)			

Network communication

When configuring the Ethernet module, be sure device settings match those of the Global Scriptor ethernet interface.

Port Type:	Ethernet
Default Port:	11000
Logon Credentials Supported:	No
Multi-Connection Capabilities:	Undetermined
Port Changeability:	Yes

Ethernet Module Configuration Description

Please refer to user manual for settings and changes to the network communication

Notes for the Device