

This document provides additional assistance with wiring your Extron IP Link Pro Control Processor to your device. Different components may require a different wiring scheme than those listed below.

For complete operating instructions, refer to the user's manual for the specific IP Link Pro Control Processor or the documentation supplied by the manufacturer of the controlled device.

For more information on using Global Scriptor Modules, refer to the "[Guide to Using Scriptor Modules](#)" document.

Device Specifications

Device Type: Other
Manufacturer: Broadspace
Firmware Version: N/A
Model(s): F1PC-C

Tested on the Following Software and Firmware Versions

IP Link Pro Control Processor Firmware	Global Scriptor Version
3.04.0001-b002	2.3.1

Version History

Module Version	Date	Notes
1_0_0_0	12/5/2019	Initial Version

Module Notes

- All statuses are based on the unsolicited response from the device.

Supported Class and Example

EthernetClass
<code>InterfaceName = ModuleName.EthernetClass('192.168.254.254', 23, Model='F1PC-C')</code>

Status Available

Update commands are not supported on the API. All statuses from the device are unsolicited.

Format with Qualifier:

```
InterfaceName.Update(Command, {'Qualifier Key': 'Qualifier Value'})
Value = InterfaceName.ReadStatus(Command, {'Qualifier Key': 'Qualifier Value'})
InterfaceName.SubscribeStatus(Command, {'Qualifier Key': 'Qualifier Value'},
```

FeedbackHandler)

FeedbackHandler will be called only when the specified qualifier gets a new status.

Format without Qualifier:

```
InterfaceName.Update(Command)
Value = InterfaceName.ReadStatus(Command)
InterfaceName.SubscribeStatus(Command, None, FeedbackHandler)
FeedbackHandler will be called when any qualifier gets a new status.
```

Command	Value
CO2	Number in units of ppm
# CO2 example Value = InterfaceName.ReadStatus('CO2') InterfaceName.SubscribeStatus('CO2', None, FeedbackHandler)	
Command	Value
Humidity	Number in units of %
# Humidity example Value = InterfaceName.ReadStatus('Humidity') InterfaceName.SubscribeStatus('Humidity', None, FeedbackHandler)	
Command	Value
PM25	Number in units of µg/m2
# PM25 example Value = InterfaceName.ReadStatus('PM25') InterfaceName.SubscribeStatus('PM25', None, FeedbackHandler)	
Command	Value
Temperature	Number in units of °C
# Temperature example Value = InterfaceName.ReadStatus('Temperature') InterfaceName.SubscribeStatus('Temperature', None, FeedbackHandler)	

Network communication

When configuring the Ethernet module, be sure device settings match those of the Global Scriptor ethernet interface.

Port Type:	Ethernet
Default Port:	23
Logon Credentials	No
Supported:	
Multi-Connection	Undetermined
Capabilities:	
Port Changeability:	Yes

Ethernet Module Configuration Description

Please refer to user manual for settings and changes to the network communication

Notes for the Device