
This document provides additional assistance with wiring your Extron IP Link Pro Control Processor to your device. Different components may require a different wiring scheme than those listed below.

For complete operating instructions, refer to the user's manual for the specific IP Link Pro Control Processor or the documentation supplied by the manufacturer of the controlled device.

For more information on using Global Scriptor Modules, refer to the "[Guide to Using Scriptor Modules](#)" document.

Device Specifications

Device Type: Camera
Manufacturer: Bosch
Firmware Version: N/A
Model(s): MIC IP fusion 9000i

Tested on the Following Software and Firmware Versions

IP Link Pro Control Processor Firmware	Global Scriptor Version
3.04.0001-b002	2.3.1

Version History

Module Version	Date	Notes
1_0_0_0	10/16/2019	Initial Version

Supported Class and Example

HTTPClass

```
InterfaceName = ModuleName.HTTPClass('192.168.254.254', 80, 'admin', 'password', Model='MIC IP  
fusion 9000i')
```

Control Commands

Format with Qualifier:

```
InterfaceName.Set(Command, Value, {'Qualifier Key': 'Qualifier Value'})
```

Format with Qualifier:

```
InterfaceName.Set(Command, Value)
```

Command	Value		
DigitalZoom	1 to 12 in steps of 1		
# DigitalZoom example InterfaceName.Set('DigitalZoom', 12)			
Command	Value	Value	Value
PanTilt	'Up' 'Right'	'Down'	'Left'
Qualifier Key	Qualifier Value		
'Speed'	'1' – '15'		
# PanTilt example InterfaceName.Set('PanTilt', 'Up', {'Speed': '1'})			
Command	Value		
PresetRecall	'1' – '99'		
# PresetRecall example InterfaceName.Set('PresetRecall', '1')			
Command	Value		
PresetSave	'1' – '99'		
# PresetSave example InterfaceName.Set('PresetSave', '1')			
Command	Value		
Stop ¹	None		
# Stop example InterfaceName.Set('Stop', None)			
Command	Value	Value	Value
Tour	'Record' 'Replay Once'	'Stop Recording' 'Stop Replay'	'Replay Loop'
# Tour example InterfaceName.Set('Tour', 'Record')			
Command	Value	Value	
Zoom	'Tele'	'Wide'	
Qualifier Key	Qualifier Value		
'Speed'	'1' – '7'		
# Zoom example InterfaceName.Set('Zoom', 'Tele', {'Speed': '1'})			

¹ This command is used to stop the continuous Pan Tilt and Zoom commands.

Status Commands

N/A

Network communication

When configuring the Ethernet module, be sure device settings match those of the Global Scriptor ethernet interface.

Port Type: Ethernet

Default Port: 80

Logon Credentials Supported: Yes

Multi-Connection Capabilities: Yes

Port Changeability: No

Ethernet Module Configuration Description

Please refer to user manual for settings and changes to the network communication

Notes for the Device