

This document provides additional assistance with wiring your Extron IP Link Pro Control Processor to your device. Different components may require a different wiring scheme than those listed below.

For complete operating instructions, refer to the user's manual for the specific IP Link Pro Control Processor or the documentation supplied by the manufacturer of the controlled device.

For more information on using Global Scriptor Modules, refer to the "[Guide to Using Scriptor Modules](#)" document.

Device Specifications

Device Type: Controller
Manufacturer: Christie
Firmware Version: N/A
Model(s): Pandoras Box

Tested on the Following Software and Firmware Versions

IP Link Pro Control Processor Firmware	Global Scriptor Version
3.04.0001-b002	2.3.0

Version History

Module Version	Date	Notes
1_0_2_0	7/22/2019	Added Spark Rev 16 commands.
1_0_1_0	7/12/2017	Initial Version

Module Notes

- Module doesn't support status.

Supported Class and Example

EthernetClass
<code>InterfaceName = ModuleName.EthernetClass('192.168.254.254', 23, Model='Pandoras Box')</code>

Control Commands

Format with Qualifier:

```
InterfaceName.Set(Command, Value, {'Qualifier Key': 'Qualifier Value'})
```

Format with Qualifier:

```
InterfaceName.Set(Command, Value)
```

Command	Value		
Cue	'1' – '16'		
Qualifier Key	Qualifier Value		
'Virtual COM Port'	'0' – '3'		
# Cue example InterfaceName.Set('Cue', '1', {'Virtual COM Port': '0'})			
Command	Value	Value	Value
SparkRev16SequenceTransport ²	'Next Cue'	'Last Cue'	'Next Frame'
	'Last Frame'		
Qualifier Key	Qualifier Value		
'Sequence ID'	'1' – '99'		
# SparkRev16SequenceTransport example InterfaceName.Set('SparkRev16SequenceTransport', 'Next Cue', {'Sequence ID': '1'})			
Command	Value		
SparkRev7Connect ¹	'1' – '99'		
Qualifier Key	Qualifier Value		
'IP Address'	'String'		
# SparkRev7Connect example InterfaceName.Set('SparkRev7Connect', '1', {'IP Address': 'String'})			
Command	Value		
SparkRev7Disconnect ¹	None		
# SparkRev7Disconnect example InterfaceName.Set('SparkRev7Disconnect', None)			
Command	Value		
SparkRev7SetCue ¹	'1' – '99'		
Qualifier Key	Qualifier Value		
'Sequence ID'	'1' – '99'		
# SparkRev7SetCue example InterfaceName.Set('SparkRev7SetCue', '1', {'Sequence ID': '1'})			
Command	Value		
SparkRev7SetCue ¹	'1' – '99'		
Qualifier Key	Qualifier Value		
'Sequence ID'	'1' – '99'		
# SparkRev7SetCue example InterfaceName.Set('SparkRev7SetCue', '1', {'Sequence ID': '1'})			
Command	Value	Value	Value
SparkRev7Transport ¹	'Play'	'Pause'	'Stop'
Qualifier Key	Qualifier Value		
'Sequence ID'	'1' – '99'		
# SparkRev7Transport example InterfaceName.Set('SparkRev7Transport', 'Play', {'Sequence ID': '1'})			
Command	Value		
SparkRev16ActivateAll ²	None		
# SparkRev16ActivateAll example InterfaceName.Set('SparkRev16ActivateAll', None)			

Global Scripter Module
Communication Sheet

Command SparkRev16ActivateDevice ²	Value None
Qualifier Key 'Site ID'	Qualifier Value '1' – '99'
Qualifier Key 'Device ID'	Qualifier Value '1' – '99'
# SparkRev16ActivateDevice example InterfaceName.Set('SparkRev16ActivateDevice', None, {'Site ID': '1', 'Device ID': '1'})	
Command SparkRev16ActivateParameter ²	Value None
Qualifier Key 'Device ID'	Qualifier Value '1' – '99'
Qualifier Key 'Site ID'	Qualifier Value '1' – '99'
Qualifier Key 'Parameter Name'	Qualifier Value 'String'
# SparkRev16ActivateParameter example InterfaceName.Set('SparkRev16ActivateParameter', None, {'Device ID': '1', 'Site ID': '1', 'Parameter Name': 'String'})	
Command SparkRev16ActivateSite ²	Value None
Qualifier Key 'Site ID'	Qualifier Value '1' – '99'
# SparkRev16ActivateSite example InterfaceName.Set('SparkRev16ActivateSite', None, {'Site ID': '1'})	
Command SparkRev16ClearActiveDevice ²	Value None
Qualifier Key 'Site ID'	Qualifier Value '1' – '99'
Qualifier Key 'Device ID'	Qualifier Value '1' – '99'
# SparkRev16ClearActiveDevice example InterfaceName.Set('SparkRev16ClearActiveDevice', None, {'Site ID': '1', 'Device ID': '1'})	
Command SparkRev16ClearActiveParameter ²	Value None
Qualifier Key 'Device ID'	Qualifier Value '1' – '99'
Qualifier Key 'Site ID'	Qualifier Value '1' – '99'
Qualifier Key 'Parameter Name'	Qualifier Value 'String'
# SparkRev16ClearActiveParameter example InterfaceName.Set('SparkRev16ClearActiveParameter', None, {'Device ID': '1', 'Site ID': '1', 'Parameter Name': 'String'})	
Command SparkRev16ClearActiveSite ²	Value None
Qualifier Key 'Site ID'	Qualifier Value '1' – '99'
# SparkRev16ClearActiveSite example InterfaceName.Set('SparkRev16ClearActiveSite', None, {'Site ID': '1'})	
Command SparkRev16ClearAllActive ²	Value None

Global Scripter Module Communication Sheet

# SparkRev16ClearAllActive example InterfaceName.Set('SparkRev16ClearAllActive', None)			
Command Transport	Value 'Play'	Value 'Stop'	Value 'Pause'
Qualifier Key 'Virtual COM Port'	Qualifier Value '0' – '3'		
# Transport example InterfaceName.Set('Transport', 'Play', {'Virtual COM Port': '0'})			

¹ This command is valid only for Spark Rev.7 or higher.

² This command is valid only for Spark Rev.16 or higher.

Network communication

When configuring the Ethernet module, be sure device settings match those of the Global Scriptor ethernet interface.

Port Type:	Ethernet
Default Port:	23
Logon Credentials Supported:	No
Multi-Connection Capabilities:	Undetermined
Port Changeability:	No

Ethernet Module Configuration Description

Please refer to user manual for settings and changes to the network communication

Notes for the Device

Appendix A. Set Commands

Cue 1 Virtual COM Port 0	\xFF\x00\x00\x00(1)
Cue 1 Virtual COM Port 3	\xFF\x00\x00\x03(1)
Cue 16 Virtual COM Port 0	\xFF\x00\x00\x00(16)
Cue 16 Virtual COM Port 3	\xFF\x00\x00\x03(16)
Spark Rev 16 - Sequence Transport Last Cue Sequence ID 1	(PBA,SeqLastCue,01)
Spark Rev 16 - Sequence Transport Last Cue Sequence ID 99	(PBA,SeqLastCue,99)
Spark Rev 16 - Sequence Transport Last Frame Sequence ID 1	(PBA,SeqLastFrame,01)
Spark Rev 16 - Sequence Transport Last Frame Sequence ID 99	(PBA,SeqLastFrame,99)
Spark Rev 16 - Sequence Transport Next Cue Sequence ID 1	(PBA,SeqNextCue,01)
Spark Rev 16 - Sequence Transport Next Cue Sequence ID 99	(PBA,SeqNextCue,99)
Spark Rev 16 - Sequence Transport Next Frame Sequence ID 1	(PBA,SeqNextFrame,01)
Spark Rev 16 - Sequence Transport Next Frame Sequence ID 99	(PBA,SeqNextFrame,99)
Spark Rev 7 - Connect 1 IP Address testString	(PBA,Connect,testString,01)
Spark Rev 7 - Connect 99 IP Address testString	(PBA,Connect,testString,99)
Spark Rev 7 - Disconnect None	(PBA,Disconnect)
Spark Rev 7 - Set 1 Sequence ID 1	(PBA,SetCue,01,01)
Spark Rev 7 - Set 1 Sequence ID 99	(PBA,SetCue,99,01)
Spark Rev 7 - Set 99 Sequence ID 1	(PBA,SetCue,01,99)
Spark Rev 7 - Set 99 Sequence ID 99	(PBA,SetCue,99,99)
Spark Rev 7 - Set Cue 1 Sequence ID 1	(PBA,SetCue,01,01)
Spark Rev 7 - Set Cue 1 Sequence ID 99	(PBA,SetCue,99,01)
Spark Rev 7 - Set Cue 99 Sequence ID 1	(PBA,SetCue,01,99)
Spark Rev 7 - Set Cue 99 Sequence ID 99	(PBA,SetCue,99,99)
Spark Rev 7 - Transport Pause Sequence ID 1	(PBA,SetSeq,01,Pause)
Spark Rev 7 - Transport Pause Sequence ID 99	(PBA,SetSeq,99,Pause)
Spark Rev 7 - Transport Play Sequence ID 1	(PBA,SetSeq,01,Play)
Spark Rev 7 - Transport Play Sequence ID 99	(PBA,SetSeq,99,Play)
Spark Rev 7 - Transport Stop Sequence ID 1	(PBA,SetSeq,01,Stop)
Spark Rev 7 - Transport Stop Sequence ID 99	(PBA,SetSeq,99,Stop)
Spark Rev16 - Activate All None	(PBA,ActivateAll)
Spark Rev16 - Activate Device None Site ID 1 Device ID 1	(PBA,ActivateDevice,01,01)
Spark Rev16 - Activate Device None Site ID 1 Device ID 99	(PBA,ActivateDevice,01,99)
Spark Rev16 - Activate Device None Site ID 99 Device ID 1	(PBA,ActivateDevice,99,01)

**Global Scripter Module
Communication Sheet**

Spark Rev16 - Activate Device None Site ID 99 Device ID 99	(PBA,ActivateDevice,99,99)
Spark Rev16 - Activate Parameter None Device ID 1 Site ID 1 Parameter Name testString	(PBA,ActivateParam,01,01,testString)
Spark Rev16 - Activate Parameter None Device ID 1 Site ID 99 Parameter Name testString	(PBA,ActivateParam,99,01,testString)
Spark Rev16 - Activate Parameter None Device ID 99 Site ID 1 Parameter Name testString	(PBA,ActivateParam,01,99,testString)
Spark Rev16 - Activate Parameter None Device ID 99 Site ID 99 Parameter Name testString	(PBA,ActivateParam,99,99,testString)
Spark Rev16 - Activate Site None Site ID 1	(PBA,ActivateSite,01)
Spark Rev16 - Activate Site None Site ID 99	(PBA,ActivateSite,99)
Spark Rev16 - Clear Active Device None Site ID 1 Device ID 1	(PBA,ClearActiveDevice,01,01)
Spark Rev16 - Clear Active Device None Site ID 1 Device ID 99	(PBA,ClearActiveDevice,01,99)
Spark Rev16 - Clear Active Device None Site ID 99 Device ID 1	(PBA,ClearActiveDevice,99,01)
Spark Rev16 - Clear Active Device None Site ID 99 Device ID 99	(PBA,ClearActiveDevice,99,99)
Spark Rev16 - Clear Active Parameter None Device ID 1 Site ID 1 Parameter Name testString	(PBA,ClearActiveParam,01,01,testString)
Spark Rev16 - Clear Active Parameter None Device ID 1 Site ID 99 Parameter Name testString	(PBA,ClearActiveParam,99,01,testString)
Spark Rev16 - Clear Active Parameter None Device ID 99 Site ID 1 Parameter Name testString	(PBA,ClearActiveParam,01,99,testString)
Spark Rev16 - Clear Active Parameter None Device ID 99 Site ID 99 Parameter Name testString	(PBA,ClearActiveParam,99,99,testString)
Spark Rev16 - Clear Active Site None Site ID 1	(PBA,ClearActiveSite,01)
Spark Rev16 - Clear Active Site None Site ID 99	(PBA,ClearActiveSite,99)
Spark Rev16 - Clear All Active None	(PBA,ClearAllActive)
Transport Pause Virtual COM Port 0	\xFF\x00\x00\x00(Pause)
Transport Pause Virtual COM Port 3	\xFF\x00\x00\x03(Pause)
Transport Play Virtual COM Port 0	\xFF\x00\x00\x00(Play)
Transport Play Virtual COM Port 3	\xFF\x00\x00\x03(Play)
Transport Stop Virtual COM Port 0	\xFF\x00\x00\x00(Stop)
Transport Stop Virtual COM Port 3	\xFF\x00\x00\x03(Stop)