
This document provides additional assistance with wiring your Extron IP Link Pro Control Processor to your device. Different components may require a different wiring scheme than those listed below.

For complete operating instructions, refer to the user's manual for the specific IP Link Pro Control Processor or the documentation supplied by the manufacturer of the controlled device.

For more information on using Global Scriptor Modules, refer to the "[Guide to Using Scriptor Modules](#)" document.

Device Specifications

Device Type: Video Processor
Manufacturer: Christie
Firmware Version: N/A
Model(s): E600

Tested on the Following Software and Firmware Versions

IP Link Pro Control Processor Firmware	Global Scriptor Version
3.00.0000-b022	2.0.0

Version History

Module Version	Date	Notes
1_0_0_0	10/31/2018	Initial Version

Module Notes

- Unidirectional variable must be set to 'True' if status is not required. Default value is 'False'.
Example: `InterfaceName.Unidirectional = 'True'`
- connectionCounter variable must be set to the number of queries that will be sent to the device before displaying 'Disconnected' if no response is received. Default value is 15.
Example: `InterfaceName.connectionCounter = 5`
- There must be at least 1 Receiving Card on RJ45 Port 1 of the device.
- When using a Function Card, it must be connected on RJ45 Port 1.
- When using a Light Sensor, it must be connected on RS485 Port 1 of the Function Card.
- Standalone mode must be disabled for Light Sensor to function.

Supported Class and Example

EthernetClass
<code>InterfaceName = ModuleName.EthernetClass('192.168.254.254', 5200, Model='E600')</code>

Control Commands

Format with Qualifier:

```
InterfaceName.Set(Command, Value, {'Qualifier Key': 'Qualifier Value'})
```

Format without Qualifier:

```
InterfaceName.Set(Command, Value)
```

Command AutoBrightness ¹	Value 'Enable'	Value 'Disable'	
# AutoBrightness example InterfaceName.Set('AutoBrightness', 'Enable')			
Command Blackout	Value 'Enable'	Value 'Disable'	
# Blackout example InterfaceName.Set('Blackout', 'Enable')			
Command Brightness	Value 0 to 255 in steps of 1		
# Brightness example InterfaceName.Set('Brightness', 255)			
Command Input	Value 'DisplayPort'	Value 'HDMI'	Value 'DVI'
# Input example InterfaceName.Set('Input', 'DisplayPort')			
Command RelayControl	Value 'On'	Value 'Off'	
Qualifier Key 'Relay'	Qualifier Value '1' – '8'		
# RelayControl example InterfaceName.Set('RelayControl', 'On', {'Relay': '1'})			
Command TestPattern	Value 'Red'	Value 'Green'	Value 'Blue'
	'White'	'Horizontal'	'Vertical'
	'Incline'	'Grayscale'	'Aging'
	'Normal Video'		
# TestPattern example InterfaceName.Set('TestPattern', 'Red')			

¹Requires a Function Card (MTH300) to be connected to RJ45 Port 1 of the device. The Light Sensor must be plugged into RS485 Port 1 of the Function Card.

Status Available

For all commands, call Update to receive the latest status. ConnectionStatus does not support the Update function and is triggered by the device providing a successful response to other Update function calls.

Format with Qualifier:

```
InterfaceName.Update(Command, {'Qualifier Key': 'Qualifier Value'})
Value = InterfaceName.ReadStatus(Command, {'Qualifier Key': 'Qualifier Value'})
InterfaceName.SubscribeStatus(Command, {'Qualifier Key': 'Qualifier Value'}, FeedbackHandler)
FeedbackHandler will be called only when the specified qualifier gets a new status.
```

Format without Qualifier:

```
InterfaceName.Update(Command)
Value = InterfaceName.ReadStatus(Command)
InterfaceName.SubscribeStatus(Command, None, FeedbackHandler)
FeedbackHandler will be called when any qualifier gets a new status.
```

Command	Value	Value
AutoBrightness ¹	'Enable'	'Disable'
# AutoBrightness examples InterfaceName.Update('AutoBrightness') Value = InterfaceName.ReadStatus('AutoBrightness') InterfaceName.SubscribeStatus('AutoBrightness', None, FeedbackHandler)		
Command	Value	Value
Blackout	'Enable'	'Disable'
# Blackout examples InterfaceName.Update('Blackout') Value = InterfaceName.ReadStatus('Blackout') InterfaceName.SubscribeStatus('Blackout', None, FeedbackHandler)		
Command	Value	
Brightness	0 to 255 in steps of 1	
# Brightness examples InterfaceName.Update('Brightness') Value = InterfaceName.ReadStatus('Brightness') InterfaceName.SubscribeStatus('Brightness', None, FeedbackHandler)		
Command	Value	Value
ConnectionStatus	'Connected'	'Disconnected'
# ConnectionStatus examples Value = InterfaceName.ReadStatus('ConnectionStatus') InterfaceName.SubscribeStatus('ConnectionStatus', None, FeedbackHandler)		
Command	Value	
LightSensorStatus ^{1,2}	0 – 65534	
# LightSensorStatus examples InterfaceName.Update('LightSensorStatus')		

<pre>Value = InterfaceName.ReadStatus('LightSensorStatus') InterfaceName.SubscribeStatus('LightSensorStatus', None, FeedbackHandler)</pre>		
Command RelayControl ¹	Value 'On'	Value 'Off'
Qualifier Key 'Relay'	Qualifier Value '1' – '8'	
<pre># RelayControl examples InterfaceName.Update('RelayControl', {'Relay': '1'}) Value = InterfaceName.ReadStatus('RelayControl', {'Relay': '1'}) InterfaceName.SubscribeStatus('RelayControl', None, FeedbackHandler)</pre>		
Command TemperatureStatus ³	Value 0 – 100	
Qualifier Key 'RJ45 Port'	Qualifier Value '1' – '8'	
Qualifier Key 'Board Address'	Qualifier Value '1' – '255'	
<pre># TemperatureStatus examples InterfaceName.Update('TemperatureStatus', {'RJ45 Port': '1', 'Board Address': '1'}) Value = InterfaceName.ReadStatus('TemperatureStatus', {'RJ45 Port': '1', 'Board Address': '1'}) InterfaceName.SubscribeStatus('TemperatureStatus', None, FeedbackHandler)</pre>		

¹ Requires a Function Card (MTH300) to be connected to RJ45 Port 1 of the device. The Light Sensor must be plugged into RS485 Port 1 of the Function Card.

² Requires a Function Card (MTH300) to be connected to RJ45 Port 1 of the device.

³ This returns the temperature reported by each Receiving Card. Requires 'RJ45 Port' (of the device) and 'Board Address' (position in chain) Parameters.

Network communication

When configuring the Ethernet module, be sure device settings match those of the Global Scripter ethernet interface

Port Type:	Ethernet
Default Port:	5200
Logon Credentials Supported:	No
Multi-Connection Capabilities:	No
Port Changeability:	No

Ethernet Module Configuration Description

Please refer to user manual for settings and changes to the network communication

Notes for the Device

Appendix A. Set Commands

Auto Brightness Disable	U\xAA\x00[\xFE\x00\x00\x00\x00\x01\x00\x00\x00\x00\x0A\x01\x00\xFF\xB9W
Auto Brightness Enable	U\xAA\x00[\xFE\x00\x00\x00\x00\x00\x01\x00\x00\x00\x00\x0A\x01\x00}7W
Blackout Disable	U\xAA\x00\x00\xFE\xFF\x01\xFF\xFF\xFF\x01\x00\x00\x01\x00\x02\x01\x00\x00UZ
Blackout Enable	U\xAA\x00\x00\xFE\xFF\x01\xFF\xFF\xFF\x01\x00\x00\x01\x00\x02\x01\x00\xFFT[
Brightness 0	U\xAA\x00\x00\xFE\x00\x01\xFF\xFF\xFF\x01\x00\x01\x00\x00\x02\x01\x00\x00VY
Brightness 255	U\xAA\x00\x00\xFE\x00\x01\xFF\xFF\xFF\x01\x00\x01\x00\x00\x02\x01\x00\xFFUZ
Input DisplayPort	U\xAA\x00\x00\xFE\xFF\x00\x00\x00\x00\x01\x00#\x00\x00\x02\x01\x00_\xD8W
Input DVI	U\xAA\x00\x00\xFE\xFF\x00\x00\x00\x00\x01\x00#\x00\x00\x02\x01\x00a\xDAW
Input HDMI	U\xAA\x00\x00\xFE\xFF\x00\x00\x00\x00\x01\x00#\x00\x00\x02\x01\x00\x05~W
Relay Control Off Relay 1	U\xAA\x00\x00\xFE\x00\x02\x00\x00\x00\x01\x00\x10\x00\x00\x05\x01\x00\x01mV
Relay Control Off Relay 8	U\xAA\x00\x00\xFE\x00\x02\x00\x00\x00\x01\x00\x17\x00\x00\x05\x01\x00\x01tV
Relay Control On Relay 1	U\xAA\x00\x00\xFE\x00\x02\x00\x00\x00\x01\x00\x10\x00\x00\x05\x01\x00\x00lV
Relay Control On Relay 8	U\xAA\x00\x00\xFE\x00\x02\x00\x00\x00\x01\x00\x17\x00\x00\x05\x01\x00\x00sV
Test Pattern Aging	U\xAA\x00\x80\xFE\x00\x01\xFF\xFF\xFF\x01\x00\x01\x01\x00\x02\x01\x00\x0AxE1Y
Test Pattern Blue	U\xAA\x00\x80\xFE\x00\x01\xFF\xFF\xFF\x01\x00\x01\x01\x00\x02\x01\x00\x04\xDBY
Test Pattern Grayscale	U\xAA\x00\x80\xFE\x00\x01\xFF\xFF\xFF\x01\x00\x01\x01\x00\x02\x01\x00\x09\xE0Y
Test Pattern Green	U\xAA\x00\x80\xFE\x00\x01\xFF\xFF\xFF\x01\x00\x01\x01\x00\x02\x01\x00\x03\xDAY
Test Pattern Horizontal	U\xAA\x00\x80\xFE\x00\x01\xFF\xFF\xFF\x01\x00\x01\x01\x00\x02\x01\x00\x06\xDDY
Test Pattern Incline	U\xAA\x00\x80\xFE\x00\x01\xFF\xFF\xFF\x01\x00\x01\x01\x00\x02\x01\x00\x08\xDFY
Test Pattern Normal Video	U\xAA\x00\x80\xFE\x00\x01\xFF\xFF\xFF\x01\x00\x01\x01\x00\x02\x01\x00\x00\xD7Y
Test Pattern Red	U\xAA\x00\x80\xFE\x00\x01\xFF\xFF\xFF\x01\x00\x01\x01\x00\x02\x01\x00\x02\xD9Y
Test Pattern Vertical	U\xAA\x00\x80\xFE\x00\x01\xFF\xFF\xFF\x01\x00\x01\x01\x00\x02\x01\x00\x07\xDEY
Test Pattern White	U\xAA\x00\x80\xFE\x00\x01\xFF\xFF\xFF\x01\x00\x01\x01\x00\x02\x01\x00\x05\xDCY

Appendix B. Update Commands

Auto Brightness	U\xAA\x00[\xFE\x00\x00\x00\x00\x00\x00\x00\x00\x00\x0A\x01\x00\xB9V
Blackout	U\xAA\x00\x00\xFE\x00\x01\x00\x00\x00\x00\x00\x00\x01\x00\x02\x01\x00XV
Brightness	U\xAA\x00\x00\xFE\x00\x01\x00\x00\x00\x00\x00\x00\x01\x00\x00\x02\x01\x00XV
Light Sensor Status	U\xAA\x00\x15\xFE\x00\x02\x00\x00\x00\x01\x00\x00\x00\x00\x06\x0B\x00\x00\x00\x00\x00U\xAA\x01\x02\x80\xFF\x81~YU\xAA\x00\x15\xFE\x00\x02\x00\x00\x00\x00\x00\x00\x00\x00\x06\x05\x00uV
Relay Control Relay 1	U\xAA\x00\x00\xFE\x00\x02\x00\x00\x00\x00\x00\x00\x10\x00\x00\x05\x08\x00rV
Relay Control Relay 8	U\xAA\x00\x00\xFE\x00\x02\x00\x00\x00\x00\x00\x00\x10\x00\x00\x05\x08\x00rV
Temperature Status RJ45 Port 1 Board Address 1	U\xAA\x00\x00\xFE\x00\x01\x00\x00\x00\x00\x00\x00\x00\x00\x0A\x02\x00`V
Temperature Status RJ45 Port 1 Board Address 255	U\xAA\x00\x00\xFE\x00\x01\x00\xFE\x00\x00\x00\x00\x00\x00\x0A\x02\x00^W
Temperature Status RJ45 Port 8 Board Address 1	U\xAA\x00\x00\xFE\x00\x01\x07\x00\x00\x00\x00\x00\x00\x0A\x02\x00gV
Temperature Status RJ45 Port 8 Board Address 255	U\xAA\x00\x00\xFE\x00\x01\x07\xFE\x00\x00\x00\x00\x00\x00\x0A\x02\x00eW