

This document provides additional assistance with wiring your Extron IPL PRO enabled product to your device. Different components may require a different wiring scheme than those listed below.

For complete operating instruction, refer to the user's manual for the specific Extron IPL PRO enabled product or the controlled device manufacturer supplied documentation.

Device Specifications:

Device Type: Other
Manufacturer: Cisco
Firmware Version: N/A
Model(s): SG500

Tested on the Following Software and Firmware Versions:

IP Link Pro Control Processor Firmware	Touch Link Panel Firmware	GS Version
2.04.0000-b007	2.01.0001-b001	1.2.3

Version History

Module Version	Date	Notes
1_0_1_0	3/27/2017	Initial Version

Module Notes

- Unidirectional variable must be set to 'True' if status is not required. Default value is 'False'. Example:
InterfaceName.Unidirectional = 'True'
- connectionCounter variable must be set the number of queries that will be sent to the device before displaying 'Disconnected' if no response is received. Default value is 15. Example:
InterfaceName.connectionCounter = 5
- If login credentials are required, deviceUsername and devicePassword must be set accordingly. The default username and password is 'cisco'.
Example: InterfaceName.deviceUsername = 'cisco'
InterfaceName.devicePassword = 'cisco'

Control Commands, States, and Qualifiers:

Initial ¹	None
----------------------	------

¹ This may need to be sent twice with a 0.3 second delay in between before the device begins responding.

Status Available:

Clock	'String'	
ConnectionStatus	'Connected'	'Disconnected'

Cable and Adapter Requirements:

Captive Screw to Female DB9 RS-232 Serial Cable

Notes for the Device:

Serial communication:

Port Type: RS-232

Baud Rate: 115200


Data Bits: 8

Parity: None


Stop Bits: One

Flow Control: None

Pin Assignments Diagram



Signal	Main Cable	Pin	Signal
TxD		2	TxD
RxD		3	RxD
GND		5	GND



General Notes:

Network communication:

When configuring the Ethernet module, be sure device settings match that of the GCP configuration.

Port Type:	Ethernet
Default Port:	23
Logon Credentials Supported:	Yes
Default Username:	cisco
Default Password:	cisco
Multi-Connection Capabilities:	Undetermined
Port Changeability:	Yes

Ethernet Module Configuration Description:

Please refer to user manual for settings and changes to the network communication

Notes for the Device:

Appendix A. Set Commands

Initial	\r
---------	----

Appendix B. Query Commands

Clock	show clock\r
-------	--------------