



USB High Speed & Power in

Act as a device connecting to a host





USB High Speed Host



Act as a host for other device to connect to it
LiDAR or IMU with USB Serial can connect to this



USB Serial/JTAG and Power IN

For Upload Firmware to ESP32 P4





Sheet: /Ethernet_PHY/
File: Ethernet_PHY.kicad_sch

Title:





Size: A4

Date:

KiCad E.D.A. 9.0.4

Rev:

Id: 2/3



Sheet: /power_system/
File: power_system.kicad_sch

Title:

Size: A4

Date:

KiCad E.D.A. 9.0.4

Rev:

Id: 3/3