




Double click

1. Select Intel(R) Extreme Tuning Utility

- Select **Profiles**
- Click **Max_System**, click **Show Values**, and click **Apply**



In Advanced Tuning, this setting will set

Core Voltage Offset  -0.135 V

System Agent Voltage Offset  -0.065 V

2. MSI Afterburner

Click profile **#4** and click **Apply**



3. Manual Power mode: toggle **fan icon** at the top keyboard to Manual.