

SOUNDLINK® COLOR II



OWNER'S GUIDE • BRUGERVEJLEDNING
BEDIENUNGSANLEITUNG • GEBRUIKERSHANDLEIDING
GUÍA DEL USUARIO • KÄYTTÖOHJE • NOTICE D'UTILISATION
MANUALE DI ISTRUZIONI • KEZELÉSI ÚTMUTATÓ
BRUKERVEILEDNING • PODRĘCZNIK UŻYTKOWNIKA
MANUAL DO PROPRIETÁRIO • BRUKSANVISNING
續凱詢與關係 • 사용자 안내서 • 用户指南 • 使用者指南 • 取扱説明書
PYKOBOACTBO BNAAENЬЦА • स्वामी की निर्देशिका • பெய்கும்

Please read and keep all safety and use instructions.

Important Safety Instructions

- 1. Read these instructions.
- 2. Keep these instructions.
- 3. Heed all warnings.
- 4. Follow all instructions.
- 5. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- 6. Only use attachments/accessories specified by the manufacturer.
- 7. Unplug this apparatus during lightning storms or when unused for long periods of time.
- 8. Refer all servicing to qualified personnel. Servicing is required when the apparatus has been damaged in any way.

WARNINGS/CAUTIONS



This symbol means there are important operating and maintenance instructions in this guide.

- Use this product only with an agency approved power supply which meets local regulatory requirements (e.g., UL, CSA, VDE, CCC) in accordance with the manufacturer's specifications.
- The product markings are located on the bottom and inside foot of the product.
- Do NOT place naked flame sources, such as lighted candles, on or near the product.
- Do NOT make unauthorized alterations to this product.
- If the battery leaks, do not allow the liquid to come in contact with the skin or eyes. If contact is made, seek
 medical advice.
- Do not expose products containing batteries to excessive heat (e.g. from storage in direct sunlight, fire or the like).

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by Bose Corporation could void the user's authority to operate this equipment.

This device complies with part 15 of the FCC Rules and with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device complies with FCC and Industry Canada radiation exposure limits set forth for general population. It must not be co-located or be operating in conjunction with any other antennas or transmitters.

This equipment should be installed and operated with a minimum distance of 8 inches (20 cm) between radiator and vour body.

Meets IDA Requirements.

CAN ICES-3 (B)/NMB-3(B)

Management Regulation for Low-power Radio-frequency Devices **Article XII**

According to "Management Regulation for Low-power Radio-frequency Devices" without permission granted by the NCC, any company, enterprise, or user is not allowed to change frequency, enhance transmitting power or alter original characteristic as well as performance to an approved low power radio-frequency devices.

Article XIV

The low power radio-frequency devices shall not influence aircraft security and interfere legal communications; If found, the user shall cease operating immediately until no interference is achieved. The said legal communications means radio communications operated in compliance with the Telecommunications Act.

The low power radio-frequency devices must be susceptible with the interference from legal communications or ISM radio wave radiated devices.

DON'T attempt to remove the rechargeable lithium-ion battery from this product. Contact your local Bose retailer or other qualified professional for removal.



relevant provisions of Directive 1999/5/EC and all other EU directive requirements. The complete declaration of conformity can be found at: www.Bose.com/compliance



Please dispose of used batteries properly, following local regulations. Do not incinerate.



This symbol means the product must not be discarded as household waste, and should be delivered to an appropriate collection facility for recycling. Proper disposal and recycling helps protect natural resources, human health and the environment. For more information on disposal and recycling of this product, contact your local municipality, disposal service, or the shop where you bought this product.



Names and Contents of Toxic or Hazardous Substances or Elements						
		Toxic or Hazardous Substances and Elements				
Part Name	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent (CR(VI))	Polybrominated Biphenyl (PBB)	Polybrominated diphenylether (PBDE)
PCBs	Х	0	0	0	0	0
Metal Parts	Х	0	0	0	0	0
Plastic Parts	0	0	0	0	0	0
Speakers	Х	0	0	0	0	0
Cables	Х	0	0	0	0	0

This table is prepared in accordance with the provisions of SJ/T 11364.

O: Indicates that this toxic or hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement of GB/T 26572.

X: Indicates that this toxic or hazardous substance contained in at least one of the homogeneous materials used for this part is above the limit requirement of GB/T 26572.



Please complete and retain for your records
The serial and model numbers are located on the bottom and inside foot of the product.
Serial number:
Model number:

Please keep your receipt with your owner's guide. Now is a good time to register your Bose product. You can easily do this by going to http://global.Bose.com/register

Date of Manufacture: The eighth digit in the serial number indicates the year of manufacture; "6" is 2006 or 2016. **China Importer:** Bose Electronics (Shanghai) Company Limited, Part C, Plan 9, No. 353 North Riying Road, China (Shanghai) Pilot Free Trade Zone

EU Importer: Bose GP, Castleblayney Road, Carrickmacross, County Monaghan, Ireland

Taiwan Importer: Bose Taiwan Branch, 9F-A1, No.10, Section 3, Minsheng East Road, Taipei City 104, Taiwan. Phone Number: 886 2 2514 7977.

Filone Number. 000 2 2514 7577.

Mexico Importer: Bose de México, S. de R.L. de C.V., Paseo de las Palmas 405-204, Lomas de Chapultepec, 11000 México, D.F. Phone Number: 001 800 900 2673

Apple, the Apple logo, and Siri are trademarks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc.

Android, Google Play and the Google Play logo are trademarks of Google Inc.

The *Bluetooth** word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Bose Corporation is under license.

Google Now is a trademark of Google, Inc.

The N-Mark is a trademark or registered trademark of NFC Forum, Inc. in the United States and in other countries.

Siri is a trademark of Apple Inc., registered in the U.S. and other countries.

©2016 Bose Corporation. No part of this work may be reproduced, modified, distributed or otherwise used without prior written permission.

The Bose [®] Connect App	
Features	7
Getting Started	
Unpacking	8
Placement guidelines	9
Connecting to power	10
Powering on your speaker	10
Control buttons	11
Using the Multi-function button	12
Playback controls	12
Speakerphone controls	12
Accessing voice control on your mobile device through your speaker	13
Voice alerts	13
Setting up voice prompts	
Pre-installed languages	14
Selecting a language	14
Disabling voice prompts	14
Changing the language	14
<i>Bluetooth</i> [®] Technology	
Choosing your pairing method	15
Pairing your mobile device	16
Pairing a mobile device with NFC	17
Pairing another mobile device	18
Disconnecting a mobile device	18
Reconnecting a mobile device	18
Managing multiple connections	
Identifying the connected mobile devices	19
Switching between two connected mobile devices	19
Connecting to a mobile device stored in your speaker's pairing list	19
Clearing your speaker's pairing list	19
Using the Bose® Connect app	19

CONTENTS

connecting a cabled device	
Using a cable to connect a mobile device	20
Operating on battery power	
Battery protection mode	21
Auto-off setting	21
Disabling auto-off	21
Getting system Information	
Status indicators	22
Battery indicator	23
Bluetooth® indicator	23
Input indicator	23
Care and maintenance	
Cleaning	24
Customer service	24
Limited warranty	24
Technical information	24
Troubleshooting	
Common solutions	25
Resetting your speaker	27

Download Bose® Connect to easily manage *Bluetooth*® connections, unlock features and access future updates.

Features


- Unlock the full potential of your speaker.
- Free app compatible with most Apple and Android™ systems.
- Easily connect to and switch between multiple mobile devices with a single swipe.
- Disable voice prompts.
- Keep your speaker up-to-date with the latest software.
- Customize speaker settings, like voice prompt language.





Unpacking

Carefully unpack the carton and confirm that the following parts are included:







USB charging cable

If part of the speaker is damaged, do not use it. Contact your authorized Bose® dealer or Bose customer service. Refer to the contact sheet in the carton.

Placement guidelines

- For best *Bluetooth*® performance place your mobile device within 33 ft. (10 m) of your speaker, and make sure there is a clear line of sight between you and your speaker. Moving your mobile device further away, or not having a clear line of sight, may impact sound quality, and your mobile device may disconnect from your speaker.
- For optimal performance, place the back of your speaker near, but not directly against a wall. Bass response decreases as you move your speaker away from a wall.
- Keep other wireless equipment at least 3 ft. (1 m) away from your speaker.
- Place your speaker and your mobile device outside of and away from metal cabinets, other audio/video components and direct heat sources.


CAUTION: Stand your speaker on its base. Standing your speaker on any other side may cause damage to your speaker and affect sound quality.

Connecting to power

Your speaker ships with a partial charge. Before using your speaker for the first time, connect it to a USB wall charger or computer that is powered on. Your speaker does not need to be fully charged, but it does require the initial connection to activate the battery.

Note: Use a 1000 mA power source for the best speaker charging experience. Using a power source with less than 1000 mA may result in a slower charging time or your speaker may not be able to charge while playing audio.

1. Plug the small end of the USB charging cable into the micro-B USB connector on your speaker.



2. Plug the other end into a USB wall charger or computer that is powered on.

The battery indicator blinks amber, and your speaker emits a tone. When fully charged, the battery indicator glows green.

Powering on your speaker

On the button pad, press the Power button \circlearrowleft .


- The first time the speaker is powered on, the *Bluetooth*® indicator blinks blue, and you hear a voice prompt to select a language (see page 14).
- When the speaker has been powered on previously and at least one mobile device has been paired, the *Bluetooth*® indicator blinks white and the speaker connects to the last two mobile devices.

You hear "Battery < low/medium/high">. Connected to < mobile device name >." The Bluetooth® indicator glows solid white.

Control buttons

The button pad enables you to power on your speaker and control your speaker's playback, volume and speakerphone.

Note: Certain mobile devices may not support these functions.



Using the Multi-function button

This button controls music sources and speakerphone calls on your mobile device from your speaker.

Playback controls

Play	Press • ● • .
	Press • ● • .
Pause	Note: In Input mode, pressing • ● • mutes the audio (see page 20).
Skip forward to the next track	Press • ● • twice.
Skip backward to the previous track	Press • ● • three times.

Speakerphone controls

Make a call	Press and hold • • • to access voice control on your mobile device. Note: See page 13 for more information.
Switch a call from speakerphone to your mobile device, while on a call	Press and hold • ● • .
Answer a call	Press • ● • .
Reject a call	Press and hold • ● • .
End a call	Press • ● • .
Mute a call	Press and hold + and - simultaneously. Press and hold again to unmute.
Switch between calls	While on a call, press • ● • to answer a second call. Press • ● • twice to switch between the calls.

Accessing voice control on your mobile device through your speaker

The speaker microphone acts as an extension of the microphone in your smartphone. Using the Multi-function button $\bullet \bullet \bullet$, you can access the voice control capabilities on your mobile device to make/take calls or ask Siri® or Google Now™ to play music, tell you the weather, give you the score of a game, and more.

Press and hold • • • to access voice control on your mobile device.

Voice alerts

Your speaker identifies incoming callers (when applicable). To disable this feature, see "Disabling voice prompts" on page 14.

Voice prompts guide you through the *Bluetooth®* pairing and connecting processes.

Pre-installed languages

- English
- Mandarin
- Italian
- Dutch

- Spanish
- Japanese
- Portuguese
- Russian

- French
- Korean
- Swedish
- Polish

• German

To check for additional languages

Visit: global.Bose.com/Support/SLCII

You can also use the Bose Connect app (see page 7).

If your language preference is not available, see "Disabling voice prompts."

Selecting a language

- 1. Press + or to scroll through the languages.
- When you hear your language, press and hold the Multi-function button ● to select it.

You hear a beep and "Ready to pair."

Disabling voice prompts

Press and hold + and - simultaneously until you hear "Voice prompts off."

Note: Repeat to re-enable voice prompts.

Changing the language

- 1. Press and hold \oplus and \star simultaneously until you hear the voice prompt for the first language option.
- 2. Press + or to scroll through the languages.
- 3. When you hear your language preference press and hold ● until you hear a beep and "Connected to <mobile device name>."

Bluetooth® wireless technology lets you stream music from *Bluetooth* smartphones, tablets, computers or other devices to your speaker. Before you can stream music from a mobile device, you must pair the device with your speaker.

Choosing your pairing method

You can pair your mobile device with your speaker using *Bluetooth* wireless technology or Near Field Communication (NFC).

You can also use the Bose Connect app to pair your mobile device (see page 7).

What is NFC?

NFC is a technology that enables mobile devices to establish wireless communication with each other by simply tapping the mobile devices together. Refer to your mobile device owner's guide to see if your model supports NFC.

If your mobile device does not support Bluetooth pairing via NFC or if you are unsure:	Follow the instructions for "Pairing your mobile device" on page 16.
If your mobile device supports <i>Bluetooth</i> pairing using NFC:	Follow the instructions for "Pairing a mobile device with NFC" on page 17.

Note: If your mobile device supports *Bluetooth* pairing via NFC, you can use either pairing method.

Pairing your mobile device

When you power your speaker on for the first time, the speaker automatically searches for your mobile device.

1. On your mobile device, turn on the *Bluetooth*® feature.

Tip: The *Bluetooth* feature is usually found in the Settings menu.

2. Select your Bose® SoundLink® speaker from the device list.




Once paired, you hear "Connected to <mobile device name>," and the Bluetooth indicator glows solid white.

Note: To pair another mobile device, see page 18.

Pairing a mobile device with NFC

- Unlock your mobile device and turn on the Bluetooth® and NFC features.
 Refer to your mobile device owner's guide to learn more about these features.
- 2. Tap the NFC touchpoint on your mobile device to the top of your speaker. Your device may prompt you to accept pairing.



Once paired, you hear "Connected to <mobile device name>," and the Bluetooth indicator glows solid white.

Pairing another mobile device

You can store up to eight paired mobile devices in the speaker pairing list.

- Press and hold the *Bluetooth*® button ≯ until the *Bluetooth* indicator blinks blue, and you hear, "Ready to pair another device." Pair your mobile device to the speaker (see page 16).
- If your mobile device supports pairing via NFC, see page 17.

Disconnecting a mobile device

- Turn off the *Bluetooth* feature on your mobile device.
- If your mobile device supports pairing via NFC, tap and hold the NFC touchpoint on your mobile device to the top center of your speaker.

Reconnecting a mobile device

When powered on, your speaker tries to reconnect with the two most recently connected mobile devices.

Note: The mobile devices must be within range and powered on.

If your mobile device supports pairing via NFC, tap the NFC touchpoint on your mobile device to the top of your speaker.

You can store up to eight paired mobile devices in the speaker pairing list and your speaker can be actively connected to two mobile devices at a time.

Note: You can only play audio from one mobile device at a time.

Identifying the connected mobile devices

Press \$ to hear which mobile devices are currently connected.

Switching between two connected mobile devices

- 1. Pause audio on your first mobile device.
- 2. Play audio on your second mobile device.

Connecting to a mobile device stored in your speaker's pairing list

- 2. Press ⋠ within two seconds to connect to the next mobile device in your speaker's pairing list.
- 3. Repeat until you hear the desired mobile device name.
- 4. Play audio on the connected device.

Clearing your speaker's pairing list

- 1. Press ⋠ and hold for 10 seconds, until you hear "Bluetooth® device list cleared. Ready to pair."
 - All mobile devices are cleared and your speaker is ready to pair a new mobile device.
- 2. Delete your Bose® SoundLink® speaker from the *Bluetooth* list on your device.

Using the Bose® Connect app


You can also easily manage multiple connected mobile devices using the Bose Connect app. For more information, see page 7.

You can connect the audio output of a smartphone, tablet, computer or other type of mobile device to the speaker's AUX connector.

Using a cable to connect a mobile device

The AUX connector accepts a 3.5 mm stereo cable plug (not provided).

1. Using a 3.5 mm stereo cable, connect your mobile device to the AUX connector on your speaker.



- 2. Press \cup on your speaker.
- 3. Press ⊕.

The Input indicator glows white.

Battery protection mode

When your speaker is unplugged and unused for more than three days with a remaining charge of less than 10 percent, it enters battery protection mode to preserve battery power. To reactivate your speaker, connect it to a USB wall charger or computer that is powered on.

When not in use, store your speaker in a cool place.

Note: Do not store your speaker for extended periods when fully charged or when the battery indicator blinks red.

Auto-off setting


Your speaker powers off after 30 minutes of inactivity (no sound coming from your speaker) while operating on battery power.

Disabling auto-off

- Press and hold + and → simultaneously.
 You hear "Auto-off disabled."
- 2. Repeat to re-enable the auto-off feature.

Status indicators

The top of the system has a series of indicators that glow according to system state. Battery indicator



Battery indicator

Shows the battery charge level. Each time you power on your speaker, the battery indicator displays the battery charge level for two seconds and a voice prompt announces the battery charge level.

To check the battery charge level, press and hold \circlearrowleft while checking the battery indicator.

Note: Battery performance varies with the content played and the volume level at which it is played. In typical use, the speaker battery lasts up to eight hours.

Indicator activity	System State
Solid green	Charged / medium to full charge
Blinking amber	Charging
Solid amber	Medium charge
Blinking red	Need to charge

Bluetooth® indicator

Shows the connection status of a mobile device.

Indicator activity	System state
Blinking blue	Ready to pair
Blinking white	Connecting
Solid white	Connected

Input indicator

Shows the connection status of a mobile device connected with an AUX cable.

Indicator activity	System state
Solid white	System is ready to play content from a device

For more information on using a cable to connect a mobile device, see page 20.

Cleaning

- Clean the surface of the speaker with a soft, damp cloth (water only).
- Do not use any sprays near the speaker. Do not use any solvents, chemicals, or cleaning solutions containing alcohol, ammonia or abrasives.
- Do not allow liquids to spill into any openings.

Customer service

For additional help, contact Bose customer service. Refer to the contact sheet in the carton.

Limited warranty

Your speaker is covered by a limited warranty. Details of the limited warranty are provided on the warranty card in the carton. Please refer to the warranty card for instructions on how to register. Failure to register will not affect your limited warranty rights.

The warranty information provided with this product does not apply in Australia or New Zealand. See our website at www.bose.com.au/warranty or www.bose.co.nz/warranty for details of the Australia and New Zealand warranty.

Technical information

Input Voltage: 5V ===

Input Current: 1A

If you experience problems with your *Bluetooth*® speaker:

- Check the battery indicator (see page 23). Charge your speaker if necessary.
- Make sure all cables are securely attached.
- Check the state of status indicators (see page 22).
- Place your speaker according to placement guidelines (see page 9).
- Make sure your mobile device supports Bluetooth® or Bluetooth pairing via NFC technology (see page 15).

If you could not resolve your issue, see the table below to identify symptoms and solutions to common problems. If you are unable to resolve your issue, contact Bose® customer service.

Common solutions

The following table lists symptoms and possible solutions to common problems.

Problem	What to do
Battery won't charge	Battery may be in protection mode or discharged. Plug the USB charging cable into a USB wall charger or computer that is powered on.
No power	Connect the USB charging cable to a different USB port.
(battery)	Use a different USB cable.
	Use a different wall charger.
	Connect to a different AC (mains) power source.
Speaker won't pair with mobile device	• On your mobile device, turn the <i>Bluetooth</i> ® feature off and then on. Remove your speaker from the <i>Bluetooth</i> list on your mobile device. Pair your mobile device again.
	 Clear your speaker's pairing list: Press \$ and hold for 10 seconds. Delete your Bose SoundLink speaker from the Bluetooth list on your device. Pair again.
	Pair a different device (see page 15).
	Reset your speaker (see page 27).
Speaker won't pair with NFC	Unlock your device and turn on the <i>Bluetooth</i> and NFC features.
	Tap the NFC touchpoint on the back of your device to the top of your speaker.
	• Use <i>Bluetooth</i> to pair your device (see page 16).

Problem	What to do
No sound	On your mobile device, turn the <i>Bluetooth</i> ® feature off and then on. Remove your Bose SoundLink speaker from the <i>Bluetooth</i> list on your mobile device. Pair your mobile device again.
	Increase the volume on your speaker, your mobile device and music source.
	• Verify voice prompts are on. Press \$ to hear the connected mobile device. Make sure you are using the correct mobile device.
	Use a different music source.
	Pair a different mobile device (see page 15).
	If two mobile devices are connected, pause your other mobile device first.
	 Clear your speaker's pairing list: Press * and hold for 10 seconds. Delete your Bose SoundLink speaker from the <i>Bluetooth</i> list on your device. Pair again.
No sound from	Power on the mobile device and play music.
a cabled mobile device	Increase the volume on your speaker and mobile device.
device	• Press and release ⊕ until the Input indicator glows white.
	Use a different AUX cable.
	Increase the volume on the mobile device.
	Connect a different mobile device.
Poor sound	Use a different music source.
quality	Pair a different mobile device.
	Disconnect the second device.
	Increase the volume on your mobile device and music source.
Poor sound	Increase the volume on your speaker and mobile device.
quality from a cabled mobile	Use a different AUX cable.
device	Connect a different mobile device.
Audio plays from the wrong mobile device (when two mobile devices are connected)	• Press \$ to hear the connected mobile device(s). Make sure you are using the correct mobile device.
	Pause or quit the music source on the device playing music.
	Disconnect the second device.
Speaker powers off	If using a cabled mobile device, increase the volume on your mobile device.
	Disable auto-off (see page 21).

Resetting your speaker

Factory reset clears paired devices and language settings from your speaker and returns it to original factory settings.

- 1. Power on your speaker.
- 2. Press and hold \bigcirc for 10 seconds until the *Bluetooth*[®] indicator blinks blue, and you hear a voice prompt to select a language (see page 14).





©2016 Bose Corporation, The Mountain, Framingham, MA 01701-9168 USA AM747473 Rev. 01

SOUNDLINK® COLORII








0

Press d.
Tryk på d.
Drukken Sie d.
Drukken Sie d.
Presione d.
Presione d.
Premere d.
Hyturnjä meg az
d gombot.
Trykk d.
Naciśni przycisk d..

Pressione d.
Tryck på d.
ma d)
の意子音니다.
技下 d)
技 d)
が ボタンを押します。
d) ズミンでは、
Hassoure d).



3

whees + or - is broot integration the singular Try på + else - for at blades ignorem strongene. Tryk på • • og hold nede for at vellige dit sprog. Drücken Sie + oder -, um durch die Strachen zu blättern Halten Sie zum Auswählen der Sprache • • pedrückt. Druk op + of - om door de tallen te scrolle Houd • • ingedrukt om je tall at selecteren Presione + o - gara desplazares por los seleccionar el dioma.

際性・火災関係語言・ 使用したい実施リケナウススされるまで + ボタンボルは - ボタンボールます。 ボタンボルは - ボタンボールで 高 ボタンボルして 高額を変形します。 新型点を 表現 大変形 本内 を 日ヤ・町 -がた 場所で 100円 大阪 100円 トルロー がた 場所で 100円 トルロー 1000年 Manuscaltra tomory ・ + 1000年 Manuscaltra (Manuscaltra (



Valitse Bose SoundLink ja kuuntele musiikkia.

vantor bour sciniciani ja vontreer mitteleton.
Selectioner Bours SoundLink et démarrez la lecture.
Selectionare Bose SoundLink et démarrez la masica.
Valiasza a Bose SoundLink element, Valiasza a Bose SoundLink element, Selection et l'alla Bose SoundLink på, og spill av musikk.
Vijelser urzgaferie Select Bose
SoundLink ja zond.



BOSE® CONNECT



Google Play

shance your speaker experience with e Bose Connect app. i en bedre opievelse med højttaleren ed app'en Bose Connect.

Atemberaubende Klangerlebnisse mit di Bose Connect-App. Verbeter je luidsprekerervaring met de Bose Connect-app.

la aplicación Bose Connect.

Bose Connect - sovelluksella saat


Bose Connect -sovelluksella saat enemmän irti kaiuttimestasi. Tirez le meilleur profit de votre enceinte avec l'application Bose Connect.

Migliore esperienza d'ascolto con il diffusore grazie all'app Bose Connect. Hangszóróját mág jobban élvezheti, ha Bose Connect alkalmazást használja. Forbadre hayttaleropplevelsen med Bo Connect-appen. aplicativo Bose Connect.
Fler användningsmöjligheter für högstalaren med Bose Connect-appen.
ទៅនេះ២០១៩ សេចការបាន់ការនៅការមេខានការបាន់ការនៅការមេខានការបាន់ការបាន់ការនៅការមេខានការបាន់ការបាន់ការនៅការមេខានការបាន់ការប

利用 Bose Connect 应用提升您的扬声器体验。 利用 Bose Connect 應用提升您的接聲器 使用 Bose Connect 應用提升您的接聲器

でスピーカーの機能を最大限にご活用 ください。 अपने स्पीकर के अनुभव को बौस कनेक्ट एप्प द्वारा बदाएं।

Bose Connect. يتجربة استغدام أفضل للساعة للغاصة بك مع









ollann Charpe
Full charpe
Full

e carica Completa
Teljezon feltöftve
Fullsdet
Pelmy pozion nakdowa
Carga completa
Fullsddat
Bibraylis
PUT 공건
光測电
完全交流
滿充電
文寸 ura²
Полині заряд

Medis charge
Sala oplades
Muss geläden werden
Mest worden opgela den
Necesita zurgar
Variaus vähises, ladattava
Charge nécessalire
Ricaricare
Tölteni kell
Må lades
Konieczne ladowanie

-11.5E

/ In connect
// In connect
// In connect
// In Connecting
// In thickning
// Inthickning
// In





global.Bose.com/Support/SLCII

United States	(877)841-2673
Australia	1800 061 046
Argentina	0800-222-1889
Austria	0800 2673444
Bahamas	1-877-700-2107
Belgium	0800 92 812
Bermuda	1-877-700-2109
Bolivia	800-11-2099
Brazil	0800-892-0570
Canada	877 650 2073
Chile	1230-020-4851
China	86 400 880 2266
Colombia	01-800-5-1-83962
Costa Rica	0-800-011-1300
Denmark	80337799
El Salvador	800-6099
Finland	0800 05575
France	0800 857758
Germany	0800 2673 444
	852 2123 9000
	+43 1 6040 434 31

India	1800 11 2673
Ireland	1800656751
Italy	800 83 22 77
Japan	0570 080 021
Latin America	508 614 6000
Luxembourg	0800 92835
Mexico	001 800 900 2673
Netherlands	8002673888
New Zealand	0800 501 511
Norway	80081190
Panama	001-855-873-0865
Peru	0800-77-309
Poland	(48) 22-853-0031
Sweden	20909060
Switzerland	0800 880 020
Taiwan	886 2 2514 7977
United Arab Emirates	800 2673
United Kingdom	0808 1688 582
Uruguay	111-411-002-9941
Venezuela	0800-102-9116





©2016 Bose Corporation, The Mountain, Framingham, MA, 01701-9168 USA AM767468 Rev. 00

BOSE® SOUNDLINK® COLOR II

Bluetooth® speaker

Important Safety Instructions
Vigtige sikkerhedsinstruktioner
Wichtige Sicherheitshinweise
Belangrijke veiligheidsinstructies
Instrucciones importantes de seguridad
Tärkeitä turvallisuusohjeita
Instructions importantes relatives à la sécurité
Importanti istruzioni di sicurezza
Fontos biztonsági utasítások
Viktige sikkerhetsinstruksjoner
Ważne zalecenia dotyczące bezpieczeństwa
Instruções de segurança importantes
Viktiga säkerhetsanvisningar

คำแนะนำด้านความปลอดภัยที่สำคัญ

중요 안전 지침

重要安全说明

重要安全說明

安全上の留意項目

महत्वपूर्ण सुरक्षा निर्देश

Важные инструкции по технике безопасности

تعليمات السلامة الهامة



use instructions.

Refer to the owner's guide (online) for more information abo
your speaker (including accessories and replacement parts).

To request a printled copy, use the phone numbers provided.

Owner's Guide: global Bose.com/Support/SLCII

- 1 Read these instructions

- Follow all instructions
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- 6. Only use attachments/accessories specified by the
- Unplug this apparatus during lightning storms or when unused for long periods of time.
- Refer all servicing to qualified personnel. Servicing is required when the apparatus has been damaged in any way.

WARNINGS/CAUTIONS

This symbol means there are important operating and maintenance instructions in this guide.

- Use this product only with an agency approved power supply which meets local regulatory requirements (e.g., UL, CSA, VDE, CCC) in accordance with the manufacturer's specifications.
- . The product label is located on the bottom of the product
- Do NOT place naked flame sources, such as lighted candles on or near the product.
- Do NOT make unauthorized alterations to this product

- Do NOT make unauthorized alterations to this product.
 If the battery leaks, do not allow the liquid to come in contact with the skin or eyes. If contact is made, seek medical advice.
 Do not expose products containing batteries to excessive heat (e.g. from storage in idrect sunlight, fire or the like).
 CAN (CES-3 (B)/NIHB-3(B)

CAN CES - \$10,0/MeS-16)

NOTE: The cuipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Pert 15 of the PCC rules. These limits are disigned to provide reasonable protection against harmful interference are activated installation. This equipment generates, uses, and can radiate radio frequency energy and. Individual end action ancounter with the instructions, may cause harmful interference to 10 olds communications. However, this is no guarantee that interference with or count on a perticular action of the instructions. In the instruction of the instruction. In this equipment does cause harmful interference to a ready on television receiption, which can be determined by luming the equipment off and on, you are encouraged to try to correct the interference by one rone of the following measures.

Necession of relocate the receiving anterna.

- Increase the separation between the equipment and receive Connect the equipment to an outlet on a different circuit than the one to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help Changes or modifications not expressly approved by Bose Corpora could void the user's authority to operate this equipment.

This device complies with part 15 of the FCC Rules and Industry Canada license-exempt RSS standard(s).

Consider incense-exempt risks statution(s). Operation is subject to the following two conditions: (1) This devimary not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

This device complies with FCC and Industry Canada RF radiation exposure limits set forth for general population. It must not be co-located or be operating in conjunction with any other antennas

or transinuters.
This equipment should be installed and operated with a minimum distance of 8 inches (20 cm) between the radiator and your body.
Meets IDA Requirements.

DON'T attempt to remove the rechargeable lithium-ion battery from this product. Contact your local Bose retailer or other qualified professional for removal.

Input Rating: 5V _____ 1A

Management Regulation for Low-power Radio-frequency Devices

Article XII

According to "Management Regulation for Low ices" without permission granted by the NCC, any company, enterprise, or user is not allowed to change frequency, enhance transmitting power or alter original characteristic as well as performance to an approved low power radio-frequency devices.

Article AV

The low power radio-frequency devices shall not influence aircraft security and interfere legal communications; If found, the user sha cease operating immediately until no interference is achieved. The said legal communications means radio communications operated in compliance with the Telecommunications Act.

The low power radio-frequency devices must be susceptible with the interference from legal communications or ISM radio wave



radiated devices.

Bose Corporation hereby declares that this product is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/FC and all other EU directive requirements. The complete declaration of conformity can be found at: www.Bose.com/compliance Please dispose of used batteries properly, following local regulations. Do not incinerate.



This symbol means the product must not be discarded as household waste, and should be delivered to an as household waste, and should be delivered to an appropriate collection facility for recycling. Proper disposal and recycling helps protect natural resources, human health and the environment. For more information on disposal and recycling of this product, contact your local municipality, disposal service, or the shop where you bought this product.

Date of Manufacture: The eighth digit in the serial number indicates the year of manufacture; "5" is 2005 or 2015.

China Importer: Bose Electronics (Shanghai) Company Limited, Part C, Plan 9, No. 353 North Riying Road, China (Shanghai) Pilot Free Trade Zone

EU Importer: Bose GP, Castleblayney Road, Carrickmacross, County Monaghan, Ireland

Monaphan, Ireland Taiwan Importer: Bose Taiwan Branch, 9F-Al, No.10, Section 3, Minsheng East Board, Taipei Gry IAA, Taiwan, Taiwan Service Phone Number: Base Sch 2748 797. Mexico Importer: Base de México, S. de R.L. de C.V., Paseo de las Palinsa 405-204. Lomas de Chapultepec. 1000 México, D.F. Mexico Service Phone Number: 0018 000 900 2673

Please complete and retain for your records The serial and model numbers can be found on the bottom of

The warranty information provided with this product does not apply in Australia or New Zealand. See our website at www.bose.com.au/warranty or www.bose.co.nz/warranty for details of the Australia and New Zealand warranty. Amazon and all related logos are trademarks of Amazon, Inc. or its

Apple and the Apple logo are trademarks of Apple Inc., re in the U.S. and other countries. App Store is a service mark

Android, Google Play, and the Google Play logo are trademarks

The Bluetooth* word mark and logos are registered trademark: owned by Bluetooth SIG, Inc. and any use of such marks by Bose Corporation is under license.

The N-Mark is a trademark or registered trademark of NFC Forum, Inc. in the United States and in other countries. © 2016 Bose Corporation. No part of this work may be reproduced, modified, distributed, or otherwise used without prior written

Vigtige sikkerhedsinstruktioner Læs og opbevar venligst alle sikkerheds- og

Der henvises til brugervejledningen (online) for flere om din højttaler (herunder tilbeher og reservedele). I bestille et trykt eksemplar, skal du bruge de anførte t Brugervejledning: global.Bose.com/Support/SLCII

- 1 Lass disso instruktioner
- Ret dig efter alle advarsler
- Følg alle instruktioner Installer ikke i nærheden af varmekilder som f.eks. radiatorer varmeowne, komfurer eller andre apparater (herunder forstærkere), der producerer varme.
- 6. Brug kun tilslutningsudstyr/tilbehør, der er angivet af
- Afbryd strømmen til apparatet under tordenvejr, eller når det står ubrugt i lang tid.
- Overlad all service til kvalificeret servicepersonale. Service er p\u00e4krævet, hvis apparatet p\u00e4 nogen m\u00e4de er blevet beskadiget.

ADVARSLER/FORSIGTIGHEDSFORHOLDSREGLER

Dette symbol betyder, at der er vigtige betjenings- og vedligeholdelsesinstruktioner i denne vejledning.

- Må kun bruges med en godkendt strømforsyning, der overhold de lokale love og regler (f.eks. UL, CSA, VDE, CCC) i henhold til producentens specifikationer.
- Produktmærkaten er placeret i bunden af produktet.
 Placer IKKE nogen form for åben ild (f.eks. stearinlys) på eller tæ

- Hvis batterierne lækker, må væsken ikke komme i kontakt med huden eller øjnene. Hvis der finder kontakt sted, skal der søges læge Udsæt ikke produkter, der indeholder batterier, for voldsom varme (f.eks. ved opbevaring i direkte sollys, brand eller lignende).

CAN ICES-3 (B) /NMB-3 (B)

CAN LESS-1 (8) /NMP-3 (8)

BEMARIX CHE voltage for tested on overholder gramsverendeme for en digital enhed it Klasse B, dant S af FCCs bestermeiser.
Dose gramsver er utderet til at yle reinelig skeptide en did sadleg interferens i en proxit installation. Dette utdaty enseneres, bruger og kan utdatallation. Dette utdaty enseneres, bruger og kan utdatallation for bette utdaty enseneres bruger og bruges i overessstemmeise med instruktionerne - fordisagse soderig interferens i brutherde senere dissipationerne - fordisagse stadelig interferens i brutherde med dato-g by revolutionerne interferens i brutherde med dato-g by revolutigation. Nivile kan kontrolleres vid at slukke og lænde for utdatyet, dopforders did storged et ellemen enfertenses i brutherde interferense i brutherde interferense i brutherde interferense i brutherne i lenderne interferense i brutherne i lenderne interferense i brutherne i lenderne fertensense ved skille kog fatte for utdatyet, dopforders da i folgende fermagningsmider:

- Vet en traditage-alterne i en andern er lengen gel er fly antenense. - det en odder og by revoluting eller fly antenense.

- Ret modtageantennen i en anden retning, eller flyt antennen
- Skab større afstand mellem udstyret og modtag Tilslut udstyret til en stikkontakt på et andet kredsløb end det.
- hvor modtageren er tilsluttet.

Kontakt forhandleren eller en radio/tv-tekniker for at få hiælo. Ændringer eller modifikationer, der ikke udtrykkeligt er godkend af Bose Corporation, kan ophæve brugerens ret til at betjene dette udstyr

Denne enhed overholder del 15 i FCC-reglerne og Industry Canada

The renth of the control of the cont

Denne enhed overholder FCC's og Industry Canadas strållingseksponeringsgrænser for befolkningen i almindelighed. Den må ikke placeres sammen med eller anvendes sammen med nogen andre antenner eller sendere. Dette udstyr skal installeres og anvendes med en afstand på mindst 10 cm mellem strålingskilden og din krop.

werholder IDA-kravens

nputklassifikation: 5 V _ _ _ 1 A fanagement Regulation for Low-power Radio-freq

henhold til "Management Regulation for Low-power Radio frequency Devices" må ingen virksomhed, organisation eller bru John tillädelse fra NCC ændre freivensen, øge transmissionselfe eller ændre de oprindelige egenskaber eller ydeevnen for jodkendte laveffektradiofrekvensenheder.

Artikel XIV

Laveffektradiofrekvenserhederne må ikke påvrine flysikkerneoen eller fostyrire lovig komminikation; hvis dette konstateres, skal brugeren ejeblikkeligt opråver med at bruge erheden, indril der opnås en tilstand uden tostyrrelser. Den omfatte lovlige kommunikation vid sige radiokommunikation, der anvendes) overensstemmelse med telekommunikationsidven.

averfektradiofrekvensenhederne skal kunne modtage forstyrrelser ra lovilg kommunikation eller enheder, der udsender ISM-ratiohalner



.

Bose Corporation erklærer hermed, at dette produkt stemmer overens med de væsentlige krav og andre relevante bestemmelser i direktiv 1999/5/EF og alle andre krav i EU-direktiver. Den fulde overensstemmelseserklæring kan findes på www.Bose.com/compilance





www.Bose.com/complance

Borstaal Purgle butterier I neehold til lokale

bestemminder. Bettier in like bit barrols.

Dette symbol betyder, at produket like mit asmdes und

bestemminder. Bettier in like bit barrols.

Dette symbol betyder, at produket like mit asmdes und

bestemminder. Bettier dop bet indievers til en

passende indsminingsrodning med herblik på

gennamendelse. Komel borstaaffelse og gennamendelse

bidoger til at beskyttelse naturressource, memselset

sunnhed og miljet. Hick die undere free oplottak, kan

du kontakte die hommen, det reorvalorssöelseb eller

den buttik, hvor dia har habt dietler produkt, kan

du kontakte die hommen, det reorvalorssöelseb eller

den buttik, hvor dia har habt dietler produkt,

speklator. Det eller festierunarmetet anvolk.

Fremstillingsdato: De otte cifre i serienummeret angiver fremstillingsåret: "5" er 2005 eller 2015.

Importer i Kina: Bose Electronics (Shanghai) Company Limited, Part C, Plan 9, No. 353 North Riying Road, China (Shanghai) Pilot Free Trade Zone

Importer i EU: Bose GP, Castleblayney Road, Carrickmacross County,

r winegindti, Italino Importer i Talwan: Bose Talwan Branch, 9F-Al, No.10, Section 3, Minsheng East Road, Talpei City 104, Talwan. Telefonnummer till service i Talwan: 886 2 2514 7977.

service i faiwan: 660 z 2514 1977. I**mporter i Mexico:** Bose de México, S. de R.L. de C.V., Paseo de las Palmas 405-204, Lomas de Chapultepec, 11000 México, D.F. Telefonnummer til service i Mexico: 001 800 900 2673

Bedes udfyldt og opbevaret, så du har det til rådighed Serie- og modelnumre kan findes på højttalerens bundpar

Garantionlysningerne til dette produkt gælder ikke for Australien Garantiophysningerne til dette produkt gedeer sike tor Austrauen eller New Zealand. Se vorse websted ab wew bose; com ausliwarraty eller www.bose.co.nz/warranty for at få flere oplysninger om garantien i Australien og New Zealand. Amazon og alle tilknyttede logner ern Amazon og alle tilknyttede logner ern Amazon, inc. eller dets associerede selskaber.

Apple og Apple-logoet er varemærker tilhørende Apple Inc., som er registreret i USA og i andre lande. App Store er et servicemærke der tilhører Apple Inc.

Android, Google Play og Google Play-logoet er varemærker tilhørende Google Inc.

tillikeriole Googlie Inc. Bluetooth"-ordmærket og -logoerne er registrerede varemærker, der ejes af Bluetooth SIG, Inc., og enhver brug af sådanne mærker fra Bose Corporations side finder sted under licens. N-mærket er et varemærke eller et registreret varemærke, der tilhører NFC Forum, Inc. i USA og i andre lande.

© 2016 Bose Corporation. Gengivelse, aendring, distribution elle anden brug af dette dokument eller dele heraf er forbudt uden forudgående skriftlig tilladelse.

Wichtige Sicherheitshinweise Bitte lesen Sie alle Sicherheitshinweise und

mationen über Ihren Laufsprecher (zum Beispiel Zubehör Ersatzteile), Wenn Sie ein gedrucktes Exemplar erhalten niten, verwenden Sie eine der angegebenen Telefonnumm enungsanleitung: global.Bose.com/Support/SLCII

- Lesen Sie die folgenden Anweisungen. Bewahren Sie die Arweisungen auf. Beachten Sie alle Warn- und Sicherheit
- Befolgen Sie alle Anweisungen. Stellen Sie das Gerät nicht in der Nähe von Wärmed auf, wie Heizkörpern, Wärmespeichern, Öfen oder anderer Geräten (auch Verstärkern), die Wärme erzeugen.
- 6. Verwenden Sie nur Zubehör-/Anbauteile, die vom Herstelle
- 7. Ziehen Sie das Netzkabel bei Gewitter oder bei längere
- lichtbenutzung des Gerätes aus der Steckdos Wenden Sie sich bei allen Reparatur - und Wartungsarbeiten nur an qualifiziertes Personal. Eine Reparatur ist erforderlich wenn das Gerät in irgendeiner Weise beschädigt wurde.

WARNUNGEN/VORSICHTSMASSNAHMEN

Dieses Symbol macht auf wichtige Bedienungs- und Wartungsarweisungen in diesem Handbuch aufmerl

- nden Sie dieses Produkt nur mit einem zugelassener Netzteil, das die lokalen gesetzlichen Anforderungen erfüllt (z. B UL, CSA, VDE, CCC) und den Angaben des Herstellers
- Das Etikett mit der Produktbezeichnung befindet sich auf der
- Stellen Sie KEINE brennenden Kerzen oder ähnliches auf das Gerät oder in die Nähe des Geräts.

 Abbeten Gillen in der Nähe des Geräts.
- Nehmen Sie KEINE nicht genehmigten Änderungen an diesem Produkt voi
- Wenn der Akku ausläuft, arhten Sie darauf, dass Ihre Haut oder lhre Augen nicht in Kontakt mit der austretenden Flüssigkeit kommen. Suchen Sie im Falle eines Kontakts einen Arzt auf.
- Setzen Sie Produkte mit Batterien keiner großen Hitze aus (z.B. durch Aufbewahrung im direkten Sonnenlicht, Feuer oder

CAN ICES-3 (B) /NMB-3 (B)

HINWEIS: Dieses Gerät wurde getestet und erfüllt die Grenzwert für digitale Geräte der Masse B gemäß Abschnitt 15 der FCC-Vorschriften. Diese Grenzwerte wurden festgelegt, um einen angemessenen Schutz gegen elektromagnetische Strungen bei einer Installation in Wöhngebieten zu gewährleisten. Dieses Gerä einer Installation in Wörngebieten zu gewährlieisten: Diese Gestellererung und einemerkalt hischfreuspeststrählung und kann sie auch aussenden. Daher werzuscht die Gesteller keint ordnungsgemäße Installation und Berautzung möglicherweise Strümpen der Früherheiten, zu werd jedoch keine Gesterin deufür gegebien, dass bei einer bestimmten Installation keine Stöstschalungen auftreten. Sollte deues Gestelle Anzulauf deue der Früherheiten, dass der der Rache deue der Früherheiten, der werden deut geselben dass bei einer bestimmten Installation keine Stöstschalungen auftreten. Sollte deues Gestell den Rach oder Früherheiten, der Früherheiten deues der Früherheiten, nicht eine der Früherheiten, der Stöstsgen durch eine der follgenden Maßnahmen zu behebert. Nowassericht mehr der follgenden Maßnahmen zu behebert.

- Störungen durch eine der folgenden Maßhahmen zu behieber:

 Neusaurichtung der Antenne.

 Vergrüßern Sie den Abdand zwischen dem Gerät und einem Radio- oder Fernsehempfanger.

 Schließen Sie das Gerät an eine Steckdose an, die nicht mit dem Stromkers des Badio- bzw. Fernsehempfangers vertrunden ist.

 Werden Seich an einen Händler oder einen erfahrenen Radio-

Fernantekt-niker. Verlanderungen am Gerät, die nicht durch die Bose Corporation auforiseft wurden, Krimen zur Folge-haben, dass die Betriebsterinkrins für das Gerät erlicht. Deses Gerät effelt die Bestimmungen in Teil 5 der FCC-Vorschriftet und die Rezenfreien Standards von Industry Canada. Der Betrieb unterfleied den beiden folgenden Bedragungen: (1) dieses Gerät darf leines Schrungen verunsschen und 70 deses Gerät muss Spelfte Schrungen dullen, erschellicht Schrungen, die zu einem unswrünschten Betrieb des Geräts führen.

zu einen unerwundschein betriebt des Gerafs furreits. Dieses Gerät erfüllt die HF-Strahlungsexpositionsgrenzwerte c FCC und von Industry Canada für die allgemeine Bezolkerung. Es darf nicht zusammen mit anderen Antennen oder Sendern aufgestellt oder betrieben werden.

Dieses Gerät sollte mit einem Mindestabstand von 20 cm zwischer dem Radiator und Ihrem Körper aufgestellt und betrieben werden Erfüllt die IDA-Anforderungen.

Versuchen Sie NICHT, die aufladbare Lithium-Ionen-Batterie aus diesem Produkt zu nehmen. Wenden Sie sich zum Herausnehmen Ihren Bose-Händler oder einen anderen qualifizierten Fachmann. Eingangsnennleistung: 5 V

ungsverordnung für energiearme Funkfrequenzgeräte Artikel XII

Fundfrequenggeräte^{*} dürfen Unternehmen oder Benutzer ohne Erlaubnis durch die NCC Folgendes nicht: die Frequenz ändern, die Übertragungsleistung verbessem oder die ursprünglichen Eigenschaffen sowie die Leistung für ein zugelassenes energiea Fundfrequenggerät ändern.

Artikel XIV





Konformatkersklarung ist einschalt unter wurde Des conformalisatie unter wurde Des conformalisatie unter wurde des conformalisatie unter wurde des conformalisaties des Beschen nicht die des Neumalis Micht verbrennen. Dieses Symbol bestundt d. dass das Produkt nicht mit dem Hausmild einschweiden darf, soderen bei einer geeignetes Sammetstelle für das Beschrigt abgeseiten werden mass, bie derstungsgemätelle Erboraupu unt das Reyching talegen dasset der beschalt der den Beschneide und des Unterhalten der den der Beschneide und der Beschneide und des Beschneides der der der Beschneide und der Beschneide und des Beschneides der der Beschneide und des Beschneides der Beschneides der Beschneide und der Beschneide und des Beschneides des Beschneides der Beschneides der Beschneides der Beschneides der Beschneide und der Beschne

Herstellungsdatum: Die achte Ziffer in der Seriennummer gibt das Herstellungsjahr an: "5" ist 2005 oder 2015.

China-Import: Bose Electronics (Shanghai) Company Limited, Part C, Plan 9, No. 353 North Riying Road, China (Shanghai) EU-Import: Bose GP, Castleblayney Road, Carrickmacross, County

monagnar, Irlanio. Taiwan-Import: Bose Taiwan Branch, 9F-A1, No.10, Section 3, Mirsheng East Road, Taipei City 104, Taiwan. Taiwan Service-Telefonnummer: 886 2 2514 7977.

Telefonnummer: 889 Z. 2514 7917.

Mexiko-Import: Boss de México, S. de R.I., de C.V., Paseo de las Palmas 405-204, Lomas de Chapultepec, 11000 México, D.F. Mexiko Service-Telefonnummer: 001 800 900 2673 Bitte füllen Sie Folgendes aus und bewahren Sie es für Ihre Unterlagen auf. Die Serien- und Modellnummer finden Sie an der Unterseite des Lautsprechers.

Serennummer:

Die mit diesem Produkt angegebenen Garantieinformationen gelten nicht in Australien und Neusseland. Nähere Information zu unsere Garantie in Australien und Neusseland finder Sie auf unsere Website unter werw. Des Seannaf von der Sie auf unsere Website unter www.bosse.com.aufwaranty bzw. www.bose.co.nz/warranty.

Amazon und alle damit verbundenen Logos sind Marken von Amazon, Inc. oder seinen Partnerunternehmen. Apple und das Apple-Logo sind Marken der Apple Inc., die in den USA und weiteren Ländem eingefragen sind. App Store ist eine Dienstleistungsmarke von Apple Inc. Android, Google Play und das Google Play-Logo sind Marken von

Belangrijke veiligheidsinstructies Lees alle veiligheidsinstructies en de gebruiksaanwijzing door en bewaar deze

Raadpleeg de gebruikershandleiding (online) voor meer informatie over de luistgreker (waaronder accessoires en reserveonderdelen). Om een gedruikt exemplaar aan te vragen, gebruik je de telefoonnummers die je hebt ontviangen. Gebruikershandleiding: global Bose.com/Support/SICII

- 1 Lees deze instructies door
- Bewaar deze instructies.

 Neem alle waarschuwingen in acht
- Volg alle instructies.
- Niet installeren in de buurt van warmtebronnen zoals radiatoren, verwarmingsroosters, kachels of andere apparaten (waaronder versterkers) die warmte produceren.
- Gebruik uitsluitend aansluitstukken/accessoires die door de fabrikant worden gespecificeerd.
- Verwijder de stekker van dit apparaat uit het stopcontact bij onweer of als het langere tijd niet wordt gebruikt.
- Laat alle onderhoud over aan bevoegde medewerkers.
 Onderhoud is vereist wanneer het apparaat is beschadigd.

WAARSCHUWINGEN

Dit symbool betekent dat deze handleiding belangrijke bedienings- en onderhoudsinstructies bevat.

- Gebruik dit product uitsluitend met een goedgekeurde voeding die voldoet aan de plaatselijke voorschriften (bv. UL, CSA, VDE, CCC) in overeenstemming met de specificaties van de fabrikant Het productlabel bevindt zich aan de onderkant van het product.
- Plaats GEEN open vlammen, zoals brandende kaarsen, op of bij het product.
- Er mogen GEEN wijzigingen aan dit product worden aangebracht
- Als de batterij lekt, zorg dan dat de vloeistof niet in aanraking komt met huid of ogen. Bij aanraking dien je medische hulp in
- Stel producten die batterijen bevatten niet bloot aan overmatige warmte (by, door bewaring in direct zonlicht, door vuur en

CAN ICES-3 (B)/NMB-3(B)

CAN CES-3 (I)/MPS-3(I)

OPHERONICO 1 pagonats is geletat en voldort aan de normen voor een dipilaal appanat van kiase B. volgens deef 15 van de fer-Cevopscriffente. Deen roman gin bedeod om nedelijke beschemingt be berden tegen schadelijke drom pij indablike in een vooromegiving. Dit appanat alsemeret en gebruikt adorferepaartie eeregie en kan deze uitstralet en het kan, ab het net wordt veroorzeken aan tadiocommunicatie. Et is erflert geen gaarste dott apparatul scriff endige beschemingt in de de veroorzeken aan tadiocommunicatie. Et is erflert geen gaarste dott appanatul scriff keelijke bring veroorzeken de in de ontwergst en met seld on it he begeen kan voordee bepaald door het apparatul aar het deelijke bring veroorzeken de telle passad door het apparatul aan en de volgende maatergeleker.

Fill de de volgende maatergeleker.

meer van de volgende maatregeler. Richt de omkangstantenne opnieuw of verplaats deze. Vergroot de elstand tussen de apparatuur en de ontvanger. Suit de apparatuur aan op een stopcontact dat behoort tot een andere groep dan de groep waarop de ontvanger is aangesloten. Voor hulp neem je contact op met de dealer of een ervaren radio-of ty-technicus.

of ty-technicus.

Veranderingen of annpassingen die niet utdrukkelijk zijn goelgekeurd door Bose Corporation kunnen leiden tot het vervallen van de bevoegdelwid one gebruiker om dit aparatat te gebruiken. Dit apparatat voldoet aan deel 15 van de FCC-voorschriften en aan de RSS-romin(en) van Industry Canada voor van vergurning vrijgestelde apparatie Op het gebruik zijn de volgende twee voorv

op nie geduin. Zijn de vrogeniet wer voorwaarden van deepassiig.

(i) Dit apparaat mag geen storing veroorzaken en (2) dit apparaat moet bestand zijn tegen storing, waaronder storing die kan leiden tot een ongewenste werking van het apparaat. Dit apparaat voldoet aan de straingsfinieten van de FCC en Industry Canada voor blootstelling van de bevolking aan RF-str Het mag niet worden geplaatst bij of samen worden gebruikt m andere antennes of zenders.

Dit apparaat moet worden geïnstalleerd en gebruikt met e minimale afstand van 20 cm tussen de zender en je lichaa

minimae aissand van zu om tussen de zender en je lichaam. Volddet aan de IDA-vereisten. Probeer de oplaadbare lithiumionenbatterij **NIET** uit dit product te verwijderen. Neem contact op met je plaatselijke Bose-dealer of ander bevoegd vakman om deze te verwijderen. hangsspecificaties: 5 V _____ 1A
hangsspecificaties: 5 V _____ 1A
hangement Regulation for Low-power Radio-frequency Devices
borschrift voor het beheer van radiofrequente apparaten met

Artike XII Volgers de "Management Regulation for Low-power Radio-frequency Dexices" mogen bedrijven, ondernemingen of getruiker roade treeterming van de NCC de oorganiselijke eigenschapper en werking van geodgekeurde radiofrequente apparaten met bad; vermogen niet wijzigen en evermin de frequentie daarvan wijzigen of het zendvermogen verhogen.

Artike XIV.

Artik



ISM-radiogolven utstralen.

Esse Corporation verklaart hierbij dat dit product voldcet aan de essentiële vereisten en andere et bepalingen van richtlijn 1991/5/EG en all ela endere vereisten van die EU-richtlijnen. De volledige conformiteitsverklaring kun je vinden op www.Boss.com/compliense



Gool gebruikte batterijen op de juiste wijze weg, volgens de plaatselijke voorschriften. Niet verbranden.



Net verbranden.

Dit symbool betekent dat het product niet mag worden weggespond als bushondelijk afval en maar een geschlik inzamelpant voor recycling moet worden geschoff, with inzamelpant voor recycling moet worden geschoff, with hubptorenen, de mensellijke geschoffen in hutstufflijke hubptorenen, de mensellijke geschoffen in hut mit beschemen. Voor meet informatiel over het allvoeren er recycler von dit product neven je contract sop met de premerent waar je worden stop with verbranden voor de verbranden voor met de verbranden voor de v

Fabricagedatum: Het achtste cijfer in het serienummer geeft het fabricagejaar aan. "5" is 2005 of 2015.

Importeur in China: Bose Electronics (Shanghai) Company Limited, Part C, Plan 9, No. 353 North Riying Road, China (Shanghai) Importeur in de EU: Bose GP, Castleblayney Road, Carrickmaci

Courty Monaghan, Jerland Importer in Taiwan Bosc Taiwan Bornch, 9F-Al, No.10, Section 3, Mischer Sac Road, Tapie (Chy 104, Taiwan, Serviceteledocniummer Taiwan: 886 2 2514 7977. Importers in Mexico. Bosc de Néxico, S. de R.L. de C.V., Paseo de las Palmas AGS 2-0, Lomas de Chasulteres (1000 Mexico, D.F. Serviceteledonniummer Mexico: 001 800 900 2673

Vul het volgende in en bewaar deze informatie voor je administratie

Het serie- en modelnummer vind je aan de onderkant van de luidspreker.

De bij dit product verstrekte garantie-informatie is niet van toepassing in Australië en Nieuw-Zeeland. Zie onze website op www.bose.com.au/warranty of www.bose.co.nz/warranty voc informatie over de garantie voor Australië en Nieuw-Zeeland. Amazon en alle gerelateerde logo's zijn handelsmerken van Amazon

Apple en het Apple-logo zijn handelsmerken van Apple Inc., gedeponeerd in de VS en andere landen. App Store is een servicemerk van of Apple Inc. Android, Google Play en het Google Play-logo zijn handelsmerken van Google Inc.

Het Bluetooth*-woordmerk en de logo's zijn gedeponeerde handelsmerken die eigendom zijn van Bluetooth SIG, Inc. en het

Downloaded from www.Manualslib.com manuals search engine



©2016 Bose Corporation, The Mountain, Framingham, MA 01701-9168 USA AM775823 Rev. 00