




BATTERY J1

POS

NEG

C10

C9

C3

L4

U1

X1

SVCC

ADC-

ADC+

GND

C14

VT

RST

SWO

DIO

CLK

GND

DEBUG

SENSOR J2

ANT1

C8

C5

C4

L1

C6

L2

C1

C2

L3