PingPong – captain's quick chart

master PC + Overview · N1MM Logger+ multi-op · S55OO

1 · Once, every PC

1. N1MM: Config → Configure Ports… → **Broadcast Data** → **Radio** ticked, line `127.0.0.1:12060` `127.0.0.1:12062`.
2. Start `n1mm_lamps.exe`.
3. Options ▾ → **My name…** (RUN1, INB1 …).
4. Options ▾ → Network → **Allow PingPong in Windows Firewall…**
5. VPN / ZeroTier adapter set to **Private** in Windows.

2 · Before the start

1. Master lamp: Options ▾ → **Open PingPong Overview…**
2. Update all lamps… until `All lamps v… ✔`.
3. Optional: network password on the master lamp – others click the red 🔒 line.
4. Ready check → every row **green**.
5. Test all lamps – each flashes its own name.
6. Statistics ▾ → **Reset at contest start…** (Sat 01:00).

3 · During

1. Watch the table (colors below) – or the web page on a phone: `http://<master>:8046`.
2. Alarm `🔔 NOT HEARD` → check that PC → Silence alarm.
3. PC gone for good → right-click its row → **Remove from the list**.
4. Ping-pong lock: ON/OFF for all PCs.
5. Lamps stuck → Emergency ▾ → restart all (asks twice).

4 · After

1. Activity tab → Contest report… (opens in the browser – print or save as PDF).
2. Statistics ▾ → **Save CSV…** for the raw numbers.
3. Settings ▾ → **Save setup…** – names, colors, master settings for next time.

Overview – what the rows mean

✔ READY	Before operating: ready.
problem	Before operating: not ready – reason in **Check**.
TX CQ	Transmitting – row in the station's color.
F12 call	An F12 call is on.
URGENT	Shift/Ctrl+F2/F4 (URGENT / PRIORITY) – flashes.
🔔 not heard	Operating station silent 30 s – alarm + beep.
grey	Not heard (12 s +) – not operating yet.

★ = master · **Ping** column: ms to each lamp every 5 min (red = lost or over 500 ms).

Buttons

Row 1	Ping-pong lock · Ready check · Test all lamps · Emergency ▾ (restart / stop all)
Row 2	Update all lamps… · **Settings ▾** (save/restore setup, network password, web page firewall, always on top) · **Statistics ▾** (reset now / at contest start, contest report, CSV)
Tabs	Stations · Function keys · Activity (waits, calls, ping, TX per hour, event log)

Keys (operators)

F12	Hold-off call: S&P → S&P stations (30 s); Run → all (5 s)
Shift + F2 / F4	Urgent: sends F2/F4, flashes on the band
Ctrl + F2 / F4	Priority: others stopped (Esc) and held, then F2/F4

Times and the ping-pong lock are set on the master lamp: Options ▾ → Ping-pong and F12 times.

Quick fixes

`no data from this PC's N1MM`	Broadcast Data → Radio line incl. `127.0.0.1:12062`
`no PingPong heard – firewall?`	Firewall rule; VPN adapter **Private**
`⚠ TWO MASTERS` / versions	Update all lamps…; check the network
🔒 / 🔓 red line	Click it: enter / remove the network password
Remote PCs missing	ZeroTier or OpenVPN **TAP** only (no TUN / WireGuard / Tailscale)

Ports

UDP **12062**	N1MM → lamp (same PC)
UDP **46070**	lamps ↔ lamps ↔ Overview
TCP **8046** / **8047**	Overview web page / phone lamp (read only)

PingPong · github.com/s55oo/N1MMPingPong · operator sheet: PingPong-cheat-sheet.pdf

Not a hardware interlock – N1MM's own interlock still applies.