

CE195352 – Fixed-Function PWM with PSoC 3/5LP

Objective

This code example demonstrates how fixed-function PWMs operate in PSoC® 3 and PSoC 5LP.

Overview

This is a straightforward example that demonstrates the use of a fixed-function PWM. The PWM is set up to output a 50 percent duty cycle digital signal with a period of 1 second. The signal can be used to drive an LED for visual testing of the PWM output. A switch is routed into the kill input of the PWM. When the switch is pressed, the PWM output is shut off.

Requirements

Tool: PSoC Creator™ 4.2

Programming Language: C (Arm® GCC 5.4.1)

Associated Parts: PSoC 3 and PSoC 5LP parts

Related Hardware: CY8CKIT-059, CY8CKIT-001, CY8CKIT-050, CY8CKIT-030

Hardware Setup

If using the CY8CKIT-059 PSoC 5LP Prototyping Kit, no external hardware connections are required. If using a different kit or hardware platform, two connections are required. An SPST switch needs to be connected to P2[2] to enable the kill functionality. The switch should be open when not pressed and should short the pin to ground when pressed. P2[1] should be connected to an LED to view the PWM output. An oscilloscope can also be used to view the output if an LED is not available.

If you are not using CY8CKIT-059, you may need to target a different PSoC device. To do so, right-click the project in the Workspace Explorer and select **Device Selector**. Select the appropriate PSoC device for your hardware platform.

Software Setup

None.

Operation


After you program the device, the PWM will start generating its output signal. Press and hold the switch to turn OFF the PWM output. Release the switch to turn ON the PWM output.


Design and Implementation

Figure 1 shows the PSoC Creator schematics of this code example. This code example uses PWM Component.



Figure 1. PSoC Creator Schematic of Code Example





Test Setup and Procedure:

- 1) Plug CY8CKIT-059 into USB port of PC.
- 2) Program the board and observe the blue LED blinking at a rate of 1 Hz.
- 3) Press and hold SW1 on the kit to stop the PWM output and observe the LED no longer blinking. Release the button to enable the PWM output.

All functionality for this code example is implemented in hardware. The only firmware required is to configure and enable the PWM. After that, the CPU enters an idle loop.

This code example was created to operate completely in the hardware peripherals of the PSoC device, specifically the universal digital blocks (UDBs) and fixed-function PWM. This frees the CPU to handle other tasks. The UDBs also contain the inverter connecting the pin to the kill input of the PWM. Using the UDBs in PSoC allows you to design full circuits without external components.

Components and Settings

Table 1 lists the PSoC Creator Components used in this example, as well their placement.

Table 1. PSoC Creator Components

Component	Instance Name	Purpose	Non-default Settings
PWM	PWM_1	Generate square wave and bring out the signal to GPIO	Fixed Function One Output Period = 100 counts, 1 sec Compare = 50 counts, Greater than
Inverter	not_1	Invert the output of Digital Input Pin	-
Clock	clock_1	Drive the PWM at 100 Hz	100 Hz
Digital Input Pin	Kill_Switch	Stop the PWM signal	Initial drive state: High (1)
Digital Output Pin	PWM_Out	Drive the PWM signal to LED	Show External Terminal



Table 2 shows the pin selections for this code example, which is targeted at the CY8CKIT-059 Prototyping Kit. To target the project at other PSoC development kits, go to the *CE195352_Blinking_LED.cydwr* file and change the pin assignments accordingly.

Table 2. Pin Selections

Pin Name	Location
Kill_Switch	P2[2]
PWM_Out	P2[1]

Reusing This Example

This code example is designed to run on CY8CKIT-059. To port the design to a different PSoC device and/or kit, change the target device in **Device Selector**, and update the pin assignments in the **Design Wide Resources Pins** settings as needed.

Related Documents

Application Notes					
AN82156 - PSoC 3, PSoC 4, and PSoC 5LP – Designing PSoC Creator Components with UDB Datapaths	Explains how to create digital Components using PSoC UDBs				
AN81623 - PSoC 3, PSoC 4, and PSoC 5LP Digital Design Best Practices	Gives best practices for creating digital designs with PSoC				
AN82250 - PSoC 3, PSoC 4, and PSoC 5LP – Implementing Programmable Logic Designs with Verilog	Describes how to program PSoC digital resources with Verilog				
Code Examples					
CE95294	7-Bit Down Counter with PSoC 3/4/5LP				
CE95295	8-Bit UDB Counter with PSoC 3/5LP				
CE95308	Digital Utility Components with PSoC 3/5LP				
CE95351	Fixed-Function PWM with PSoC 4				
CE95298	Switch Debouncer with PSoC 3/4/5LP				
PSoC Creator Component Datasheet					
PWM	Details the use of the PWM Component				
Device Documentation					
PSoC 3 Datasheets	PSoC 3 Technical Reference Manuals				
PSoC 4 Datasheets	PSoC 4 Technical Reference Manuals				
PSoC 5LP Datasheets	PSoC 5LP Technical Reference Manuals				
Development Kit (DVK) Documentation					
PSoC 3 and PSoC 5LP Kits					
PSoC 4 Kits					



PSoC Resources

Cypress provides a wealth of data at www.cypress.com to help you select the right PSoC device for your design and quickly and effectively integrate it into your design. For a comprehensive list of resources, see KBA86521 – How to Design with PSoC 3, PSoC 4, and PSoC 5LP. The following is an abbreviated list:

- Overview: PSoC Portfolio, PSoC Roadmap
- Product Selectors: PSoC 1, PSoC 3, PSoC 4, PSoC 5LP, or PSoC 6. In addition, PSoC Creator includes a device selection tool.
- Datasheets: Describe and provide electrical specifications for the PSoC device families.
- CapSense Design Guides: Learn how to design capacitive touch-sensing applications.
- Application Notes: Cover a broad range of topics, from basic to advanced level.
- Code Examples: for PSoC 3, PSoC 4, and PSoC 5LP; or for PSoC 6.
- PSoC Technical Reference Manuals (TRM):
 Provide detailed descriptions of the architecture and registers for PSoC device family.
- Training Videos: These videos provide guidance on getting started with various Cypress product families and tools.

- **Development Kits:** Some examples include:
 - PSoC 6 BLE Pioneer Kit is a low-cost hardware platform that enables design and debug of the PSoC 63 series. It comes with an E-lnk display shield board.
 - □ CY8CKIT-042 and CY8CKIT-040, Pioneer kits, are easy-touse and inexpensive development platforms. These kits include connectors for Arduino[™] compatible shields and Digilent® Pmod[™] daughter cards.
 - CY8CKIT-049 is a series of very low-cost prototyping platform for sampling PSoC 4 devices.
 - CY8CKIT-030 and CY8CKIT-050 are designed for analog performance. They enable you to evaluate, develop, and prototype high-precision analog, low-power, and low-voltage applications powered by PSoC 3 and PSoC 5LP, respectively.
 - CY8CKIT-001 is a common development platform for all PSoC family devices.
 - CY8CKIT-059 is a rapid prototyping kit for PSoC 5LP.
- The MiniProg3 device provides an interface for flash programming and debug.




PSoC Creator

PSoC Creator is a free, Windows based Integrated Design Environment (IDE). It enables you to design system hardware and firmware concurrently based on PSoC 3, PSoC 4, PSoC 5LP, and PSoC 6 MCU (see Figure 2). With PSoC Creator, you can do the following:

- 1. Drag and drop Components to build your hardware system design in the main design workspace.
- Codesign your application firmware with the PSoC hardware.
- 3. Configure Components using configuration tools.
- 4. Explore the library of 100+ Components.
- 5. Review Component datasheets.

Figure 2. PSoC Creator Features





Document History

Document Title: CE195352 - Fixed-Function PWM with PSoC 3/5LP

Document Number: 001-95352

Revision	ECN	Orig. of Change	Submission Date	Description of Change
**	4753117	KLMZ	01/17/2016	New spec
*A	6012100	SAGA	01/16/2018	Updated template



Worldwide Sales and Design Support

Cypress maintains a worldwide network of offices, solution centers, manufacturer's representatives, and distributors. To find the office closest to you, visit us at Cypress Locations.

Products

Arm® Cortex® Microcontrollers cypress.com/arm

Automotive cypress.com/automotive

Clocks & Buffers cypress.com/clocks

Interface cypress.com/interface

Internet of Things cypress.com/iot

Memory cypress.com/memory

Microcontrollers cypress.com/mcu

PSoC cypress.com/psoc

Power Management ICs cypress.com/pmic

Touch Sensing cypress.com/touch
USB Controllers cypress.com/usb

Wireless Connectivity cypress.com/wireless

PSoC® Solutions

PSoC 1 | PSoC 3 | PSoC 4 | PSoC 5LP | PSoC 6 MCU

Cypress Developer Community

Community Forums | Projects | Videos | Blogs | Training | Components

Technical Support

cypress.com/support

All other trademarks or registered trademarks referenced herein are the property of their respective owners.



Cypress Semiconductor 198 Champion Court San Jose, CA 95134-1709

© Cypress Semiconductor Corporation, 2016-2018. This document is the property of Cypress Semiconductor Corporation and its subsidiaries, including Spansion LLC ("Cypress"). This document, including any software or firmware included or referenced in this document ("Software"), is owned by Cypress under the intellectual property laws and treaties of the United States and other countries worldwide. Cypress reserves all rights under such laws and treaties and does not, except as specifically stated in this paragraph, grant any license under its patents, copyrights, trademarks, or other intellectual property rights. If the Software is not accompanied by a license agreement and you do not otherwise have a written agreement with Cypress governing the use of the Software, then Cypress hereby grants you a personal, non-exclusive, nontransferable license (without the right to sublicense) (1) under its copyright rights in the Software (a) for Software provided in source code form, to modify and reproduce the Software solely for use with Cypress hardware products, only internally within your organization, and (b) to distribute the Software in binary code form externally to end users (either directly or indirectly through resellers and distributors), solely for use on Cypress hardware product units, and (2) under those claims of Cypress's patents that are infringed by the Software (as provided by Cypress, unmodified) to make, use, distribute, and import the Software solely for use with Cypress hardware products. Any other use, reproduction, modification, translation, or compilation of the Software is prohibited.

TO THE EXTENT PERMITTED BY APPLICABLE LAW, CYPRESS MAKES NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARD TO THIS DOCUMENT OR ANY SOFTWARE OR ACCOMPANYING HARDWARE, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. No computing device can be absolutely secure. Therefore, despite security measures implemented in Cypress hardware or software products, Cypress does not assume any liability arising out of any security breach, such as unauthorized access to or use of a Cypress product. In addition, the products described in these materials may contain design defects or errors known as errata which may cause the product to deviate from published specifications. To the extent permitted by applicable law, Cypress reserves the right to make changes to this document without further notice. Cypress does not assume any liability arising out of the application or use of any product or circuit described in this document. Any information provided in this document, including any sample design information or programming code, is provided only for reference purposes. It is the responsibility of the user of this document to properly design, program, and test the functionality and safety of any application made of this information and any resulting product. Cypress products are not designed, intended, or authorized for use as critical components in systems designed or intended for the operation of weapons, weapons systems, nuclear installations, life-support devices or systems, other medical devices or systems (including resuscitation equipment and surgical implants), pollution control or hazardous substances management, or other uses where the failure of the device or system could cause personal injury, death, or property damage ("Unintended Uses"). A critical component is any component of a device or system whose failure to perform can be reasonably expected to cause the failure of the device or system, or to affect its safety or effectiveness. Cypress is not liable, in whole or in part, and you shall and hereby do release Cypress from any claim, damage, or other liability arising from or related to all Unintended Uses of Cypress products. You shall indemnify and hold Cypress harmless from and against all claims, costs, damages, and other liabilities, including claims for personal injury or death, arising from or related to any Unintended Uses of Cypress products.

Cypress, the Cypress logo, Spansion, the Spansion logo, and combinations thereof, WICED, PSoC, CapSense, EZ-USB, F-RAM, and Traveo are trademarks or registered trademarks of Cypress in the United States and other countries. For a more complete list of Cypress trademarks, visit cypress.com. Other names and brands may be claimed as property of their respective owners.