### **Addressing Modes**

Muhammad Afzaal m.afzaal@nu.edu.pk

### **Book Chapter**

- "Computer Organization and Architecture"
- Author "William Stallings"
- 8<sup>th</sup> Edition
- Chapter 11
  - Section 11.1

### **Addressing Modes**

- The set of mechanism by which an instruction can specify how to obtain its operands
- An operand address provides the location where the data to be processed is stored
- In an assembly instruction, the destination may be a register or memory location
- Source may be an immediate value or the address of the source data

### **Addressing Modes**

- Immediate
- Direct
- Indirect
- Register
- Register Indirect
- Displacement
- Stack

#### **Useful Notations**

- In the next slides, we use the following notations
  - A denotes the contents of an address field in the instruction
  - R denotes the contents of an address field in the instruction that refers to a register
  - EA is the actual effective address of the location containing the referenced operand
  - [X] denotes the contents of memory location X or register X

### **Immediate Addressing (1/2)**

- Simplest form of addressing where operand value is present in the instruction
- No memory reference other than instruction fetch is required to obtain the operand

**Operand** 

### Immediate Addressing (2/2)

Example


```
.code
MOV AL, 10h
```

### **Direct Addressing (1/3)**

- Direct access to the data segment is required in direct addressing mode
- Address field contains the effective address of operand
- Base address of segment and offset of storage location is required

$$EA = A$$

## **Direct Addressing (2/3)**



### **Direct Addressing (3/3)**

#### Example

```
.data
  val DB 10h
.code
MOV al, val
MOV al, [102h] ;same as above
```

## **Indirect Addressing (1/3)**


- Memory cell pointed to by address field contains the address of the operand
- One major advantage is to reference more words if address field is less than word length

$$EA = [A]$$

Indirect addressing can be nested or cascaded

$$EA = [A]$$

# **Indirect Addressing (2/3)**



### **Indirect Addressing (3/3)**

Example


```
.data
  val DB 10h
  vptr DW val
.code
  MOV si, vptr
  MOV al, [si]
```

## Register Addressing (1/3)

- Similar to direct addressing
- In this mode, a register contains the operand
- Depending upon the instruction, the register may be the first operand, the second operand or both
- Processing data between register does not involve memory, so it provides fastest processing of data

$$EA = R$$

# Register Addressing (2/3)



## Register Addressing (3/3)

Example


```
.data
  val DB 10h
.code
  MOV al, ah
```

### Register Indirect Addressing (1/3)

- Similar to direct addressing that offset is combined with base address of DS to get physical address
- Operand is in memory cell pointed to by contents of register R
- Offset lies in a pointer register (BX or BP) or index register (SI or DI)

$$EA = [R]$$

### Register Indirect Addressing (2/3)



### Register Indirect Addressing (3/3)

#### Example

```
.data
  val DB 10h
.code


MOV si, OFFSET val
MOV al, [si]
```

### **Displacement Addressing (1/2)**

- In this addressing mode, an instruction has two address fields
- Both these values are added to produce the effective address
- Displacement addressing can be used as
  - Relative Addressing
  - Base-Register Addressing
  - Indexing

$$EA = A + [R]$$

### Displacement Addressing (2/2)



### **Relative Addressing**

- Address of next instruction is added to address field to produce EA
- Address of next instruction is got from PC

$$EA = A + [PC]$$

### **Base-Register Addressing**

- Register contains the main memory address
- Address field contains a displacement from address contained in register
- Examples are Segment Registers in x86

$$EA = A + R$$

### Indexing

- Address field contains the main memory address
- Register contains the displacement from the address contained in address field

$$EA = A + R$$

### **Stack Addressing**

- Operand is on the top of stack
- Operand can be pushed on the stack when it is necessary to save it
- Whenever operand is needed, it can be popped from the stack

# **Extract of Addressing Modes**

Mode	Algorithm	Principal Advantage	Principal Disadvantage
Immediate	Operand = A	No memory reference	Limited operand magnitude
Direct	EA = A	Simple	Limited address space
Indirect	EA = (A)	Large address space	Multiple memory reference
Register	EA = R	No memory reference	Limited address space
Register Indirect	EA = (R)	Large address space	Extra memory reference
Displacement	EA = A + (R)	Flexibility	Complexity
Stack	EA = Top of Stack	No memory reference	Limited applicability