## Lenovo Air Quick Start Guide

Welcome to your new Lenovo Air! This guide will help you get started with your device and explore its amazing features. With its powerful Apple M2, stunning display, and advanced camera system, you're holding cutting-edge technology in your hands.

## **Device Specifications**

Feature	Specification
Processor	Apple M2
RAM	8 GB
Storage	64 GB
Display	10.9" 2732x2048
Camera	N/A
Battery	N/A mAh
5G Support	No
OS	Android 13

## **Getting Started**

- 1. Insert SIM Card: Use the SIM ejector tool to open the SIM tray. Insert your nano-SIM card.
- 2. Power On: Hold the power button for 3 seconds until the screen lights up.
- 3. Setup Wizard: Follow on-screen prompts to select language, connect to Wi-Fi, and sign in.
- **4. Security Setup:** Configure face unlock, fingerprint, or PIN for device security.
- **5. App Installation:** Download essential apps from the app store.

## **Key Features**

**Professional Camera System:** Capture stunning photos with advanced camera featuring night mode, portrait mode, and 4K video recording.

Lightning-Fast Performance: Apple M2 ensures smooth gaming and multitasking.

All-Day Battery: Large mAh battery with fast charging support.

**Immersive Display:** 10.9 inch display with HDR10+ support for vivid colors.

**5G Connectivity:** 4G LTE connectivity for reliable mobile data.