# CMPE 212 Principles of Digital Design

Lecture 2

Number Systems

January 27, 2016

www.csee.umbc.edu/~younis/CMPE212/CMPE212.htm

#### Lecture's Overview

#### Previous Lecture:

- Von Neumann and System Bus models.
- Different levels of abstractions
   (programmer's view, operating system view, hardware designer, etc.)
- Some historical perspective
- Digital versus analog systems
   (concepts covered in this course goes beyond computers)

### ☐ This Lecture:

- Different representations of numbers
- Arithmetic in different radix
- Converting numbers between bases (whole and fractions)

## **Weighted Position Code**

- Number systems: Ordered set of symbols or digits, with defined relations for  $+ \times \div$
- The base, or radix of a number system defines the number of symbols, i.e., the range of possible values that a digit may have:
  0 9 for decimal; 0,1 for binary; 0 7 for octal; 0-4 base 5
- The general form for determining the decimal value of a number is given by: n=1

$$Value = \sum_{i=-m}^{n} b_i . k^i$$

#### **Example:**

$$541.25_{10} = 5 \times 10^{2} + 4 \times 10^{1} + 1 \times 10^{0} + 2 \times 10^{-1} + 5 \times 10^{-2}$$

$$= (500)_{10} + (40)_{10} + (1)_{10} + (2/10)_{10} + (5/100)_{10}$$


$$= (541.25)_{10}$$




## **Addition in Different Bases**


+	0	1	2	3	4
0	0	1	2	3	4
1	1	2	3	4	10
2	2	3	4	10	11
3	3	4	10	11	12
4	4	10	11	12	13

Base 5






**Binary** 



#### Decimal (Base 10)

- Addition table enlists the results of adding two one-digit numbers
- Analogous to decimal, the addition table for other bases
- Carry out reflects a complete cycle



## **Binary Addition**

$$Sum_i = (a_i + b_i + Carry_{in}) \mod 2$$

 $Carry_{out} = (a_i + b_i + Carry_{in}) / 2$ 




**Mohamed Younis** 

\* Slide is (partially) courtesy of M. Murdocca and V. Heuring

# **Binary Subtraction**

 $Result_i = (a_i - b)$ 

 $Borrow_{out} = (a_i)$ 



<mark>i - Borrow<sub>in</sub></mark>	2	Must borr the new s					1 = 1				
- b <sub>i</sub> - Borrov		After the first borrow, the new subtraction for this column is $0-1$ , so we must borrow again.					in.	1	1		
	to reach 100 = 01	e borrow ripples through three columns reach a borrowable 1, i.e., 0 = 011 (the modified bits) + 1 (the borrow)					ns				
		comply	(ehrvin)	ball light	0	10	1)	1	10	10	/
minuend	X	229		1	1	1	Ø	Ø	1	0	
subtrahend	Y	- 46		0	0	1	0	1	1	1	-
difference	X - Y	183	000001	1	0	1	1	0	1	1	1

- Representation of negative numbers covert subtraction to be addition
- Similarity of the equations enables the use of the same circuit to add and subtract

# **Signed Fixed Point Numbers**

- □ For an 8-bit number, there are  $2^8 = 256$  possible bit patterns. These bit patterns can represent negative numbers if we choose to assign bit patterns to numbers in this way. We can assign half of the bit patterns to negative numbers and half of the bit patterns to positive numbers.
- ☐ Four signed representations we will cover are:
  - Signed Magnitude
  - > Radix complement (e.g., Two's Complement for binary)
  - Diminished radix complement (e.g., One's complement for binary)
  - Excess-M (Biased)

# **Signed Magnitude**

 □ Also known as "sign and magnitude," the leftmost bit is the sign (0 = positive, 1 = negative) and the remaining bits are the magnitude.

#### ■ Example:

$$+25_{10} = 00011001_2$$
 ,  $-25_{10} = 10011001_2$ 

☐ Two representations for zero:


$$+0 = 00000000_2$$
,  $-0 = 10000000_2$ 

- ☐ Using an 8-bit representation:
  - ➤ Largest number is +127<sub>10</sub>, smallest number is -127<sub>10</sub>
- ☐ Using an N-bit representation:
  - $\triangleright$  Largest number is +(2<sup>N-1</sup>-1)<sub>10</sub>, smallest number is -(2<sup>N-1</sup>-1)<sub>10</sub>



# **Unsigned Multiplication**

■ Multiplication of two 4-bit unsigned binary integers produces an 8-bit result



■ Multiplication of two 4-bit signed binary integers produces only a 7-bit result (each operand reduces to a sign bit and a 3-bit magnitude, producing a sign-bit and a 6-bit result)



# **Example of Base 2 Division**

- $\Box$  (7 / 3 = 2)<sub>10</sub> with a remainder R of 1.
- $\square$  Equivalently, (0111/11 = 10)<sub>2</sub> with a remainder R of 1.



## **Base Conversion**

#### **Integer Part**

- If source radix S < target radix T</li>
  - Evaluate the polynomial representation of the number in the target number system, e.g.,  $(32)_4 = 3 \times 4^1 + 2 \times 4^0 = (14)_{10}$
- If source radix S > Target radix T

$$(N)_S = d_{n-1}S^{n-1} + ... + d_1S^1 + d_0S^0$$
  
=  $(M)_T = x_{m-1}T^{m-1} + ... + x_1T^1 + x_0T^0$ 

Apply Reminder Method in order to determine the digits  $x_{m-1}, \ldots, x_1, x_0$ 

$$(N)_S = (M)_T = (x_{m-1}T^{m-2} + ... + x_1)T^1 + x_0T^0$$

→ 
$$x_0 = (N)_S$$
 modulo T,  $Q1 = (N)_S / T = x_{m-1} T^{m-2} + ... + x_1$ 

→ 
$$x_1$$
= Q1 modulo T, Q2 = Q1 / T =  $x_{m-1}$ T<sup>m-2</sup> + ... +  $x_2$ 

... and so on

#### **Fraction Part**


$$F = d_{-1}S^{-1} + d_{-2}S^{-2} + ...$$
  $= x_{-1}T^{-1} + x_{-2}T^{-2} + ...$ 

Repetitively multiply by T (Multiplication Method) the fraction part

$$F \times T = x_{-1} + x_{-2}T^{-1} + ... \rightarrow x_{-1} = [F \times T]$$
, which is the integer part

## **Base Conversion: Remainder Method**

- Example: Convert 23.375<sub>10</sub> to base 2.
- Start by converting the integer portion:






**Mohamed Younis** 

# **Base Conversion: Multiplication Method**

• Now, convert the fraction:




• Putting it all together, 23.375  $_{10}$  = 10111.011  $_2$  .



# **Non-terminating Base 2 Fraction**

We can't always convert a terminating base 10 fraction into an equivalent terminating base 2 fraction:





<sup>:</sup> 

<sup>.</sup> 

<sup>\*</sup> Slide is courtesy of M. Murdocca and V. Heuring

# Base 2, 8, 10, 16 Number Systems

	Binary (base 2)	Octal (base 8)	Decimal (base 10)	Hexadecimal (base 16)
Example:	0	0	0	0
Show a column for ternary	1	1	1	1
(base 3). As an extension	10	2	2	2
of that, convert 14 <sub>10</sub> to	11	3	3	3
base 3, using 3 as the	100	4	4	4
divisor for the remainder	101	5	5	5
method (instead of 2).	110	6	6	6
	111	7	7	7
	1000	10	8	8
	1001	11	9	9
Decult :- 440	1010	12	10	A
Result is 112 <sub>3</sub>	1011	13	11	В
	1100	14	12	C
	1101	15	13	D
	1110	16	14	E
* Slide is courtesy of M. Murdocca and V. Heu	1111	17	15	F

## **More on Base Conversions**

Converting among power-of-2 bases is particularly simple:

$$1011_2 = (10_2)(11_2) = 23_4$$

$$23_4 = (2_4)(3_4) = (10_2)(11_2) = 1011_2$$

$$101010_2 = (101_2)(010_2) = 52_8$$

$$01101101_2 = (0110_2)(1101_2) = 6D_{16}$$

How many bits should be used for each base 4, 8, etc., digit?

For base 2, in which  $2 = 2^1$ , the exponent is 1 and so one bit is used for each base 2 digit. For base 4, in which  $4 = 2^2$ , the exponent is 2, so two bits are used for each base 4 digit. Likewise, for base 8 and base 16,  $8 = 2^3$  and  $16 = 2^4$ , and so 3 bits and 4 bits are used for base 8 and base 16 digits, respectively.



#### Conclusion

#### ☐ Summary

- → Different representations of numbers (Radix, Weighted Position Code, Binary, octal and hexadecimal)
- → Arithmetic in different radix
- → Converting numbers between bases (multiplication and remainder conversion method, bit grouping)
- → Converting integer and fractions

#### ■ Next Lecture

- → Representation of signed fixed numbers
  - Signed Magnitude

Diminished radix Complement

Excess (Biased)

> Radix Complement

Reading assignment: sections 1.1 - 1.3, in the textbook

