

Lecture 2

Binary Codes, Signed & Unsigned Numbers - 1's & 2's Complement



CSE260 : Digital Logic Design

Binary Coded Decimal (BCD)

- Decimal numbers are more natural to humans. Binary numbers are natural to computers. Quite expensive to convert between the two.
- If little calculation is involved, we can use some *coding schemes* for decimal numbers.
- One such scheme is **BCD**, a.k.a the **8421** code.
- Represent each decimal digit as a **4-bit binary code**.

Binary Coded Decimal (BCD)

Decimal digit	0	1	2	3	4
BCD	0000	0001	0010	0011	0100
Decimal digit	5	6	7	8	9
BCD	0101	0110	0111	1000	1001

- Also known as the **8421** code.
- Represent each decimal digit as a **4-bit binary code**.
- Some codes are unused, eg: $(1010)_{\text{BCD}}$, $(1011)_{\text{BCD}}$, ..., $(1111)_{\text{BCD}}$. These codes are considered as errors.
- Easy to convert, but arithmetic operations are more complicated.
- Suitable for interfaces such as keypad inputs and digital readouts.

Binary Coded Decimal (BCD)

Decimal digit	0	1	2	3	4
BCD	0000	0001	0010	0011	0100
Decimal digit	5	6	7	8	9
BCD	0101	0110	0111	1000	1001

- Examples:

$$(234)_{10} = (0010\ 0011\ 0100)_{\text{BCD}}$$

$$(7093)_{10} = (0111\ 0000\ 1001\ 0011)_{\text{BCD}}$$

$$(1000\ 0110)_{\text{BCD}} = (86)_{10}$$

$$(1001\ 0100\ 0111\ 0010)_{\text{BCD}} = (9472)_{10}$$

Note: BCD is **not equivalent** to binary.

$$\text{Example: } (234)_{10} = (11101010)_2$$



Binary Codes

Other Codes:

- Excess-3

Decimal Digit	BCD 8421	Excess-3
0	0000	0011
1	0001	0100
2	0010	0101
3	0011	0110
4	0100	0111
5	0101	1000
6	0110	1001
7	0111	1010
8	1000	1011
9	1001	1100
Unused Bit Combinations	1010	0000
	1011	0001
	1100	0010
	1101	1101
	1110	1110
	1111	1111

Negative Numbers Representation

- There are three common ways of representing signed numbers (positive and negative numbers) for binary numbers:



Sign
and
Magnitude



1s Complement



2s Complement

Sign-and-Magnitude

- Negative numbers are usually written by writing a minus sign in front.

❖ Example:

$-(12)_{10}$, $-(1100)_2$


- In computer memory of fixed width, this sign is usually represented by a bit:

0 for +

1 for -

Sign-and-Magnitude [cont.]

- Example: an 8-bit number can have 1-bit sign and 7-bits magnitude.



Signed magnitude representation

Examples:

	1101_2	$= 13_{10}$	(a 4-bit unsigned number)
0	1101	$= +13_{10}$	(a positive number in 5-bit signed magnitude)
1	1101	$= -13_{10}$	(a negative number in 5-bit signed magnitude)

	0100_2	$= 4_{10}$	(a 4-bit unsigned number)
0	0100	$= +4_{10}$	(a positive number in 5-bit signed magnitude)
1	0100	$= -4_{10}$	(a negative number in 5-bit signed magnitude)

Sign-and-Magnitude [Cont.]

- Largest Positive Number: 0 1111111 $+(127)_{10}$
- Largest Negative Number: 1 1111111 $-(127)_{10}$
- Zeroes:

0 0000000	$+(0)_{10}$
1 0000000	$-(0)_{10}$
- Range: $-(127)_{10}$ to $+(127)_{10}$
- Signed numbers needed for negative numbers.
- Representation: Sign-and-magnitude.

1s Complement


- Given a number x which can be expressed as an n -bit binary number (*i.e. integer part has n digits and fraction has m digit*), its negative value can be obtained in **1s-complement** representation using:

Decimal Digit	1's complement
+7	0111
+6	0110
+5	0101
+4	0100
+3	0011
+2	0010
+1	0001
+0	0000

Decimal Digit	1's complement
-7	1000
-6	1001
-5	1010
-4	1011
-3	1100
-2	1101
-1	1110
-0	1111

1s Complement [Cont.]

$-(00001100)_2$



$(11110011)_{1's}$

1s Complement [Cont.]

- Essential technique: **invert** all the bits.

Examples: 1s complement of $00000001 = (11111110)_{1s}$

1s complement of $01111111 = (10000000)_{1s}$

- Range [in 8 bits]: $-(127)_{10}$ to $+(127)_{10}$
- General Formula = $-(2^{n-1} - 1)$ to $+(2^{n-1} - 1)$**
- The most significant bit still represents the sign:
 $0 = +ve$; $1 = -ve$.

Note: Range for n bit no. is $-(2^{(n-1)}-1)$ to $+(2^{(n-1)}-1)$

1s Complement

Example: (assuming 8-bit binary numbers)

$$(14)_{10} = (00001110)_2 = (00001110)_{1s}$$

$$-(14)_{10} = -(00001110)_2 = (11110001)_{1s}$$

$$-(80)_{10} = -(?)_2 = (?)_{1s}$$

2s Complement

- Given a number x which can be expressed as an n -bit (*i.e. integer part has n digits and fraction has m digit*) number, its negative number can be obtained in **2s-complement** representation using:

$$-x = 2^n - x$$

Example: With an 8-bit number 00001100, its negative value in 2s complement is thus:

$$\begin{aligned}
 -(00001100)_2 &= -(12)_{10} \\
 &= (2^8 - 12)_{10} \\
 &= (244)_{10} \\
 &= \mathbf{(11110100)_{2s}}
 \end{aligned}$$

2s Complement [cont.]

- **Method 1:** Essential technique: **invert** all the bits and **add 1**.

Examples:

2s complement of

$$\begin{aligned}(00000001)_{2s} &= (11111110)_{1s} \text{ (invert i.e 1's complement)} \\ &= (11111111)_{2s} \text{ (add 1)}\end{aligned}$$

2s complement of

$$\begin{aligned}(01111110)_{2s} &= (10000001)_{1s} \text{ (invert i.e 1's complement)} \\ &= (10000010)_{2s} \text{ (add 1)}\end{aligned}$$

Official
Method

Unofficial
Method

- **Method 2:** Keep unchanged till 1st occurrence of 1 from LSB and invert remaining 1's into 0's and 0's into 1's till MSB

$$(01111110)_{2s} = (10000010)_{2s}$$

2s Complement [Cont.]

Range in 8 bits: $-(128)_{10}$ to $+(127)_{10}$

General Formula = $-(2^{n-1})$ to $+(2^{n-1}-1)$

The most significant bit still represents the sign:

0 = +ve; 1 = -ve.

Note: Range for n bit no. is $-2^{(n-1)}$ to $+2^{(n-1)}-1$

2s Complement

Example: (assuming 8-bit binary numbers)

$$(14)_{10} = (00001110)_2 = (00001110)_{2s}$$

$$-(14)_{10} = -(00001110)_2 = (11110010)_{2s}$$

$$-(80)_{10} = -(?)_2 = (?)_{2s}$$

Comparisons of three methods

Example: 4-bit signed number (*Positive Values*)

Values	Sign and Magnitude	1's Complement	2's Complement
+7	0111	0111	0111
+6	0110	0110	0110
+5	0101	0101	0101
+4	0100	0100	0100
+3	0011	0011	0011
+2	0010	0010	0010
+1	0001	0001	0001
+0	0000	0000	0000

Note: Signed magnitude cannot be used for arithmetic calculations

Comparisons of three methods

Example: 4-bit signed number (*Negative Values*)

Values	Sign and Magnitude	1's Complement	2's Complement
-0	1000	1111	0000
-1	1001	1110	1111
-2	1010	1101	1110
-3	1011	1100	1101
-4	1100	1011	1100
-5	1101	1010	1011
-6	1110	1001	1010
-7	1111	1000	1001
-8	-	-	1000

Note: Signed magnitude cannot be used for arithmetic calculations

Exercise

1. For 2's complement binary numbers, the range of values for 5-bit numbers is

- a. 0 to 31 b. -8 to +7 c. -8 to +8
d. -15 to +15 e. -16 to +15

2. In a 6-bit 2's complement binary number system, what is the decimal value represented by $(100100)_2$?

- a. -4 b. 36 c. -36 d. -27 e. -28

3. Following numbers are in 1's complement system. Turn them to their no. negative representation

- A. 1010101 B. 0111000 C. 0000001 D. 00000

4. Now perform 2's complement

UNSIGNED NO. ARITHMETIC OPERATION!

Binary Arithmetic Operations for Unsigned numbers

ADDITION

- Like decimal numbers, two numbers can be added by adding each pair of digits together with carry propagation.

$$\begin{array}{r}
 (11011)_2 \\
 + (10011)_2 \\
 \hline
 (101110)_2
 \end{array}$$

$$\begin{array}{r}
 (647)_{10} \\
 + (537)_{10} \\
 \hline
 (1184)_{10}
 \end{array}$$

UNSIGNED NO. ARITHMETIC OPERATION!

Binary Arithmetic Operations for Unsigned numbers

SUBTRACTION

- Two numbers can be subtracted by subtracting each pair of digits together with borrowing, where needed.

$$\begin{array}{r}
 (11001)_2 \\
 - (10011)_2 \\
 \hline
 (00110)_2 \\
 \hline
 \end{array}$$

$$\begin{array}{r}
 (627)_{10} \\
 - (537)_{10} \\
 \hline
 (090)_{10} \\
 \hline
 \end{array}$$



Overflow

Arithmetic Overflow happens in signed arithmetic when the result is too big or too small to fit in the available bits, causing wrong answers and mistakes in the sign of the number.


Overflow Detection Rules

Rule-1: Add two same signed numbers
if (result also has the same sign):
 No Overflow;
else:
 Overflow;

Rule-2: Sub two same signed Numbers:
 Never Overflow;

Rule-3: Add two different signed Numbers:
 Never Overflow;

Rule-4: Sub two different numbers:
 Case-1: $+A - (-B) = +A + (+B) \Rightarrow$ Follow Rule-1
 Case-2: $-A - (+B) = -A + (-B) \Rightarrow$ Follow Rule-1



ARITHMETIC OPERATIONS ON SIGNED NUMBER

2s Complement Addition/Subtraction

- Algorithm for addition, $A + B$:

1. Perform binary addition on the two numbers.
2. Ignore the carry out of the MSB (most significant bit).
3. Check for overflow: Overflow occurs if the 'carry in' and 'carry out' of the MSB are different, or if result is opposite sign of A and B.

- Algorithm for subtraction, $A - B$:

$$A - B = A + (-B)$$

1. Take 2s complement of B by inverting all the bits and adding 1.
2. Add the 2s complement of B to A.

2s Complement Addition/Subtraction

Example: in a 4-bit binary system

+3	0011
+ +4	+ 0100
----	-----
+7	0111
----	-----

-1	1111
+ -5	+ 1011
----	-----
-6	1 1010
----	-----

+6	0110
+ -3	+ 1101
----	-----
+3	1 0011
----	-----

+4	0100
+ -7	+ 1001
----	-----
-3	1101
----	-----

Which of the above is/are overflow(s)?

2s Complement Addition/Subtraction

Example: in a 4-bit binary system

-3	1101
+ -6	+ 1010
----	-----
-9	1 0111
----	-----

+5	0101
+ +6	+ 0110
----	-----
+11	1011
----	-----

Which of the above is/are overflow(s)?

1s Complement Addition/Subtraction

- Algorithm for addition, $A + B$:

1. Perform binary addition on the two numbers.
2. If there is a carry out of the MSB, **add 1 to the result.**
3. Check for overflow: Overflow occurs if result is opposite sign of A and B.

- Algorithm for subtraction, $A - B$:

$$A - B = A + (-B)$$

1. Take 1s complement of B by inverting all the bits.
2. Add the 1s complement of B to A.

1s Complement Addition/Subtraction

Example: in a 4-bit binary system

+3	0011
+ +4	+ 0100
----	-----
+7	0111
----	-----

+5	0101
+ -5	+ 1010
----	-----
-0	1111
----	-----

-2	1101
+ -5	+ 1010
----	-----
-7	10111
----	+ 1

	1000

-3	1100
+ -7	+ 1000
----	-----
-10	10100
----	+ 1

	0101

Sample Math:

Add -3 with -6 in 6 bits using 2's complement number system and justify whether there is overflow or not.

Solution:

Unsigned 3 = 11

+3 = 011

+3 in 6 bits = 000011

To get -3 in binary, we need to calculate 2's complement.

So, 111100 (1's complement)

+1 (Adding 1)

-3 in 6 bits = 111101 (2's complement)

----- (1)

Unsigned 6 = 110

+6 = 0110

+6 in 6 bits = 000110

To get -6 in binary, we need to calculate 2's complement.

So, 111001 (1's complement)

+1 (Adding 1)

-6 in 6 bits = 111010 (2's complement)

----- (2)

Sample Math [Cont.]:

Add -3 with -6 in 6 bits using 2's complement number system and justify whether there is overflow or not [cont.]

Now, adding (1) and (2),

$$\begin{array}{r}
 111101 \\
 111010 \\
 \hline
 1\ 110111
 \end{array}$$

Ignoring the carry, final result is 110111

Here, we are adding two negative numbers and the result is also a negative number. Hence, there is no overflow.