Micro Servo 9G




Bloques De Facilino


Micro Servo:

Se encuentran dentro de:

Puerto en Serie:

Se encuentra dentro de:





Codigo Facilino

Comunicación

USB Serie



Codigo Arduino

```
#define D8 12
#include <ESP32_Servo.h>
/*** Global variables ***/
Servo _servoD8;
/*** Function declaration ***/
/*** Class declaration
/*** Tasks declaration ***/
/*** ISR function declaration
/*** Additional Global variables ***/
void setup()
{
 _servoD8.attach(D8);
   _servoD8.write(0);
 Serial.begin(115200);
}
void loop(){
   _servoD8.write(Serial.parseFloat());
}
/*** Function definition ***/
```