Relay Commands

Makes the second relay active.							
Sample Command	Command		Relay Number		Relay Status		End Of Command
ro 21;	ro	space	2	space	1	space	;
	relay operate	sps	2nd relay	sps	active	sps	
Makes the fourth relay deactive.							
Sample Command	Command		Relay Number		Relay Status		End Of Command
ro 40;	ro	space	4	ace	0	space	;
	relay operate	sps	4th relay	sbs	deactive	spa	
??							
Sample Command	Command		End Of	Com	nmand		
rl ;	ri	ge		;			
	relay list	space					

Alarm Commands

Sets the alarm at the specified date time	e. Note that, minute s	s can	be set to multip	les o	f ten . The wee	k star	ts on Monday. /	At D a	y Of Week Ta	b , 1 s	tands for Mon o	lay a	nd 7 for Sunday				
Sample Command	Command		Alarm Id		Repeat		Day Of Week		Hour		Minute		Relay Number		Status		End Of Command
as 1 1 7 23 50 7 1 ;	as	space	1	space	1	space	7	space	23	space	10	ge	3	space	1	space	;
	alarm set	sps		sps	yes	sp	Sunday	sps		spe		space	3rd relay	spe	active	sps	
	the alarm at the specified date time. Note that, minutes can be set to multiples of ten. The week starts on Monday. At Day Of Week Tab, 1 stands for Sample Command. Sample Command. Alarm Id. Beneat. Day Of Week. Hour.																
Sample Command	Command		Alarm Id		Repeat		Day Of Week		Hour		Minute		Relay Number		Status		End Of Command
as 2 0 1 22 20 1 0 ;	as	space	2	space	0	space	1	space	22	space	20	space	1	space	0	space	;
	alarm set	gs		g	no	g	Monday	Sp		S		Sp	1st relay	Sp	deactive	Sp	
Deletes the alarm according to the given																	
Sample Command	Command		Alarm Id		End O	f Cor	nmand										
ad 1 ;	ad	9	1	8		;											
		g		ă													
	alarm delete	space		space													
	alarm delete	spa		sba													
		spa		sba													
ists the alarms to the Arduino Serial Me	onitor.	spa															
Sample Command	onitor. Command		End Of		mand												
	onitor.	space	End Of		mand												

Real Time Clock Commands

sets the real time clock according to the g	iven date time fo	rmat.													
Sample Command	Command		Year		Month		Date		Hour		Minute		Second		End Of Comman
cs 2018 10 23 12 34 56 ;	cs	space	2018	Sce	10	space	23	space	12	space	34	space	56	space	;
	clock set	spe		space		sp8		sps		spe		spe		sps	
Gets the date time from the real-time cloc	k.														
Gets the date time from the real-time cloc Sample Command	k. Command		End C	Of Com	nmand										
		space		Of Com	nmand										

Peripheral Commands (Voltage, Current, Temperature)

Gets the peripherals values from ports.			
Sample Command	Command		End Of Command
pg;	pg	ace	;
	peripheral get	sps	

AlarmTask

Purpose:				II	D				Repeat					D	ateTin	пе					Rela	nber	Status	
Bit Representation (Example):	0	0	0	0	0	0	0	0	1	0	0	1	0	1	1	0	0	0	1	1	1	1	1	1
Range:				(0-	255)				(0 1)	Da	y Of We	eek	Hour (0 - 24) Min(0 - 5)								(0-7	(0 1)		
Total Bits:				8 b	oits				1 bit		3 bits				5 bits				3 bits	s	3 bits			1 bit
Real Values (Example):				(ס		_		TRUE	;	Sunday	,	12								7			On
Bytes:				1 B	yte											2 B	yte							

RTC

Purpose:		YE	EAR				Month			Day					Н	our					Minute				Second						
Bit Representation (Example):	0 0	1	0	1	0 0	1	0	0	1	0	1	1	1	0	0	0 1	1	1	1	1	1	1	1	0	0	0	0	0	0		
Mask		0xFC	000000			0x0	03C000000	1		0x0	03E000	00			0x000	1F000			0x00000FC0						0x0000003F						
Range:		(0-	- 64)			(0 1)	Day Of W	eek		Hour	r (0 - 2	24)			Min(0 - 5)				(0	-7)(0	1)									
Real Values (Example):		1	18				4				23				;	3															
Total Bits:		6 l	bits				4 bits			5	5 bits				5 l	oits					6 bits					6	bits				
Bytes:			1 By	rte					2	2 Byte	е						3	3 Byte						4 Byte							