HIGH-RISK ACTIVITY | SERNEM PRO SERIES | VERIFIED 2026

SERNEM

HEALTH AND SAFETY RESOURCES

WORKING AT HEIGHT CRITICAL SAFETY RULES

PLAN • PRIORITIZE COLLECTIVE PROTECTION • PREVENT FALLS

OSHA 29 CFR 1926 | EN 361 • EN 365 • EN 795 | ISO 45001 FRAMEWORK

DOCUMENT

SRN-WAH-001

Revision 2.0

EN

SCAN

Open the digital poster library

SERNEM PRE-JOB CONTROL

CHECK BEFORE STARTING

30 SEC CHECK

- ✓ WORK PERMIT
- ✓ RISK ASSESSMENT
- ✓ TOOLBOX TALK
- ✓ RESCUE PLAN
- ✓ WEATHER
- ✓ PPE CHECK
- ✓ AREA ISOLATION

01 — MANDATORY



PRE-WORK PLANNING

- ✓ Verify the risk assessment and work permit.
- ✓ Define the safe access and work method.
- ✓ Barricade the area below and prevent unauthorized access.

02 — MANDATORY



USE COLLECTIVE PROTECTION

- ✓ Use guardrails, platforms or suitable scaffolds first.
- ✓ Protect openings with secure covers or barriers.
- ✓ Do not start if collective protection is incomplete.

03 — MANDATORY



FULL BODY HARNESS

- ✓ Inspect webbing, stitching and labels before every use.
- ✓ Wear, fasten and adjust the harness correctly.
- ✓ Remove damaged or fall-arrested equipment from service.

04 — MANDATORY



APPROVED ANCHORAGE

- ✓ Connect only to a designated and approved anchorage.
- ✓ Verify a capacity of 22.2 kN per attached worker.
- ✓ Select an anchorage above head level whenever possible.

05 — WARNING



FALL CLEARANCE

- ✓ Calculate free-fall and total clearance distance.
- ✓ Prevent contact with lower levels or obstructions.
- ✓ Minimize the risk of a swing fall.

06 — MANDATORY



SAFE ACCESS

- ✓ Use inspected access equipment suitable for the task.
- ✓ Maintain three-point contact on ladders.
- ✓ Keep access routes clear, stable and unobstructed.

07 — WARNING



PREVENT DROPPED OBJECTS

- ✓ Secure tools using a suitable tethering system.
- ✓ Store materials safely away from edges.
- ✓ Isolate the area below and control access.

08 — INFORMATION



RESCUE READINESS

- ✓ Prepare a workable rescue plan before starting.
- ✓ Ensure rescue equipment and trained personnel are available.
- ✓ Verify emergency communication and response arrangements.

CRITICAL STOP CRITERIA

STOP WORK NOW

STOP

- ✖ THERE IS NO APPROVED ANCHORAGE OR FALL PROTECTION
- ✖ THE HARNESS, LANYARD OR CONNECTOR IS DAMAGED
- ✖ AN UNPROTECTED EDGE OR OPEN HOLE IS PRESENT
- ✖ NO RESCUE PLAN OR RESPONSE CAPABILITY IS AVAILABLE
- ✖ WIND, ICE OR VISIBILITY CONDITIONS ARE UNSAFE

TECHNICAL CONTROL

CRITICAL VALUES

1,8 m OSHA CONSTRUCTION THRESHOLD	**22,2 kN** ANCHORAGE VALUE / WORKER
100% CONTINUOUS TIE-OFF	**3-POINT** LADDER CONTACT

REFERENCE

OSHA 29 CFR 1926.501 / 1926.502

EN 361 • EN 365 • EN 795

PERSONAL PROTECTIVE EQUIPMENT

REQUIRED PPE



- CHIN-STRAP HELMET — EN 397
- SAFETY GLASSES — EN 166
- WORK GLOVES — EN 388
- SLIP-RESISTANT FOOTWEAR — ISO 20345
- FULL BODY HARNESS — EN 361

ENGINEERING CONTROLS FIRST, PERSONAL PROTECTION SECOND.

SERNEM

Better Safety, Better Tomorrow.

STOP WORK IF IT IS UNSAFE!

VERIFIED • PRO SERIES • 2026

www.sernem.com